

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [Anderic](#) /

> [Anderic RR7099T Replacement Remote Control User Manual for Harbor Breeze CHQ8BT7098T Ceiling Fans](#)

Anderic RR7099T

Anderic RR7099T Replacement Remote Control User Manual

For Harbor Breeze CHQ8BT7098T Ceiling Fans

1. INTRODUCTION

This manual provides instructions for the Anderic RR7099T replacement remote control, designed to operate Harbor Breeze CHQ8BT7098T ceiling fans. This remote offers identical functionality to the original equipment, ensuring seamless control of your fan and light.

2. COMPATIBILITY INFORMATION

The Anderic RR7099T remote control is specifically engineered as a direct replacement for the original Harbor Breeze CHQ8BT7098T remote. To ensure compatibility, verify that your existing remote control has the FCC ID: **CHQ8BT7098T** printed on its back.

Important Note: This remote control is **not** compatible with KUJCE9201 models.

3. PACKAGE CONTENTS

- Anderic RR7099T Remote Control
- Wall Mount Holder
- Mounting Screws (for wall holder)
- Instruction Manual (this document)





Image: Anderic RR7099T remote control shown within its included wall mount holder.

4. SETUP AND INSTALLATION

4.1. Battery Installation

The remote control requires batteries (not included). Open the battery compartment cover on the back of the remote and insert the correct battery type, observing polarity (+/-) as indicated inside the compartment. Close the cover securely.

4.2. Dip Switch Configuration

To ensure proper communication with your ceiling fan, the new remote's dip switches must match the settings of your original remote or the receiver unit in your fan. This step is crucial for the remote to function correctly.

1. Locate the battery compartment on the back of the Anderic RR7099T remote control.
2. Inside the battery compartment, you will find a set of small switches, typically numbered (e.g., 1, 2, 3, 4). These are the dip switches.
3. Carefully open the battery compartment of your **original** Harbor Breeze CHQ8BT7098T remote control (if available) or access the receiver unit in your ceiling fan to identify its dip switch settings.
4. Match the position (ON/OFF or UP/DOWN) of each dip switch on the Anderic RR7099T remote to the corresponding switch on your original remote or fan receiver. Pay close attention to the labeling, as 'ON' positions might be indicated differently or appear reversed between units.
5. Once the dip switches are matched, close the battery compartment cover on the new remote.



Image: Rear view of the Anderic RR7099T remote control, illustrating the battery compartment and the accessible dip switches for code matching.

4.3. Wall Mount Holder Installation

The included wall mount holder provides a convenient storage location for your remote. Use the provided screws to secure the holder to a desired wall surface. Ensure the surface is suitable for screw installation.

5. OPERATING INSTRUCTIONS

The Anderic RR7099T remote control features intuitive buttons for controlling your ceiling fan and light functions.



Daria Electronics Etc. Inc.



ANDERIC
FAN & LIGHTING

DR1000T



Image: Front view of the Anderic RR7099T remote control, displaying the LCD screen, LIGHT button, and FAN button.

- **LIGHT Button:**

Press this button once to turn the ceiling fan light ON or OFF. Press and hold this button to dim or brighten the light. The LCD display will show the light intensity percentage.

- **FAN Button:**

Press this button repeatedly to cycle through the fan speed settings: Low, Medium, High, and Off. The LCD display will indicate the current fan speed setting.

6. TROUBLESHOOTING

- **Remote Not Responding:**

Ensure that fresh batteries are correctly installed in the remote control. Verify that the dip switch settings on the remote precisely match those of your ceiling fan's receiver unit.

- **Inconsistent Light Dimming:**

If the light dimming function is inconsistent, especially with LED bulbs, this can sometimes be due to compatibility issues between the fan's receiver and certain LED bulb types. The remote's functionality is designed to replicate the original remote's performance.

- **Limited Range:**

Ensure there are no obstructions between the remote and the ceiling fan receiver. Replace batteries if the range is significantly reduced.

7. SPECIFICATIONS

Model Number	RR7099T
Compatible With	Harbor Breeze CHQ8BT7098T Ceiling Fans
Connectivity Technology	Radio Frequency
Max Number of Supported Devices	1
Item Weight	3.2 ounces
Package Dimensions	7.01 x 2.76 x 1.85 inches

8. SUPPORT

For further assistance or inquiries regarding your Anderic RR7099T replacement remote control, please contact Anderic support:

Website: www.anderic.com

Phone: 1-855-263-1742

