

[Manuals.plus](#) /

> [Marsail](#) /

> Marsail Glass Electric Standing Desk with Drawer (Model MSED32W-US) - User Manual

Marsail MSED32W-US

Marsail Glass Electric Standing Desk with Drawer (Model MSED32W-US) - User Manual

48x24 Inch White Glass Top Height-Adjustable Desk

1. INTRODUCTION

Thank you for choosing the Marsail Glass Electric Standing Desk with Drawer. This desk is designed to provide a versatile and ergonomic workspace, allowing seamless transitions between sitting and standing positions. Featuring a durable tempered glass top and convenient integrated storage, this manual will guide you through the assembly, operation, and maintenance of your new desk to ensure optimal performance and longevity.



Image 1.1: Marsail Glass Electric Standing Desk in use.

2. SAFETY INFORMATION

Please read and adhere to the following safety guidelines to prevent injury or damage to the product:

- Ensure the desk is securely assembled following the provided instructions.
- Do not exceed the maximum weight limit of **110 lbs (50 kg)**. Exceeding this limit may compromise stability and cause damage or injury.
- Use the desk's adjustable height feature to maintain proper posture and minimize back pain.
- Regularly inspect the desk for any signs of wear or damage. Address any issues promptly to ensure continued safe use.

- Keep children and pets away from the desk during height adjustments.
- Ensure no obstructions are present in the desk's path during height adjustments.

3. PACKAGE CONTENTS

Verify that all components are present before beginning assembly. If any parts are missing or damaged, please contact Marsail customer support.

- Tempered Glass Desktop (48x24 Inch)
- Desk Frame (Legs and Crossbar)
- Integrated Drawer Assembly
- Control Panel
- Power Adapter and Cable
- Assembly Hardware (Screws, Allen Wrenches)
- Instruction Manual

4. ASSEMBLY INSTRUCTIONS

The Marsail Glass Electric Standing Desk is designed for straightforward assembly. It is recommended that **two people** assemble the desk. All necessary tools, including a screwdriver, are included.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratches.
2. **Assemble Desk Frame:** Attach the desk legs to the crossbar using the provided hardware. Ensure all screws are tightened securely.
3. **Install Control Panel:** Mount the control panel to the designated location on the desk frame.
4. **Attach Drawer Assembly:** Secure the integrated drawer assembly to the underside of the desktop.
5. **Mount Desktop:** Carefully place the tempered glass desktop onto the assembled frame. Secure it using the appropriate fasteners.
6. **Connect Power:** Plug the power adapter into the desk and then into a wall outlet.



Image 4.1: Disassembled components of the Marsail Standing Desk.

5. OPERATING INSTRUCTIONS

5.1 Height Adjustment

The desk features an electric lifting mechanism for smooth height adjustments between **28.3 inches (72 cm)** and **46.4 inches (118 cm)**.

- **Raise/Lower:** Use the up and down arrows on the control panel to adjust the desk to your desired height.
- **Preset Heights:** The control panel includes 4 programmable preset buttons. To save a height, adjust the desk to the desired level, then press and hold a preset button (1-4) until you hear a beep or see a confirmation on the display. To recall a saved height, simply press the corresponding preset button.



Image 5.1: Desk height adjustment range.

5.2 Integrated Drawer Storage

The desk is equipped with a 4-zone drawer to help organize your office supplies and keep your workspace clutter-free.

- **Access:** Gently pull the drawer handle to open.
- **Organization:** Utilize the partitioned sections for efficient storage of pens, notebooks, tablets, and other small items.



Image 5.2: Detail of the 4-zone drawer storage.

5.3 Tempered Glass Desktop

The ultra-white tempered glass desktop offers a smooth, durable, and easy-to-clean surface. It can also be used as a dry-erase board for notes and brainstorming.

- **Writing Surface:** Use dry-erase markers directly on the glass surface for temporary notes.
- **Cleaning:** Wipe clean with a dry cloth or a damp cloth for more stubborn marks. Avoid abrasive cleaners.



Image 5.3: Tempered glass desktop as a writable surface.

6. MAINTENANCE

Proper maintenance ensures the longevity and appearance of your Marsail standing desk.

- **Cleaning the Glass Top:** Wipe the glass surface with a dry, soft cloth. For smudges or marks, use a damp cloth with a mild glass cleaner. Avoid abrasive materials or harsh chemicals that could scratch or damage the glass.
- **Cleaning the Frame:** Wipe the steel frame with a dry or slightly damp cloth.
- **Regular Inspection:** Periodically check all screws and connections to ensure they remain tight. Retighten if necessary.
- **Cable Management:** Ensure power cables and other device cables are not pinched or tangled during height adjustments.

7. TROUBLESHOOTING

If you encounter issues with your Marsail Electric Standing Desk, refer to the following common solutions:

Problem	Possible Cause	Solution
Desk does not move	Power cable disconnected; Overload; Motor error	Check power connections. Reduce weight on desk. Unplug for 10 seconds, then plug back in.
Uneven height adjustment	Obstruction; Uneven weight distribution	Clear any obstructions. Redistribute weight evenly on the desktop.
Noise during adjustment	Normal operation; Loose components	A slight motor sound is normal. Check for loose screws and tighten if necessary.
Preset heights not working	Not programmed correctly	Reprogram the preset heights by adjusting to desired level and holding the preset button.

If the issue persists, please contact Marsail customer support for further assistance.

8. SPECIFICATIONS

Detailed technical specifications for the Marsail Glass Electric Standing Desk (Model MSED32W-US):

- **Model Number:** MSED32W-US
- **Product Dimensions (D x W x H):** 23.6" x 47.2" x 28.3" (Minimum Height)
- **Desktop Size:** 48 x 24 Inches
- **Height Adjustment Range:** 28.3" to 46.4"
- **Maximum Weight Capacity:** 110 Pounds (50 kg)
- **Desktop Material:** Tempered Glass
- **Frame Material:** Stainless Steel
- **Color:** White Glass Top / White Frame
- **Number of Preset Heights:** 4
- **Drawer Type:** 4-Zone Utility Drawer
- **Assembly Required:** Yes (Recommended 2 people)
- **Included Tools:** Yes
- **Item Weight:** 49.8 Pounds
- **UPC:** 810158824812

Flexible Ergonomic Height



Image 8.1: Desk dimensions overview.

9. WARRANTY AND SUPPORT

Marsail provides a limited warranty for this product. For specific warranty details, please refer to the documentation included with your purchase or contact Marsail customer support.

- **Customer Support:** If you have any questions regarding assembly, operation, or product selection, please feel free to contact our professional U.S.-based product support team.

- **Contact Information:** Refer to the Marsail official website or your purchase documentation for the most current contact details.

© 2025 Marsail. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0D5LCJZ3B>

More documents and user manuals: <https://manuals.plus/>