

[Manuals.plus](#) /

› [ANFIER](#) /

› ANFIER W12 Offline Language Translator Device User Manual

ANFIER W12

ANFIER W12 Offline Language Translator Device User Manual

Model: W12

1. INTRODUCTION

Thank you for choosing the ANFIER W12 Offline Language Translator Device. This manual provides essential information for setting up, operating, and maintaining your device. The W12 is designed to facilitate seamless communication across language barriers with its advanced translation capabilities, both online and offline.

2. WHAT'S IN THE BOX

- ANFIER W12 Translator Device
- Protective Case
- Lanyard
- USB Charging Cable
- User Manual



Image: ANFIER W12 Translator Device, protective case, and lanyard. The device is white with a black screen displaying translation options. The clear protective case and blue lanyard are shown alongside.

3. DEVICE OVERVIEW

The ANFIER W12 features a compact design with a 3.7-inch Ultra-HD touchscreen for clear readability. It includes physical buttons for easy operation and a rear camera for photo translation.

3.7" Ultra-HD screen

Easy-to-read text
User-friendly for people of all ages



Image: The ANFIER W12 Translator Device held in hand, showcasing its 3.7-inch Ultra-HD screen with a user-friendly interface. The device is white with a black screen.

3.1. Physical Features

- **3.7-inch Ultra-HD Touchscreen:** For intuitive navigation and clear display of translated text.
- **Power Button:** Located on the side for turning the device on/off.
- **Volume Buttons:** Adjust audio output.
- **Translation Keys (A & B):** Dedicated buttons for initiating voice translation for two different languages.
- **Rear Camera:** Used for photo translation.
- **Microphone & Speaker:** For voice input and audio output.
- **USB-C Port:** For charging the device.

4. SETUP

4.1. Charging the Device

Before first use, fully charge the device using the provided USB charging cable. Connect the USB-C end to the device and the USB-A end to a compatible power adapter (not included) or computer USB port. A full charge typically takes approximately 90 minutes and provides up to 8 hours of continuous translation or 7 days of standby time.



Image: The ANFIER W12 Translator Device highlighting its long battery life: 8 hours continuous translation, 7 days long standby, and 90 minutes for a full charge via Type-C port.

4.2. Powering On/Off

- **To Power On:** Press and hold the Power button on the side until the screen lights up.
- **To Power Off:** Press and hold the Power button, then select 'Power Off' on the screen.

4.3. Initial Language Selection

Upon first startup, you will be prompted to select your preferred system language. Follow the on-screen instructions to complete the setup.

4.4. Connecting to Wi-Fi

For online translation and downloading offline language packs, a Wi-Fi connection is required.

1. From the main screen, tap on 'Settings'.
2. Select 'Wi-Fi'.
3. Toggle Wi-Fi 'On'.
4. Select your desired network and enter the password if prompted.

4.5. Downloading Offline Languages

The ANFIER W12 supports offline translation for 16 major languages. To use this feature, you must download the language packs in advance.

1. Ensure your device is connected to Wi-Fi.
2. From the main screen, tap on 'Settings'.
3. Select 'Offline Download'.
4. Choose the language pairs you wish to download for offline use.



Image: The ANFIER W12 Translator Device displaying the offline voice translation feature, listing 16 supported languages including English, Spanish, Simplified Chinese, Japanese, Arabic, and more.

5. OPERATING INSTRUCTIONS

5.1. Voice Translation (Online)

The device supports rapid online translation in 144 languages with up to 98% accuracy.

1. From the main screen, tap on 'Voice Translation'.
2. Select the source language (A) and target language (B) from the list.
3. To speak in language A, press and hold the 'A' button and speak clearly into the microphone. Release the button when finished. The device will translate and speak the text in language B.
4. To speak in language B, press and hold the 'B' button and speak clearly. Release the button when finished. The device will translate and speak the text in language A.

74 Languages & 70 Accents

98%

Accuracy

0.5s

Response




Image: The ANFIER W12 Translator Device displaying its capabilities: 74 languages & 70 accents, 98% accuracy, and 0.5-second response time for translations.

5.2. Offline Translation

After downloading the necessary language packs (refer to Section 4.5), you can perform translations without an internet connection for 16 major languages.

1. From the main screen, tap on 'Offline Translation'.
2. Select the desired offline language pair.
3. Proceed with translation using the 'A' and 'B' buttons as described in Voice Translation.

5.3. Photo Translation

Translate text from images, such as menus or signs, using the built-in camera.

1. From the main screen, tap on 'Photo Translation'.
2. Select the source and target languages.
3. Align the text you wish to translate within the camera frame on the screen.
4. Tap the camera icon to capture the image. The device will process the image and display the translated text.




Image: The ANFIER W12 Translator Device held up to a street sign, demonstrating its instant photo translation capability. The screen shows the original text and its translation.

5.4. Recording

The device can record audio and potentially translate it. Refer to the on-screen instructions within the 'Recording' application for detailed usage.

5.5. Settings

Access various device settings to customize your experience.

- **Wi-Fi:** Manage network connections.
- **System Language:** Change the device's interface language.
- **Time and Date:** Adjust time settings.
- **Offline Download:** Manage downloaded language packs.
- **Voice Broadcast:** Adjust voice settings, including male and female voice options.
- **Display:** Adjust screen brightness and other display preferences.




Image: The ANFIER W12 Translator Device screen displaying the 'Settings' menu, specifically highlighting the option to switch between male and female voices for translations.

6. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the device. Avoid liquid cleaners or aerosols.
- **Storage:** Store the device in a cool, dry place away from direct sunlight and extreme temperatures.
- **Protective Case:** Always use the provided protective case and lanyard to prevent accidental damage and enhance portability.

7. TROUBLESHOOTING

- **Device not turning on:** Ensure the device is fully charged. Connect it to a power source and try again.
- **Translation not working:** Check your Wi-Fi connection for online translation. For offline translation, ensure the required language packs have been downloaded.
- **Inaccurate translation:** Ensure you are speaking clearly and directly into the microphone. Verify that the correct source and target languages are selected.
- **Weak Wi-Fi signal:** Move closer to your Wi-Fi router or try connecting to a different network.
- **Battery drains quickly:** Reduce screen brightness or disable unnecessary features to conserve battery life.

8. SPECIFICATIONS

Model Number	A-W12-WHITE
Screen Size	3.7 inches
Battery Capacity	1500mAh Lithium Ion
Continuous Use Time	Up to 8 hours
Standby Time	Up to 7 days
Online Translation Languages	144 Languages and Accents
Offline Translation Languages	16 Major Languages (English, Portuguese, Indonesian, Chinese (Simplified), Arabic, Russian, French, German, Korean, Chinese (Traditional), Japanese, Spanish, Thai, Vietnamese, Hindi, Italian)
Item Weight	10.5 ounces
Package Dimensions	6.61 x 3.62 x 1.73 inches

9. SAFETY INFORMATION

- Do not expose the device to extreme temperatures, direct sunlight, or moisture.
- Avoid dropping or subjecting the device to strong impacts.
- Keep out of reach of children.
- Use only approved charging cables and accessories.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

How do I resolve the 'UNAUTHORISED ACCESS (4)' error message on my ANFIER W12 Offline Language Translator?

The error message "UNAUTHORISED ACCESS (4)" typically indicates a server-side authentication issue or a problem with the device's unique identification (SN) in the manufacturer's database. Since you have already tried restarting the device multiple...

[Read full answer](#)