

[Manuals.plus](#) /

› [Zinus](#) /

› Zinus Piper Bed Frame 150x190 cm with Upholstered Headboard - Assembly and Care Manual

Zinus EU-FPPPW3OC-12O

Zinus Piper Bed Frame 150x190 cm with Upholstered Headboard - Instruction Manual

Model: EU-FPPPW3OC-12O

1. INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your Zinus Piper Bed Frame. The Piper upholstered bed frame combines modern style with comfort, featuring a padded headboard and a sturdy construction designed for durability and quiet use. Please read this manual thoroughly before beginning assembly to ensure proper setup and long-lasting enjoyment of your product.



Image 1.1: Front view of the Zinus Piper Bed Frame, showcasing the upholstered headboard and overall design.

2. SAFETY INFORMATION

Please observe the following safety precautions during assembly and use:

- Always assemble the bed frame on a soft, clean surface to prevent damage to the product or your floor.
- Ensure all bolts and screws are securely tightened before use. Periodically check and re-tighten as necessary.
- Keep small parts away from children during assembly to prevent choking hazards.
- **Caution:** Pay attention to sharp edges during handling and assembly to avoid injury.
- Do not exceed the maximum weight recommendation of 318 kg (699 lbs).

3. PACKAGE CONTENTS

Your Zinus Piper Bed Frame is delivered in a single compact box. Carefully unpack all components and verify that you

have received all parts listed below. If any parts are missing or damaged, please contact customer support.



Image 3.1: Overview of all components included in the package, ready for assembly.

Components Included:

- Headboard
- Side Rails (Upholstered)
- Footboard (Upholstered)
- Center Support Beam
- Wooden Slats
- Support Legs
- Hardware Pack (bolts, washers, nuts, Allen wrench, ratchet tool)
- Instruction Sheet

4. SETUP AND ASSEMBLY INSTRUCTIONS

Assembly of the Zinus Piper Bed Frame is designed to be straightforward and can typically be completed in under an hour with the help of a friend. All necessary tools are included. Follow these steps carefully:



Image 4.1: The included ratchet tool and numbered parts simplify the assembly process.

1. **Prepare the Area:** Clear a space on a soft, clean surface (like a carpet) to prevent scratching components or your floor.
2. **Identify Parts:** Lay out all components and hardware. Match them with the parts list and diagrams in the instruction sheet. Zinus products often feature numbered parts for easy identification.
3. **Assemble the Headboard and Footboard:** Attach the support legs to the headboard and footboard using the provided bolts and the ratchet tool. Do not overtighten initially.
4. **Connect Side Rails:** Attach the upholstered side rails to the headboard and footboard. Ensure the connection points align correctly. Use the provided bolts and tighten them securely.
5. **Install Center Support Beam:** Place the center support beam in the middle of the frame, connecting it to the headboard and footboard. Attach any additional support legs to this beam.

6. **Place Wooden Slats:** Unroll or place the wooden slats across the frame. Many Zinus slat systems come with Velcro or pre-drilled holes to secure them to the frame, preventing movement and noise.
7. **Final Tightening:** Once all components are in place, go back and securely tighten all bolts and screws using the ratchet tool. Ensure the frame is stable and level.



Image 4.2: Detail of the sturdy corner connections and slat support system.

5. OPERATING INSTRUCTIONS

The Zinus Piper Bed Frame is designed to provide a stable and comfortable foundation for your mattress.

- **Mattress Placement:** Carefully place your mattress (sold separately) onto the wooden slats. Ensure it is centered and sits evenly on the frame.
- **Weight Distribution:** Distribute weight evenly across the bed frame. Avoid concentrating heavy loads on a single point.
- **Clearance:** The bed frame offers 16.5 cm (6.5 inches) of under-bed clearance, suitable for robot vacuums or

Una scatola, tutto ciò che serve



Image 5.1: The bed frame provides 16.5 cm of clearance, ideal for robot vacuums or under-bed storage.

6. MAINTENANCE

Regular maintenance will help prolong the life and appearance of your bed frame.

- **Cleaning:** For the upholstered parts, gently spot clean with a damp cloth and mild detergent if necessary. Avoid harsh chemicals. For the metal frame and wooden slats, wipe with a dry or slightly damp cloth.
- **Tighten Connections:** Periodically (every 3-6 months) check all bolts and screws and re-tighten them to ensure the frame remains stable and silent.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight may cause fading of the upholstered fabric.
- **Ventilation:** Ensure adequate ventilation around your mattress to prevent moisture buildup.

7. TROUBLESHOOTING

If you encounter any issues with your Zinus Piper Bed Frame, refer to the following common solutions:

Problem	Possible Cause	Solution
Squeaking noises	Loose bolts or slats rubbing	Re-tighten all bolts. Ensure slats are properly seated and not rubbing against the frame.
Frame feels unstable	Incomplete tightening of hardware	Verify all connections are fully tightened. Ensure the frame is on a level surface.
Missing parts	Packaging error	Contact Zinus customer support immediately with your purchase details.

8. SPECIFICATIONS

Detailed specifications for the Zinus Piper Bed Frame (150x190 cm):

- **Model Number:** EU-FPPPW3OC-12O
- **Dimensions (Overall):** 190.5 cm (Length) x 150 cm (Width) x 106.6 cm (Height)
- **Product Weight:** 29.16 kg
- **Material:** Alloy Steel, Foam, Wood, Polyester
- **Color:** Off White
- **Style:** Contemporary
- **Special Feature:** Upholstered Headboard
- **Compatible Mattress Size:** 150 x 190 cm
- **Maximum Weight Recommendation:** 318 Kilograms (699 lbs)
- **Under-bed Clearance:** Approximately 16.5 cm



Image 8.1: Dimensional drawing of the Zinus Piper Bed Frame.

9. WARRANTY AND SUPPORT

Your Zinus Piper Bed Frame comes with a limited 5-year warranty, providing peace of mind regarding the quality and durability of your purchase.

- **Warranty Coverage:** The 5-year limited warranty covers manufacturing defects and material flaws under normal use. Please refer to the full warranty statement included with your product or on the Zinus website for complete terms and conditions.
- **Customer Support:** For any questions, missing parts, or warranty claims, please contact Zinus customer support. You can often find support contact information on the Zinus official website or through your retailer.
- **Online Resources:** Visit the official [Zinus Store on Amazon](#) for more product information and support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question