Lamshaw VPSTAY B1 / Anyloop B1 ALB1

Lamshaw 16mm Silicone Replacement Wristband User Manual

Compatible with VPSTAY B1 and Anyloop B1 ALB1 Fitness Trackers

1. Product Overview

This manual provides instructions for the Lamshaw 16mm Silicone Replacement Wristband, designed for compatibility with VPSTAY B1 and Anyloop B1 ALB1 fitness trackers. This wristband offers a comfortable and secure fit for daily wear and sports activities.

Key Features:

- **Material:** Crafted from premium soft silicone for a comfortable and elegant feel.
- **Fit Size:** Adjustable to fit wrists measuring 5.5"-7.8" (140mm-200mm), suitable for both men and women.
- **Breathability:** Features massive perforations to enhance breathability and ventilation, ensuring comfort during physical activity.
- **Durability:** Lightweight, sweat-resistant, and designed for long-lasting use.
- **Buckle:** Equipped with a magnetic folding buckle for easy and secure adjustment without traditional holes.



Image 1.1: The Lamshaw 16mm Silicone Replacement Wristband in black, shown attached to a compatible fitness tracker.



Image 1.2: Detail of the magnetic folding buckle, highlighting its convenient and stable design.

2. Setup

To set up your new Lamshaw replacement wristband, follow these steps:

1. **Attaching the Band to Your Tracker:** Ensure your fitness tracker is compatible with 16mm bands. Align the spring bars of the replacement band with the lug holes on your fitness tracker. Gently push the spring bar inwards and slide the band into place until the spring bar clicks securely into the lug hole. Repeat for the other side of the band.
2. **Adjusting the Band Length:** The wristband features a magnetic folding buckle for easy adjustment.




Image 2.1: Instructions for adjusting the band length. Open the button on the back of the strap, adjust to your wrist circumference, press the button, and the adjustment is complete.

- Open the button located on the back of the strap.
- Slide the buckle along the strap to adjust the length until it comfortably fits your wrist circumference.
- Once the desired length is achieved, press the button to secure the buckle in place. The magnetic closure will ensure a stable fit.



Image 2.2: Wrist circumference guide for optimal fit. The band accommodates wrists from 5.7 inches (145mm) to 8.25 inches (210mm).

3. Operating

Once the band is attached and adjusted, it is ready for use. The design ensures comfort and stability during various activities.

- **Wearing Comfort:** The soft silicone material and perforated design allow for continuous wear without discomfort, even during extended periods or intense workouts.
- **Secure Fit:** The magnetic folding buckle provides a secure and stable fit, preventing the tracker from slipping during movement.
- **Quick Drying:** The breathable design helps the band dry quickly after sweating, enhancing overall comfort and

hygiene.



Image 3.1: The wristband being worn comfortably by a user, demonstrating its suitability for everyday activities.

4. Maintenance

Proper care will extend the life and maintain the appearance of your silicone wristband.

- **Cleaning:** Regularly clean the band with a soft, damp cloth. For deeper cleaning, use mild soap and water. Rinse thoroughly and allow it to air dry completely before reattaching to your tracker.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, solvents, or harsh chemicals, as these can damage the silicone material.
- **Storage:** When not in use, store the band in a clean, dry place away from direct sunlight and extreme temperatures.

5. Troubleshooting

If you encounter any issues with your wristband, consider the following:

- **Band Feels Too Loose or Too Tight:** Re-adjust the magnetic folding buckle as described in the 'Setup' section (Section 2) to achieve a comfortable and secure fit. Refer to the wrist circumference guide (Image 2.2).
- **Difficulty Attaching to Tracker:** Ensure the spring bars are correctly aligned with the lug holes on your fitness tracker. Apply gentle pressure and ensure the spring bar clicks into place. Do not force the band.

- **Skin Irritation:** If you experience skin irritation, ensure the band is clean and dry. Avoid wearing it too tightly. If irritation persists, discontinue use and consult a healthcare professional.

6. Specifications

Department	Unisex-Adult
Compatible Tracker Models	VPSTAY B1, Anyloop B1 ALB1 (1.47 Inches Fitness Tracker)
Band Width	16mm
Material	Soft Silicone
Clasp Type	Magnetic Folding Buckle
Metal Type	No Metal Type (referring to the band material itself, buckle is metal)
Gem Type	No gemstone
Adjustable Wrist Size	5.5"-7.8" (140mm-200mm)

7. Warranty and Support

Your Lamshaw 16mm Silicone Replacement Wristband comes with a commitment to quality.

- **Warranty:** For 30 days after the date of purchase, we address all quality-related issues with a replacement or refund.
- **Defective Items:** Please contact us immediately if you receive a defective item.
- **Customer Support:** For any questions, concerns, or support needs, please contact the seller directly through your purchase platform.

© 2024 Lamshaw. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question