



[Manuals.plus](#) /

> [Haier](#) /

> Haier H32K80E 32-Inch HD Smart Google TV User Manual

Haier H32K80E

Haier H32K80E 32-Inch HD Smart Google TV User Manual

Model: H32K80E

1. INTRODUCTION

This manual provides essential information for the safe and efficient operation of your Haier H32K80E 32-inch HD Smart Google TV. Please read it thoroughly before using the television and retain it for future reference.

Your new Haier Smart Google TV features a 32-inch HD display, integrated Google TV operating system, Dolby Audio for enhanced sound, HDR10 support for improved contrast, built-in Chromecast for content streaming, and voice control capabilities. The Bezel-Less design offers an immersive viewing experience.



Front view of the Haier H32K80E 32-inch HD Smart Google TV.

2. SAFETY INFORMATION

To ensure safe operation and prevent damage, observe the following precautions:

- **Placement:** Position the TV on a stable, level surface. Ensure adequate ventilation around the TV; do not block ventilation openings. Avoid placing the TV in direct sunlight or near heat sources.
- **Power:** Use only the specified power supply. Ensure the power cord is not pinched or walked on. Unplug the TV during lightning storms or when unused for long periods.
- **Water and Moisture:** Do not expose the TV to rain or moisture. Do not place objects filled with liquids, such as vases, on the TV.
- **Cleaning:** Disconnect the power cord before cleaning. Use a soft, dry cloth to clean the screen and cabinet. Do not use liquid cleaners or aerosol sprays.
- **Servicing:** Do not attempt to service this product yourself. Refer all servicing to qualified service personnel.

3. PACKAGE CONTENTS

Verify that all items listed below are included in your package:

- Haier H32K80E 32-Inch HD Smart Google TV
- Remote Control
- Batteries (for remote control)
- User Manual (this document)
- Quick Start Guide
- TV Stand Components
- Power Cord

Haier

More Creation, More Possibilities

HD Smart LED TV 32" K80E



Dimension with stand (width x depth x height)

720.8*179.4*468mm

Dimension without stand (width x depth x height)

720.8*85.6*434.4mm

Weight: 5.2 kg

What's in the Box:

- Remote
- Battery
- User Manual
- Quick Start Page
- TV Stand

Illustration of TV dimensions and included accessories.

4. SETUP

4.1. Attaching the TV Stand

1. Carefully place the TV screen-down on a soft, clean surface to prevent scratches.
2. Align the stand components with the screw holes on the bottom of the TV.
3. Secure the stand using the provided screws. Do not overtighten.
4. Place the TV upright on a stable surface.

4.2. Connecting Devices

Your Haier H32K80E TV offers various connectivity options:

- **HDMI:** Connect external devices such as Blu-ray players, game consoles, or set-top boxes using HDMI cables. The TV supports HDMI 2.1.
- **Antenna/Cable:** Connect an antenna or cable TV source to the RF input.
- **USB:** Insert USB drives for media playback.

- **Ethernet:** For a wired internet connection, connect an Ethernet cable to the LAN port.



Rear view illustrating available connection ports.

4.3. Initial Power-On and Setup

1. Connect the power cord to the TV and then to a power outlet.
2. Press the power button on the TV or remote control to turn it on.
3. Follow the on-screen instructions to select your language, connect to a Wi-Fi network, and sign in with your Google account. A Google account is required to access Google TV features and download apps.

5. OPERATING INSTRUCTIONS

5.1. Remote Control Overview

The remote control allows you to navigate the Google TV interface, adjust settings, and use voice commands.

Haier

More Creation, More Possibilities

HD Smart LED TV 32" K80E



Dimension with stand (width x depth x height)

720.8*179.4*468mm

Dimension without stand (width x depth x height)

720.8*85.6*434.4mm

Weight: 5.2 kg

What's in the Box:


- Remote
- Battery
- User Manual
- Quick Start Page
- TV Stand

Remote control with voice command and quick access buttons.

- **Power Button:** Turns the TV on or off.
- **Google Assistant Button:** Activates voice control.
- **Navigation Pad (Up/Down/Left/Right/OK):** Navigates menus and selects items.
- **Back Button:** Returns to the previous screen.
- **Home Button:** Returns to the Google TV home screen.
- **Volume Up/Down:** Adjusts the volume.
- **Channel Up/Down:** Changes TV channels.
- **Quick Access Buttons:** Dedicated buttons for popular streaming services like YouTube, Netflix, and Prime Video.

5.2. Google TV Interface

Google TV organizes movies, shows, live TV, and more from your apps and subscriptions into one place. It also provides personalized recommendations.



The Google TV home screen with content recommendations.

- **Home Screen:** Access recommended content, installed apps, and settings.
- **Apps:** Download and manage applications from the Google Play Store.
- **Library:** Find your purchased or rented content.
- **Search:** Use the search function to find specific titles or genres.

5.3. Voice Control (Google Assistant)

Press the Google Assistant button on your remote and speak into the microphone to control your TV, search for content, get information, or control smart home devices.

5.4. Chromecast Built-in

Easily cast movies, shows, photos, and more from your phone, tablet, or laptop directly to your TV. Ensure your device and TV are connected to the same Wi-Fi network.



Casting content from various devices to the TV using Chromecast built-in.

5.5. Bluetooth Connectivity

Connect Bluetooth-enabled devices such as headphones, soundbars, or game controllers to your TV for enhanced audio or control.

- Go to **Settings > Remotes & Accessories > Pair accessory**.
- Put your Bluetooth device into pairing mode.
- Select your device from the list on the TV screen to pair.

Haier

More Creation, More Possibilities

HD Smart LED TV 32" K80E



Dimension with stand (width x depth x height)

720.8*179.4*468mm

Dimension without stand (width x depth x height)

720.8*85.6*434.4mm

Weight: 5.2 kg

What's in the Box:

- Remote
- Battery
- User Manual
- Quick Start Page
- TV Stand

Bluetooth connectivity for devices like game controllers.

6. MAINTENANCE

6.1. Cleaning the TV

- Always unplug the TV before cleaning.
- Use a soft, lint-free cloth to gently wipe the screen. For stubborn marks, slightly dampen the cloth with water or a specialized screen cleaner (apply to cloth, not directly to screen).
- Wipe the TV cabinet with a soft, dry cloth. Avoid abrasive cleaners or solvents.

6.2. Software Updates

Your Google TV may receive automatic software updates. Ensure your TV is connected to the internet to receive the latest features and security patches. You can also manually check for updates in the Settings menu.

7. TROUBLESHOOTING

If you encounter issues with your TV, refer to the following common problems and solutions:

| Problem | Possible Solution |
|----------------------------------|---|
| No power | Check if the power cord is securely connected to the TV and the power outlet. Try a different outlet. |
| No picture, but sound is present | Ensure the correct input source is selected. Check HDMI or other video cable connections. |
| No sound, but picture is present | Check the volume level and mute status. Ensure external audio devices are properly connected and powered on. |
| Remote control not working | Replace the batteries. Ensure there are no obstructions between the remote and the TV. Re-pair the remote if it's a Bluetooth remote. |
| Cannot connect to Wi-Fi | Check your router and modem. Ensure the Wi-Fi password is correct. Try restarting the TV and your router. |
| Apps are slow or freezing | Close unused apps. Clear app cache in Settings. Restart the TV. Ensure sufficient internet speed. |

If the problem persists after trying these solutions, please contact Haier customer support.

8. SPECIFICATIONS

Key technical specifications for the Haier H32K80E 32-inch HD Smart Google TV:

| Feature | Specification |
|------------------------------------|--|
| Model Number | H32K80E |
| Screen Size | 32 Inches (82 cm visible diagonal) |
| Resolution | HD (720p) |
| Display Technology | LCD |
| Operating System | Google TV |
| Audio Technology | Dolby Audio, dbx-TV certified |
| Special Features | HDR10, Chromecast built-in, Voice Control, Bezel-Less Design |
| Connectivity Technology | Bluetooth, Wi-Fi, HDMI 2.1 |
| Product Dimensions (with stand) | 720.8 x 179.4 x 468 mm (W x D x H) |
| Product Dimensions (without stand) | 720.8 x 85.6 x 434.4 mm (W x D x H) |
| Item Weight | 3.9 kg |

9. WARRANTY AND SUPPORT

Your Haier H32K80E TV comes with a **2-year warranty**, covering manufacturing defects under normal use. Please retain your proof of purchase for warranty claims.

For technical assistance, troubleshooting beyond this manual, or warranty service, please contact Haier customer support through their official channels. Refer to the Quick Start Guide or Haier's official website for contact information specific to your region.