

Best Choice Products SKY7702

Best Choice Products Kids 3-in-1 Picnic, Sand & Water Table with Umbrella

Model: SKY7702

Brand: Best Choice Products

[Overview](#) [Assembly](#) [Safety Information](#) [Product](#)
[Operation](#) [Maintenance](#) [Specifications](#) [Warranty & Support](#)

1. SAFETY INFORMATION

Please read and understand all instructions before assembly and use of this product. Keep this manual for future reference.

- **Age Recommendation:** Not for children under 3 years old.
- **Weight Capacity:** The table and benches are designed to support a maximum weight of 220 lbs. Ensure this limit is not exceeded.
- **Supervision:** Always supervise children when they are using the picnic table, especially during sand and water play.
- **Placement:** Place the table on a flat, stable surface to prevent tipping. Avoid placing near hazards such as pools (unless supervised), steep drops, or sharp objects.
- **Umbrella Use:** Ensure the umbrella is securely installed and adjusted. Remove the umbrella during strong winds to prevent damage or injury.
- **Material Safety:** Crafted with treated, BPA-free natural wood, meeting U.S. Federal Safety Standards (ASTM F963-17 and CPSIA).
- **Choking Hazard:** Small parts may be present during assembly. Keep away from young children.

2. PRODUCT OVERVIEW

The Best Choice Products Kids 3-in-1 Picnic, Sand & Water Table is a versatile outdoor activity center designed for toddlers. It seamlessly transitions between a traditional picnic table, a sand table, and a water table, providing multiple play options.

Key Features:

- **3-in-1 Design:** Easily convert from a picnic table to a sand or water table by removing the central tabletop panels. Two plastic activity bins are included.
- **Adjustable Umbrella:** A height-adjustable umbrella provides shade, adapting as your child grows.
- **Durable Construction:** Made from 100% hemlock wood for lasting outdoor use.
- **Seating Capacity:** Comfortably seats up to 4 children.
- **Certified Safe:** Designed with treated, BPA-free natural wood, adhering to federal safety standards (ASTM F963-17 and CPSIA).



Image: The Best Choice Products Kids 3-in-1 Picnic Table in Walnut/Red with its umbrella extended.

3. ASSEMBLY INSTRUCTIONS

Assembly is required for this product. Please follow the included assembly guide carefully. It is recommended to have a hammer and wrench available for assembly.

For a visual guide on assembly, please refer to the official product video below:

Your browser does not support the video tag.

Video: Official Best Choice Products video demonstrating the assembly and features of the Kids Outdoor Convertible Wood Picnic Table.

Assembly Tips:

- Lay out all components and hardware before beginning.
- Follow the step-by-step diagrams in the included Assembly Guide.
- Do not overtighten screws during initial assembly; tighten fully once all parts are aligned.

4. OPERATING INSTRUCTIONS

4.1 Converting to Sand or Water Table:

1. Locate the central wooden tabletop panels.
2. Carefully lift and remove these panels. They are designed for easy removal.
3. Beneath the panels, you will find two plastic activity bins.
4. Fill the bins with play-grade sand (sold separately) or water for sensory play.
5. To convert back to a picnic table, ensure bins are empty and clean, then place the wooden panels back into position.

3-in-1 Design

Remove the table top to switch between a picnic set, a sand table, or a water table!



Image: The table with the central wooden panels removed, revealing two activity bins for sand or water play.

4.2 Adjusting the Umbrella:

The included umbrella can be adjusted in height to provide optimal shade as needed.

1. Locate the hook and latch system on the umbrella pole.
2. Press the release button or lift the latch to unlock the pole.
3. Slide the umbrella pole up or down to the desired height.
4. Release the button/latch to secure the umbrella in place.

Adjustable Umbrella

Freely raise and lower the umbrella for maximum coverage throughout the day



Image: Diagram illustrating the adjustable umbrella feature with the hook and latch system.

5. MAINTENANCE

- **Cleaning:** Wipe down the wooden surfaces with a damp cloth and mild soap as needed. Ensure all surfaces are dry after cleaning. The plastic bins can be removed and washed with soap and water.
- **Wood Care:** As the table is made of natural wood, consider applying a wood sealant or stain periodically to protect it from weather elements and prolong its lifespan, especially with frequent water use.
- **Storage:** During periods of non-use or inclement weather, it is recommended to cover the table or store it indoors to protect the wood and umbrella.
- **Inspection:** Regularly check all screws and connections to ensure they are tight. Tighten if necessary. Inspect the wood for any splinters or damage and address them promptly.

6. PRODUCT SPECIFICATIONS

Feature	Detail
Brand	Best Choice Products
Model Name	3-in-1 Kids Sand & Water Table Outdoor Wood Picnic Table w/ Umbrella
Model Number	SKY7702
Color	Walnut/Red
Frame Material	Wood (Hemlock)
Item Weight	34 Pounds
Maximum Weight Recommendation	220 Pounds
Item Dimensions (L x W x H)	38"L x 37.75"W x 19.5"H
Seating Capacity	4 Children
Indoor/Outdoor Usage	Outdoor
Required Assembly	Yes
Tools Recommended For Assembly	Hammer, Wrench
Included Components	Assembly Guide
UPC	842957142613

PRODUCT DIMENSIONS




Image: Detailed diagram showing the dimensions of the picnic table and umbrella.

7. WARRANTY & SUPPORT

Manufacturer Warranty: Best Choice Products offers a 60-day warranty. All returns are shipped back to a Best Choice Products return center at the customer's expense within 60 days of delivery. However, a pre-paid return shipping label will be sent via email if the return is a result of our error. Please note that it is at the company's discretion to decide if the item may be returned to a Best Choice Products return center. Unauthorized returns may not be accepted. Once your claim is processed and approved, please allow 5-7 business days for the request to be completed. If a replacement unit or replacement parts are requested, please be aware that the fulfillment time-frame is based on product availability.

For further assistance or to initiate a warranty claim, please contact Best Choice Products customer support directly.

