

[Manuals.plus](#) /

› [GIOTOHUN](#) /

› GIOTOHUN H1 Cat Water Fountain Filters Instruction Manual

GIOTOHUN H1-new

GIOTOHUN H1 Cat Water Fountain Filters Instruction Manual

Model: H1-new

INTRODUCTION

Thank you for choosing GIOTOHUN H1 Cat Water Fountain Filters. This manual provides essential information for the proper installation, use, and maintenance of your replacement filters and sponges. Following these instructions will help ensure your pet receives clean, fresh drinking water, contributing to their overall health and well-being.

PRODUCT OVERVIEW

This product includes 6 replacement filters and 6 replacement sponges, designed for the GIOTOHUN 2L (67oz) Cat Water Fountain (Model H1). Each filter is individually packaged to maintain its integrity and effectiveness.

Compatible GIOYOHUN Cat Fountain



Image: Compatible Pet Fountains. This image displays several models of pet water fountains that are compatible with these replacement filters and sponges.

Filtration System

The filters feature a 4-layer filtration system designed to purify water and remove impurities:

- **High-density microporous filter:** Removes fine impurities and loose pet hairs.
- **Large diameter coconut shell activated carbon:** Eliminates residual odors and improves water taste.
- **Cationic resin:** Replaces heavy metal ions that can contribute to stone formation in pets.
- **Sponge filter:** Traps dust and airborne particles, enhancing overall water cleanliness.

Multiple Filtration System

Keep the water clean and fresh




Image: Multiple Filtration System diagram. This diagram shows the four layers of filtration: high-quality cotton, coconut shell activated carbon, and a sponge layer, working together to keep water clean and fresh.



High Density Cotton Layer

Out Hair, Sediment
and Debris to Clean Water

Activated Carbon

Purify and Freshen Drinking

Image: Filter components. This image highlights the high-density cotton layer for removing hair, sediment, and debris, and the activated carbon for purifying and freshening drinking water.



Image: Filter and sponge dimensions. This image displays the measurements of both the oval-shaped filter (2.95 inches by 1.64 inches) and the circular sponge (3.07 inches diameter, 1 inch height, 0.39 inch thickness).

SETUP AND INSTALLATION

1. **Rinse Filter:** Before first use, rinse the new filter thoroughly under running water for 3-5 minutes to remove any carbon dust.
2. **Soak Filter:** After rinsing, soak the filter in water for 5 minutes. This helps to ensure optimal filtration.

3. **Install Filter:** Insert the filter into the designated slot in the fountain's lid, ensuring the flat side is facing upwards.
4. **Install Sponge:** Fit the sponge filter around the pump unit.

Please Rinse before Use




**After washing,
please soak for 5 minutes**




Image: Pre-use preparation. This image demonstrates the two crucial steps before using a new filter: rinsing it under running water and then soaking it for 5 minutes.

Filter Installation Method




1

Filter Installation Method



2

Insert the filter flat side up into the lid



3

Fit the sponge filter to the pump.

Image: Filter Installation Method. This diagram illustrates the three steps: 1) Filter installation method, 2) Inserting the filter flat side up into the lid, and 3) Fitting the sponge filter to the pump.

MAINTENANCE

Regular maintenance of the filters and fountain is crucial for your pet's health and the longevity of the product.

- **Filter Replacement:** It is recommended to replace the carbon filter every 2 weeks for optimal filtration.

- **Sponge Replacement:** It is recommended to replace the sponge filter every 1-2 months.
- **Water Change and Cleaning:** Change the water source and clean the fountain thoroughly every 3 days to prevent buildup and maintain hygiene.

Note: The filter material is certified safe, ensuring the safety of your pet's drinking water.

TROUBLESHOOTING

If you encounter issues with water quality or flow, consider the following:

- **Reduced Water Flow:** Check if the filter or sponge is clogged with hair or debris. Replace if necessary.
- **Unpleasant Odor/Taste:** Ensure the carbon filter is replaced regularly as recommended (every 2 weeks).
- **Cloudy Water:** This may indicate the filter needs replacement or the fountain requires a thorough cleaning.
- **Pump Issues:** Ensure the sponge filter around the pump is clean and not obstructing its operation. Clean the pump regularly as per your fountain's specific instructions.

SPECIFICATIONS

Feature	Detail
Product Type	Cat Water Fountain Filters and Sponges
Compatibility	GIOTOHUN Cat Water Fountain H1 (2L / 67oz capacity)
Package Contents	6 Filters, 6 Sponges
Filtration Layers	4 (High-density microporous, Activated Carbon, Cationic Resin, Sponge)
Filter Material	Activated carbon, High-quality cotton, Cationic resin
Recommended Filter Replacement	Every 2 weeks
Recommended Sponge Replacement	Every 1-2 months
Item Model Number	H1-new
Manufacturer	GIOTOHUN
Item Weight	1.41 ounces (total package)
Package Dimensions	3.94 x 3.9 x 3.23 inches

WARRANTY AND SUPPORT

For any questions regarding the GIOTOHUN H1 Cat Water Fountain Filters or for support, please refer to the contact information provided with your GIOTOHUN Cat Water Fountain or visit the official GIOTOHUN website. Ensure you have your product model number (H1-new) available when seeking support.

Note: This product is a consumable item. Warranty terms typically apply to the fountain unit itself, not to replacement filters and sponges, which are expected to be replaced regularly.

