

Generico 1121114601

Burner for Invicta and Bion Heating Stoves

INSTRUCTION MANUAL

Model: 1121114601 | Compatible with Invicta Serino 7, Adrano 7, Landa; Bion Heating Preziosa 7

1. Introduction

This manual provides essential information for the safe and correct installation, operation, and maintenance of the Generico 1121114601 cast iron burner. This burner is designed as a replacement part for specific stove models, including Invicta Serino 7, Invicta Adrano 7, Invicta Landa, and Bion Heating Preziosa 7. Please read this manual thoroughly before proceeding with any installation or maintenance.

2. Safety Information

WARNING: Improper installation, adjustment, alteration, service, or maintenance can cause injury or property damage. Refer to this manual. For assistance or additional information, consult a qualified installer, service agency, or the gas supplier.

- Always disconnect power to the stove before attempting any installation or maintenance.
- Allow the stove and burner to cool completely before handling.
- Wear appropriate personal protective equipment (e.g., gloves, eye protection).
- Ensure proper ventilation during operation.
- Keep flammable materials away from the stove.
- If you are unsure about any step, consult a qualified technician.

3. Product Overview

The Generico 1121114601 burner is a robust cast iron component designed for efficient combustion in compatible pellet or wood-burning stoves. Its perforated design ensures optimal airflow for burning fuel.



Figure 1: Generico 1121114601 Cast Iron Burner. This image shows the burner from an angled perspective, highlighting its rectangular base and the perforated combustion chamber. The material appears to be dark grey cast iron.

4. Specifications

Feature	Detail
Model Number	1121114601
Material	Cast Iron
Total Width	14 cm (5.5 inches)
Total Depth	10.5 cm (4.1 inches)
Cup Width	11 cm (4.3 inches)

Feature	Detail
Cup Depth	7.2 cm (2.8 inches)
Compatible Stoves	Invicta Serino 7, Invicta Adrano 7, Invicta Landa, Bion Heating Preziosa 7

5. Setup and Installation

This burner is a replacement part. Installation typically involves removing the old burner and inserting the new one. Always refer to your stove's specific instruction manual for detailed removal and installation procedures. If you are not comfortable performing this task, seek assistance from a qualified technician.

- Preparation:** Ensure the stove is completely cool and disconnected from any power source. Clear the combustion chamber of any ash or debris.
- Remove Old Burner:** Carefully locate and remove the existing burner from the combustion chamber. Note its orientation for correct installation of the new part.
- Inspect:** Before installing the new burner, inspect it for any manufacturing defects or damage.
- Install New Burner:** Place the new Generico 1121114601 burner into the combustion chamber, ensuring it sits correctly and securely in its designated position. The burner should fit snugly without excessive force.
- Final Check:** Verify that the burner is properly seated and that there are no obstructions.

6. Operating Instructions

Once the new burner is installed, operate your stove according to its original manufacturer's instructions. The burner's function is to hold the fuel (pellets or wood) and facilitate proper combustion by allowing airflow. Ensure that the stove's air intakes are clear and that the fuel used is appropriate for your stove model.

- Always use the recommended fuel type for your stove.
- Do not overfill the combustion chamber.
- Monitor the flame and adjust air settings as per your stove's manual for optimal burning efficiency.

7. Maintenance

Regular maintenance of the burner is crucial for efficient and safe stove operation. Always ensure the stove is cool and disconnected from power before performing maintenance.

- **Daily/Weekly Cleaning:** Remove ash and unburnt fuel from the burner and combustion chamber. Ensure the perforations in the burner are clear of any blockages. A wire brush or vacuum cleaner can be used.
- **Periodic Inspection:** Inspect the burner for signs of wear, cracks, or deformation. Cast iron can degrade over time, especially with high heat cycles. Replace the burner if significant damage is observed.
- **Chimney Cleaning:** Ensure your chimney and flue pipes are regularly cleaned by a qualified professional to prevent creosote buildup, which can affect stove performance and safety.

8. Troubleshooting

If you experience issues with your stove after installing the new burner, consider the following common problems:

- **Poor Combustion/Low Heat:**
 - Check if the burner perforations are clogged with ash or debris. Clean thoroughly.

- Ensure the stove's air intakes are open and clear.
- Verify that the fuel quality is appropriate and dry.
- Consult your stove's manual for proper air settings.

- **Excessive Smoke:**

- This often indicates incomplete combustion. Check for blockages in the burner or flue.
- Ensure adequate draft in the chimney.
- Use dry, appropriate fuel.

- **Burner Damage/Wear:**

- Cast iron can crack or warp over time due to extreme heat. If the burner is visibly damaged, it should be replaced to maintain efficiency and safety.

For persistent issues, contact a qualified stove technician or the seller for further assistance.

9. Warranty and Support

Specific warranty information for this Generico replacement part may vary. Please refer to the purchase documentation or contact the seller directly for details regarding warranty coverage and support. Keep your proof of purchase for any warranty claims.

For technical support or inquiries, please reach out to the retailer or manufacturer through the contact information provided at the time of purchase.

© 2024 Generico. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question