

XDOBO Kung Fu

XDOBO Kungfu 160W Portable Bluetooth Speaker User Manual

MODEL: KUNG FU

Brand: XDOBO

Introduction

Thank you for choosing the XDOBO Kungfu 160W Portable Bluetooth Speaker. This manual provides essential information for setting up, operating, and maintaining your speaker to ensure optimal performance and longevity. Please read this manual thoroughly before using the product and retain it for future reference.

Important Safety Instructions

- Do not expose the speaker to extreme temperatures, humidity, or direct sunlight.
- Avoid dropping or subjecting the speaker to strong impacts.
- Do not disassemble, repair, or modify the speaker yourself. Refer all servicing to qualified personnel.
- Keep the speaker away from water and liquids, despite its water-resistant design, to prevent damage.
- Use only the specified charging cable and power adapter.
- Clean the speaker with a soft, dry cloth. Do not use abrasive cleaners or solvents.

Package Contents

Please check that all items are present in your package:

- 1 x XDOBO Kungfu Speaker
- 1 x Charging Cable
- 1 x User Manual (this document)

Product Overview

Familiarize yourself with the various parts and controls of your XDOBO Kungfu speaker.



Figure 1: Front view of the XDOBO Kungfu speaker, highlighting its robust design and central logo.



Figure 2: Angled view of the speaker, illustrating its dynamic sound capabilities with abstract sound wave graphics.

PRODUCT MATERIAL

Delicate blending Transforming stillness into movement

|

Modular structural design,
unlocking new listening states, solid material selection,
meticulous processes, countless product iterations,
ultimately bringing a soft tactile experience



Figure 3: Detailed view showcasing the speaker's durable plastic material and ergonomic handle for easy portability.



Figure 4: An internal diagram revealing the dual speaker drivers and side-mounted passive radiators responsible for the powerful audio output.

Control Panel (Top View)

The control buttons are located on the top surface of the speaker:

- **Power Button:** Press and hold to turn on/off.
- **Bluetooth Button:** Press to enter pairing mode.
- **Volume Down (-):** Press to decrease volume.
- **Play/Pause Button:** Press to play or pause audio.
- **Volume Up (+):** Press to increase volume.
- **Mode Button:** Press to switch between input modes (e.g., Bluetooth, AUX).

Setup Guide

1. Charging the Speaker

Before first use, fully charge the speaker. Connect the charging cable to the speaker's charging port and the other end to a compatible USB power adapter (not included) or a computer's USB port. The charging indicator light will show the charging status and turn off when fully charged.

2. Powering On/Off

- To power on: Press and hold the **Power Button** for approximately 3 seconds until you hear an audible prompt.
- To power off: Press and hold the **Power Button** for approximately 3 seconds until you hear an audible prompt.

3. Bluetooth Pairing

1. Ensure the speaker is powered on and in Bluetooth pairing mode (indicated by a flashing blue LED). If not, press the **Bluetooth Button**.
2. Enable Bluetooth on your device (smartphone, tablet, etc.).
3. Search for "XDOBO Kungfu" in your device's Bluetooth settings.
4. Select "XDOBO Kungfu" to connect. Once connected, the LED indicator will turn solid blue, and you will hear a confirmation sound.

4. TWS (True Wireless Stereo) Pairing

The XDOBO Kungfu speaker supports TWS functionality, allowing you to pair two speakers for an immersive stereo sound experience.

1. Ensure both XDOBO Kungfu speakers are powered on and not connected to any other Bluetooth devices.
2. On one of the speakers (this will be the primary speaker), press and hold the **Bluetooth Button** for a few seconds until you hear a TWS pairing prompt.
3. The two speakers will automatically search for and connect to each other. Once connected, you will hear a confirmation sound, and the LED indicators on both speakers will show a synchronized status.
4. Now, connect your device to the primary speaker via Bluetooth as described in step 3. Audio will play in stereo through both speakers.

Operating Instructions

Basic Audio Playback

- **Play/Pause:** Press the **Play/Pause Button** once.
- **Volume Up:** Press the **Volume Up (+) Button**.
- **Volume Down:** Press the **Volume Down (-) Button**.
- **Next Track:** Press and hold the **Volume Up (+) Button**.
- **Previous Track:** Press and hold the **Volume Down (-) Button**.

Call Functions (if applicable)

- **Answer/End Call:** Press the **Play/Pause Button** once during an incoming call or an active call.
- **Reject Call:** Press and hold the **Play/Pause Button** for 2 seconds during an incoming call.

Switching Input Modes

Press the **Mode Button** to cycle through available input modes, such as Bluetooth and AUX (if an AUX port is present and connected).

Maintenance

Cleaning

Wipe the speaker's surface with a soft, dry, lint-free cloth. Do not use liquid cleaners, aerosols, or solvents, as they may damage the finish or internal components.

Storage

When not in use for extended periods, store the speaker in a cool, dry place, away from direct sunlight and extreme temperatures. It is recommended to charge the battery at least once every three months to maintain its lifespan.

Battery Care

To prolong battery life, avoid fully discharging the speaker frequently. Charge the speaker when the low battery indicator appears. Do not leave the speaker connected to power for excessively long periods after it is fully charged.

Troubleshooting

Problem	Possible Cause	Solution
Speaker does not turn on.	Low battery.	Charge the speaker fully.
Cannot pair with Bluetooth device.	Speaker not in pairing mode; device Bluetooth off; too far from speaker.	Ensure speaker is in pairing mode. Turn Bluetooth on/off on device. Move device closer to speaker.
No sound or low volume.	Volume too low on speaker or device; incorrect input mode.	Increase volume on both speaker and device. Check input mode.
TWS pairing failed.	Speakers too far apart; one speaker already connected to another device.	Ensure speakers are close. Disconnect any existing Bluetooth connections before TWS pairing.

Specifications

Feature	Detail
Brand	XDOBO
Model Name	Kung Fu
Speaker Type	Outdoor, Portable Bluetooth Speaker
Connectivity Technology	Bluetooth
Maximum Speaker Output Power	160 Watts
Frequency Response	20 KHz
Audio Output Mode	Stereo
Power Source	Battery
Material	Plastic
Dimensions (L x W x H)	29cm x 29cm x 13cm (approx.)

Feature	Detail
Water Resistance	Water Resistant
Special Features	Bluetooth, TWS Interconnection, High Power Output, Long Battery Life, Dual Diaphragm Design

Warranty and Support

Limited Warranty

The XDOBO Kungfu 160W Portable Bluetooth Speaker comes with a limited warranty. Please refer to the warranty card included in your package or contact XDOBO customer support for detailed terms and conditions.

Customer Support

For any questions, technical assistance, or warranty claims, please contact XDOBO customer support through their official website or the contact information provided with your purchase. Please have your product model and purchase details ready when contacting support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0D5RPHG4L>

More documents and user manuals: <https://manuals.plus/>