

**Altec Lansing IMW1012-BLKLGRY-STK-2**

# **Altec Lansing HYDRATREK Magnetic Bluetooth Speaker User Manual**

Model: IMW1012-BLKLGRY-STK-2

## **1. INTRODUCTION**

Thank you for choosing the Altec Lansing HYDRATREK Magnetic Bluetooth Speaker. This portable, rugged speaker is designed to provide high-quality audio for all your adventures, featuring a durable, waterproof design and versatile mounting options. Please read this manual carefully to ensure proper use and maintenance of your speaker.



Image: The Altec Lansing HYDRATREK speaker in black, showcasing its compact design and integrated carabiner clip.



Image: Key features of the HYDRATREK speaker, including stereo pairing, up to 6 hours playtime, IP67 waterproof rating, ability to float, included carabiner clip, and strong magnet.

## 2. PACKAGE CONTENTS

Please ensure all items are present in your package:

- Altec Lansing HYDRATREK Magnetic Bluetooth Speaker
- Speaker Mount
- Carabiner Clip (pre-attached or included separately)
- USB-C Charging Cable
- Quick Start Guide



Image: The HYDRATREK speaker shown with its mountable carabiner clip and the included mount accessory.

### 3. CONTROLS AND FUNCTIONS

Familiarize yourself with the speaker's controls:



Image: Close-up of the speaker's top panel, indicating the Volume Down, Power (On/Off), and Volume Up buttons.

- **Power Button (Circle with line):** Press and hold to power on/off. Short press to play/pause audio or answer/end calls.
- **Volume Down Button (-):** Short press to decrease volume. Press and hold to skip to the previous track.
- **Volume Up Button (+):** Short press to increase volume. Press and hold to skip to the next track.
- **Microphone:** For hands-free calling and voice assistant activation.
- **USB-C Charging Port:** Located under a protective flap, used for charging the speaker.

## 4. GETTING STARTED

### 4.1. Charging the Speaker

Before first use, fully charge your HYDRATREK speaker. The charging time is approximately 3 hours.

1. Open the protective flap covering the USB-C charging port.
2. Connect the provided USB-C cable to the speaker's charging port.



3. Connect the other end of the USB-C cable to a USB power adapter (not included) or a computer's USB port.
4. The charging indicator light will illuminate during charging and turn off when fully charged.

## 4.2. Powering On/Off

- **To Power On:** Press and hold the Power button for 2-3 seconds until you hear an audible tone.
- **To Power Off:** Press and hold the Power button for 2-3 seconds until you hear an audible tone.

## 4.3. Bluetooth Pairing

Pair your speaker with a Bluetooth-enabled device:

1. Ensure the speaker is powered on and in pairing mode (indicated by a flashing LED).
2. On your device (smartphone, tablet, etc.), enable Bluetooth and search for available devices.
3. Select "HYDRATREK" from the list of devices.
4. Once paired, the LED indicator will turn solid, and you will hear a confirmation tone.

## 4.4. True Wireless Pairing (TWS)

Connect two HYDRATREK speakers for an immersive stereo sound experience:




Image: Visual representation of pairing two HYDRATREK speakers for enhanced stereo sound.

1. Ensure both HYDRATREK speakers are powered on and not connected to any other Bluetooth device.
2. On one speaker (this will be the primary speaker), double-press the Power button. It will enter TWS pairing mode.
3. The primary speaker will automatically search for and connect to the second speaker.
4. Once connected, you will hear a confirmation tone, and the LED indicators on both speakers will change.
5. Now, connect your device to the primary speaker via Bluetooth as described in section 4.3.

## 5. OPERATING INSTRUCTIONS

### 5.1. Playing Audio

- **Play/Pause:** Short press the Power button.
- **Volume Up:** Short press the '+' button.
- **Volume Down:** Short press the '-' button.
- **Next Track:** Press and hold the '+' button.
- **Previous Track:** Press and hold the '-' button.

## 5.2. Call Management

- **Answer/End Call:** Short press the Power button.
- **Reject Call:** Press and hold the Power button.

## 5.3. Voice Assistant

Activate your device's voice assistant (Siri, Google Assistant, etc.) by double-pressing the Power button.

## 5.4. Mounting Options

The HYDRATREK speaker offers multiple ways to secure it:

- **Magnetic Mounting:** The built-in strong magnet allows you to attach the speaker to any metal surface.
- **Carabiner Clip:** Use the integrated carabiner clip to attach the speaker to backpacks, belt loops, or other gear.
- **Included Mount:** Utilize the provided mount to attach the speaker to handlebars, poles, or other compatible surfaces.



Image: The speaker demonstrating its strong magnetic attachment to a metal surface.



Image: The speaker attached to a bicycle handlebar using the included mount, ready for outdoor use.

## 6. CARE AND MAINTENANCE

To ensure the longevity of your HYDRATREK speaker:

- **Cleaning:** Wipe the speaker with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners.
- **Waterproof (IP67):** The speaker is waterproof and can be submerged up to 1 meter for 30 minutes. Ensure the charging port flap is securely closed before exposure to water. It is also sandproof, snowproof, and shockproof.
- **Storage:** Store the speaker in a cool, dry place when not in use. Avoid extreme temperatures.





**#WATERPROOF**

Image: The speaker covered in water droplets, highlighting its waterproof capability.



## **EVERYTHING-PROOF FOR ANY TERRAIN**

***Weather the Elements with Confidence.***

Waterproof, dustproof, and shockproof, the HydraTrek is designed to endure beach days, snowy slopes, and rugged trails without missing a beat.

Image: The speaker attached to a backpack, emphasizing its durability and suitability for various terrains.

## 7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Speaker does not power on.	Low battery.	Charge the speaker fully.
No sound.	Volume too low; Not paired; Device issue.	Increase speaker and device volume; Re-pair the speaker; Check device audio output.
Cannot pair with device.	Speaker not in pairing mode; Device Bluetooth off; Too far from device.	Ensure speaker is flashing LED; Turn device Bluetooth on/off; Move speaker closer to device (within 100ft).
TWS pairing fails.	Speakers already paired to other devices.	Disconnect both speakers from any other Bluetooth devices before attempting TWS pairing.

## 8. TECHNICAL SPECIFICATIONS

- **Model Name:** HydraTrek
- **Model Number:** IMW1012-BLKLGRY-STK-2
- **Dimensions:** 3"D x 4.5"W x 5.5"H
- **Weight:** 1.04 pounds
- **Material:** Metal
- **Speaker Output Power:** 5W RMS
- **Speaker Size:** 2 Inches
- **Connectivity:** Bluetooth Wireless (100 feet range)
- **Battery Life:** Up to 6 Hours
- **Charging Time:** 3 Hours
- **Water Resistance:** IP67 (Waterproof, Sandproof, Snowproof, Shockproof)
- **Special Features:** Built-in Microphone, Party Sync (True Wireless Pairing), Magnetic Mounting

## 9. WARRANTY INFORMATION

This Altec Lansing HYDRATREK speaker comes with a Limited Warranty. Please refer to the warranty card included in your package or visit the official Altec Lansing website for detailed warranty terms and conditions.

## 10. CUSTOMER SUPPORT

For further assistance, technical support, or warranty claims, please contact Altec Lansing customer service through their official website or the contact information provided in your product documentation.

**Website:** [www.alteclansing.com](http://www.alteclansing.com)