

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

> [VGR](#) /

> [VGR V-395 Wet & Dry Shaver User Manual](#)

## VGR V-395

# VGR V-395 Wet & Dry Shaver User Manual

Model: V-395 | Brand: VGR

## INTRODUCTION

---

This user manual provides detailed instructions for the safe and effective operation, maintenance, and troubleshooting of your VGR V-395 Wet & Dry Shaver. Please read this manual thoroughly before using the device and keep it for future reference.

## SAFETY INFORMATION

---

Your safety is paramount. Please adhere to the following safety guidelines:

- Ensure the shaver is unplugged while cleaning to prevent electric shock.
- Do not attempt to replace the battery yourself; seek professional assistance if needed.
- Keep the device away from water sources when charging.
- Do not use the shaver if it is damaged or malfunctioning.
- Keep out of reach of children.

## PACKAGE CONTENTS

---

Upon opening the package, verify that all components are present:

- VGR V-395 Wet & Dry Shaver
- USB Charging Cable
- Cleaning Brush
- Protective Cap for Shaver Head
- User Manual (this document)



Image: Contents of the VGR V-395 package, showing the shaver, charging cable, cleaning brush, and protective cap.

## SETUP

---

### Charging the Shaver

Before first use, fully charge the shaver. The device features an LED display to indicate charging status.

1. Connect the USB charging cable to the shaver's charging port.
2. Plug the other end of the USB cable into a compatible USB power adapter (not included), computer, laptop, or power bank.
3. The LED display will show the charging progress. A full charge typically takes approximately 2 hours.
4. Once fully charged, the shaver provides up to 90 minutes of cordless operation.

# LED DISPLAY

Shows working and charging status



NO.1  
TIME OF USE

90

NO.2  
STATUS



NO.3  
TRAVEL LOCK



NO.4  
WASHING



Image: The VGR V-395 shaver being charged via USB, highlighting the 2-hour charge time and 90-minute work time.

# USB CHARGING

USB cable provide you to  
pulg wherever you need



**2 Hours**

**Charge Time**

**90 Min**

**Work Time**

**Convenient And Safe USB Charging**



Computer



Laptop



USB Charging



Power bank

Image: Close-up of the VGR V-395 shaver's LED display, indicating time of use, status, travel lock, and cleaning reminder.

## OPERATING INSTRUCTIONS

### General Operation

1. Ensure the shaver is fully charged.
2. Press the power button to turn the shaver on. The LED display will illuminate.
3. For a dry shave, ensure your skin is clean and dry.
4. For a wet shave, you may apply shaving cream or gel to your skin. The shaver is designed for wet and dry use.
5. Gently press the shaver head against your skin and move it in circular or linear motions, following the contours of your head or beard. The easy pivot head adjusts to hug the contour of the head.

6. After shaving, press the power button again to turn the shaver off.




Image: The VGR V-395 shaver showcasing its 6D floating heads designed for a perfect hair cut.

## MAINTENANCE

---

### Cleaning the Shaver

Regular cleaning ensures optimal performance and hygiene. The VGR V-395 is IPX6 washable, allowing for easy cleaning under running water.

1. Ensure the shaver is turned off and unplugged from any power source before cleaning.
2. Open the shaver head assembly.
3. Rinse the shaver head and the internal components under running water.
4. Use the provided cleaning brush to remove any stubborn hair clippings from the blades and internal chambers.
5. Allow the shaver head to air dry completely before reassembling or storing.

6. Periodically, you may apply a drop of lubricating oil (not included) to the blades for smoother operation.



Image: The VGR V-395 shaver being cleaned under running water, highlighting its IPX6 waterproof body.

## TROUBLESHOOTING

If you encounter any issues with your VGR V-395 shaver, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Shaver does not turn on.	Battery is depleted.	Charge the shaver fully (approx. 2 hours).
Shaver not shaving effectively.	Blades are clogged with hair or dull.	Clean the shaver head thoroughly. Consider replacing the shaver head if blades are dull (replacement heads sold separately).

Problem	Possible Cause	Solution
Shaver makes unusual noise.	Hair trapped inside or lack of lubrication.	Clean the shaver thoroughly. Apply a drop of lubricating oil to the blades.
Charging indicator not working.	Faulty charging cable or power source.	Try a different USB cable or power adapter. Ensure the connection is secure.

If the problem persists after trying these solutions, please contact customer support.

## SPECIFICATIONS

Feature	Detail
Model Name	V-395
Brand	VGR
Power Source	Battery Powered (Rechargeable)
Battery Type	1 Lithium Ion battery (included)
Charging Time	Approx. 2 hours
Battery Life / Usage Time	Up to 90 minutes
Special Features	Cordless, Wet & Dry Shave, LED Display, Easy Pivot Head
Blade Material	Stainless Steel
Color	Silver
Item Weight	0.33 Kilograms
Package Dimensions	18.8 x 15.8 x 8 cm
Recommended Use	Head and Beard Shaving

## WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the warranty card included with your product or contact VGR customer service through their official website or the retailer from whom you purchased the product.

Please retain your proof of purchase for any warranty claims.