Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

BoxWave TD-G750A

BoxWave ClearTouch Crystal Screen Protector Instruction Manual

For Tidradio TD-G750A

1. Product Overview

The BoxWave ClearTouch Crystal Screen Protector is designed to provide a protective layer for your Tidradio TD-G750A device screen. This high-quality optical film offers 99% visual transparency, ensuring vibrant color display and uninhibited clarity. It is precision-cut to fit the exact dimensions of your device, shielding it from scratches and dust.



Image: Packaging for the BoxWave ClearTouch Crystal Screen Protector, showing key features like color brilliance, clarity, precision, and reusability.

2. What's Included

Each package contains the following items:

- Two (2) ClearTouch Crystal Screen Protectors for Tidradio TD-G750A.
- One (1) ClearTouch Applicator Card.
- One (1) Microfiber Cleaning Cloth.
- One (1) Dust Removing Sticker.



Image: The package contents, including two screen protectors, an applicator card, and a microfiber cleaning cloth.



Image: Close-up of the included accessories: Applicator Card, Microfiber Cleaning Cloth, and Dust Removing Sticker.

3. Installation Instructions (Setup)

Follow these steps carefully for optimal screen protector application:

1. **Clean the Device Screen:** Use the provided microfiber cleaning cloth to thoroughly clean the Tidradio TD-G750A screen. Ensure all dust, fingerprints, and smudges are removed. For stubborn marks, a screen cleaner (not included) can be used sparingly.
2. **Remove Dust:** Use the dust removing sticker to lift any remaining dust particles from the screen. Gently dab the sticker across the entire screen surface.
3. **Align the Protector:** Carefully peel back a small portion of the protective film (usually labeled "Step 1" or similar) from one end of the screen protector. Align the exposed edge of the screen protector with the corresponding edge of your device screen. Ensure precise alignment with all cutouts (e.g., speaker, camera, buttons) before proceeding.
4. **Apply the Protector:** Slowly and steadily peel off the rest of the protective film while simultaneously applying the screen protector to the device screen. Use the ClearTouch Applicator Card to smooth out any air bubbles as you go, pushing them towards the edges.

5. **Remove Top Layer:** Once the screen protector is fully applied, gently peel off the top protective layer (usually labeled "Step 2" or similar), if present.
6. **Final Smoothing:** Use the microfiber cloth to gently wipe down the newly installed screen protector, removing any remaining small bubbles or smudges.

Note: *The special low-tack adhesive may take approximately 2 days to fully adhere around the edges, during which small air gaps may clear out with regular use.*

4. Usage (Operating)

Once installed, the ClearTouch Crystal Screen Protector operates passively to protect your device. It is designed to be:

- **Scratch Resistant:** Shields your screen from daily scratches, scuffs, and abrasions.
- **Dust Repellent:** Helps prevent dust and debris from accumulating on the screen surface.
- **Visually Clear:** Maintains 99% visual transparency for an uncompromised viewing experience with vibrant colors.

No special operation is required after installation. The screen protector functions as an invisible barrier.




Image: An example demonstrating the high definition clarity of the screen protector, showing a vibrant field of yellow flowers through the protected screen area.

5. Maintenance

To ensure the longevity and clarity of your screen protector, follow these maintenance guidelines:

- **Cleaning:** Use a soft, lint-free cloth, such as the provided microfiber cloth, to gently wipe the screen protector. For smudges or fingerprints, lightly dampen the cloth with water or a screen-safe cleaning solution. Avoid harsh chemicals or abrasive materials.
- **Avoid Sharp Objects:** While the protector offers scratch resistance, extreme pressure or sharp objects can still damage it.
- **Storage:** If you are not using the second screen protector immediately, store it in its original packaging in a cool, dry place to prevent damage or dust accumulation.

6. Troubleshooting

Issue	Possible Cause	Solution
Bubbles under the protector	Dust particles or uneven application.	For small bubbles, gently push them towards the nearest edge using the applicator card or microfiber cloth. For bubbles caused by dust, carefully lift the nearest corner of the protector, use a dust-removing sticker to lift the particle, and reapply. Allow up to 2 days for small air gaps to naturally clear out as the adhesive fully bonds.
Protector not adhering at edges	Dust under the edge or insufficient pressure during application.	Press firmly along the edges with the applicator card. Ensure the screen was thoroughly cleaned before application. Allow up to 2 days for the low-tack adhesive to fully bond.
Reduced touch sensitivity	Incorrect installation or a faulty protector.	Ensure the protector is applied smoothly without large air pockets. If issues persist, consider reapplying with the second protector provided.

7. Specifications

- **Product Type:** Screen Protector Film
- **Material:** High-grade Thermoplastics (Polyethylene Terephthalate - PET)
- **Transparency:** 99% Visual Transparency
- **Compatibility:** Specifically designed for Tidradio TD-G750A
- **Adhesive Type:** Glueless, low-tack adhesive (leaves no sticky residue)
- **Package Contents:** 2x Screen Protectors, 1x Applicator Card, 1x Microfiber Cleaning Cloth, 1x Dust Removing Sticker
- **Item Weight:** 0.7 ounces (approximate, for the package)
- **Manufacturer:** BoxWave

8. Warranty and Support

BoxWave products are designed for quality and durability. For any questions, concerns, or support regarding your ClearTouch Crystal Screen Protector, please contact BoxWave Corporation directly through their official website or customer service channels. Please refer to your purchase documentation for specific warranty details.
For more information, visit the official BoxWave website:www.boxwave.com

© 2024 BoxWave Corporation. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D5TDB7KN

More documents and user manuals: **https://manuals.plus/**