Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

TYCOLE GDS-907-080 Antenna 1 x 4 with Rounded Top

TYCOLE Classic Bricks GDS-907-080 Antenna 1 x 4 with Rounded Top Instruction Manual

Model: GDS-907-080 (Antenna 1 x 4 with Rounded Top)

1. Introduction

This instruction manual provides essential information for the proper use and care of your TYCOLE Classic Bricks GDS-907-080 Antenna 1 x 4 with Rounded Top. This component is designed for creative building and is fully compatible with major brick brands, including Lego. Please read this manual thoroughly to ensure optimal integration and enjoyment of your new building elements.

2. Product Overview

The GDS-907-080 Antenna 1 x 4 with Rounded Top is a versatile building block component. It features a 1x4 stud base with a rounded top, designed to represent antenna-like structures or other creative elements in your brick constructions. It is manufactured from durable plastic and is engineered for a tight, secure fit with other compatible building blocks.

- **Component Name:** Antenna 1 x 4 with Rounded Top
- **Model Number:** GDS-907-080 (Compatible with Lego Part 3957)
- **Material:** High-quality Plastic
- **Compatibility:** 100% compatible with Lego and all major brick brands.




Image 1: The TYCOLE GDS-907-080 Antenna 1x4 with Rounded Top brick component. This image displays a single blue brick, elongated with a rounded tip and a wider base for connection.

3. Setup and Assembly

Integrating the GDS-907-080 Antenna 1 x 4 with Rounded Top into your brick creations is straightforward.

1. **Identify Connection Points:** Locate a compatible stud or hole on your existing brick structure where you wish to attach the antenna.
2. **Align Component:** Position the base of the GDS-907-080 antenna over the desired connection point.
3. **Press to Secure:** Gently but firmly press the antenna component onto the connection point until it clicks securely into place. Ensure a snug fit to prevent accidental detachment.

This component can be used to add detail, height, or specific structural elements to your models.

4. Usage Instructions

The GDS-907-080 Antenna 1 x 4 with Rounded Top is designed for creative construction. Use it to:

- Create antennas for vehicles, spaceships, or buildings.
- Add decorative spires or poles to architectural models.
- Form part of a robot's arm or sensor array.
- Enhance the aesthetic detail of any brick-built creation.

Experiment with different orientations and placements to achieve desired effects in your models.

5. Maintenance

To ensure the longevity and cleanliness of your TYCOLE Classic Bricks, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the bricks with a soft, damp cloth to remove dust and dirt. For more thorough cleaning, use mild soap and lukewarm water. Rinse thoroughly and air dry completely before storage or reuse.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, solvents, or harsh chemicals, as these can damage the plastic and color.
- **Storage:** Store bricks in a clean, dry place away from direct sunlight and extreme temperatures to prevent warping or discoloration.

6. Troubleshooting

The GDS-907-080 Antenna 1 x 4 with Rounded Top is a simple, durable component. Most issues can be resolved with basic checks.

Problem	Possible Cause	Solution
Brick does not connect securely.	Misalignment or obstruction.	Ensure the studs and holes are clean and free of debris. Realign the component and press firmly.
Brick appears warped or damaged.	Exposure to high heat or excessive force.	Avoid exposing bricks to direct sunlight or heat sources. Do not apply excessive force during assembly or disassembly. Replace damaged components.

7. Specifications

Feature	Detail
Model Name	Antenna 1 x 4 with Rounded Top
Model Number	GDS-907-080 (Compatible with Lego Part 3957)
Brand	TYCOLE
Material	Plastic
ASIN	B0D5TQTVCB
Manufacturer	Gobricks
Recommended Age	18 years and up

8. Safety Information

Please observe the following safety precautions:

- **Choking Hazard:** This product contains small parts and is not suitable for children under 3 years of age. Adult supervision is recommended for all users, especially those under the manufacturer's recommended age of 18 years.
- **Intended Use:** Use this product only for its intended purpose as a building block component.
- **Avoid Ingestion:** Do not put bricks in mouth.
- **Sharp Edges:** While designed for safety, handle with care to avoid any potential minor scrapes.

9. Warranty and Support

TYCOLE is committed to providing high-quality building components. For any questions, concerns, or support regarding your GDS-907-080 Antenna 1 x 4 with Rounded Top, please contact the seller or TYCOLE customer service through the platform where the purchase was made. Please retain your proof of purchase for any warranty claims or support inquiries.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D5TQTVCB

More documents and user manuals: **https://manuals.plus/**