

Zojirushi NW-YB10AM

Zojirushi Pressure IH Rice Cooker NW-YB10AM Instruction Manual

Model: NW-YB10AM | Brand: Zojirushi

1. INTRODUCTION

Thank you for purchasing the Zojirushi Pressure IH Rice Cooker, model NW-YB10AM. This rice cooker is designed to deliver exceptional taste and texture, featuring the "Gōnetsu Dai-Karyoku" (Powerful Heat) series technology. This manual provides essential information for the safe and efficient use of your appliance. Please read it thoroughly before operation and keep it for future reference.

Important Safety Information:

Voltage Compatibility: This product is designed exclusively for 100V domestic use in Japan. It cannot be used in regions with different power voltages or frequencies. Use outside of Japan will void the manufacturer's warranty and after-sales service.



Image: Zojirushi Pressure IH Rice Cooker NW-YB10AM in Slate Black.

2. SETUP

2.1 Unpacking

Carefully remove all packaging materials. Ensure all components are present: the main unit, inner pot, inner lid, rice scoop, and measuring cup. Retain packaging for potential future transport or service.

2.2 Placement

- Place the rice cooker on a stable, flat, and heat-resistant surface.
- Ensure adequate ventilation around the unit. Do not place it near walls or other appliances that may obstruct airflow.
- Avoid placing the unit near direct sunlight or heat sources.

2.3 Power Connection

Connect the power cord securely to the rice cooker and then plug it into a standard 100V AC outlet. Do not use extension cords or adapters unless absolutely necessary and ensure they are rated for the appliance's power requirements (1240W).

2.4 Initial Cleaning

Before first use, wash the inner pot, inner lid, rice scoop, and measuring cup with mild dish soap and warm water. Wipe the exterior of the main unit with a damp cloth. Ensure all parts are completely dry before assembly and use.

3. OPERATING INSTRUCTIONS

3.1 Gōnetsu Dai-Karyoku (Powerful Heat) Cooking

The "Gōnetsu Dai-Karyoku" feature ensures rice is cooked with strong, sustained heat, drawing out its natural sweetness and producing a fluffy texture. This is achieved through a unique structure that suppresses boil-overs, allowing for continuous high-heat cooking.

大火力が生み出す、このうまさ。


豪熱大火力[®]



※イメージ

(ふた部断面図)

蒸気



※イメージ

大火力で炊き続けても
ふきこぼれを抑える

象印独自の構造

大火力ユニット

だから

お米の甘みを引き出す

Image: Diagram illustrating the powerful heat cooking process and boil-over suppression mechanism.

3.2 Pressure IH Cooking

This rice cooker utilizes Pressure Induction Heating (IH) technology, maintaining temperatures above 100°C to cook rice thoroughly and evenly. The pressure mechanism ensures each grain is plump and delicious.

高温で炊くから
ごはんが甘くてもちもち!

100℃以上で炊き続ける[圧力IH炊飯]



Image: Cross-section diagram showing the Pressure IH heating elements (lid heater, side heater, IH heater) and pressure application.

3.3 3-Way Pressure Cooking

Customize your rice texture with three pressure cooking options:

- **Shakkiri (Firm):** For a firmer texture, ideal for dishes like curry.
- **Futsuu (Regular):** Standard texture for everyday meals.
- **Sushimeshi (Sushi Rice):** Slightly stickier and glossier, perfect for sushi.

ごはんを好みの食感に

[3通りの炊き分け圧力]



お好みに炊き分け

しゃっきり

ふつう

すしめし

お好みの食感に合わせて炊き方を選べます。

Image: Examples of rice cooked to firm, regular, and sushi rice textures.

3.4 Cooking Various Rice Types

The NW-YB10AM offers specialized settings to cook various rice types to perfection, including brown rice and mixed grains, enhancing their nutritional value and taste.

栄養価の高い お米もおいしく!



麦ごはん
メニュー

雑穀米
メニュー

玄米
メニュー

Image: Dishes featuring barley rice, mixed grain rice, and brown rice.

3.5 Quick Cooking and Keep Warm Functions

- **White Rice Quick Menu:** Cook 1 cup of white rice in approximately 30 minutes. (Cooking times may vary based on rice volume and menu selection. Refer to the full instruction manual for details.)
- **Uru-tsuya Keep Warm:** This function suppresses moisture evaporation, keeping rice delicious for up to 30 hours.

忙しい毎日を おいしく支える！



うるつや保温

水分の蒸発を抑え、30時間まで
おいしく保温。^{※2}

白米急速メニュー

1合が約**30分**^{※1}で
炊ける。



- ※1 NW-YB10の場合 白米を0.5合(約27分)～5.5合(約34分)まで炊けます。
NW-YB18の場合 白米を1合(約28分)～1升(約37分)まで炊けます。
炊飯量によって炊きあがりの時間は異なります。
※2 メニューによって異なります。取扱説明書をご確認ください。

Image: A bowl of freshly cooked white rice and a person serving rice with chopsticks, demonstrating quick cooking and keep warm features.

3.6 Aged Cooking (White Rice)

The "Aged Cooking" setting for white rice maximizes the sweetness and flavor of each grain, resulting in exceptionally tasty rice.



Image: Close-up of fluffy white rice, highlighting the 'Aged Cooking' feature.

4. MAINTENANCE

Keeping your rice cooker clean is essential for optimal performance and hygiene. The NW-YB10AM is designed for easy maintenance.

4.1 Easy Cleaning Features

- **Steam Vent Set-Free:** No need to remove and clean a separate steam vent cap.
- **Flat Top Panel:** The smooth, flat surface of the top panel makes wiping clean simple.
- **Flat Interior:** The interior of the main unit (excluding the side sensor area) is flat, preventing rice from sticking and simplifying cleaning.

4.2 Parts to Wash

Only two parts require daily washing: the inner lid and the inner pot. For detailed cleaning instructions for other parts, please refer to the full instruction manual.



Inner Lid



Inner Pot

毎日のお手入れを簡単に!

毎回洗うのは たったの2点!

※その他のお手入れに関しては
取扱説明書をご確認ください。
※画像は10サイズです。

内ぶた

内釜



凹凸が少ないフラットな構造



フラットトップパネル



フラット庫内※1

※1 フラット庫内はサイドセンサー部を除く。

Image: Demonstrating easy cleaning of the flat top panel and flat interior.

4.3 Ag+ Antibacterial Accessories

The included rice scoop and push button are treated with Ag+ antibacterial processing, inhibiting bacterial growth for improved hygiene. (Test institution: Boken Quality Evaluation Institute. Test method: Based on JIS Z2801. Antibacterial method: Ag+. Target parts: Rice scoop, push button. 99% antibacterial effect. Test number: 20220018093-1).

5. TROUBLESHOOTING

If you encounter any issues with your Zojirushi rice cooker, please refer to the following common troubleshooting tips. For more detailed solutions, consult the comprehensive instruction manual.

- **Rice not cooking properly:** Ensure the correct water level is used for the type and amount of rice. Check that the inner pot and inner lid are correctly seated. Verify that the power cord is securely plugged in.

- **Error codes displayed:** Specific error codes indicate different issues. Refer to the full manual for a list of codes and their corresponding solutions.
- **Steam leakage:** Check if the inner lid is properly installed and clean. Ensure there are no food particles obstructing the seal.
- **Unusual odors:** Perform a thorough cleaning of all removable parts. If the odor persists, contact customer support.

If the problem persists after attempting these solutions, please contact Zojirushi customer service.

6. SPECIFICATIONS

Feature	Specification
Brand	Zojirushi (ZOJIRUSHI)
Model Number	NW-YB10AM
Manufacturer Model Number	NW-YB10AM-BZ
Capacity	1 L (5.5 Go)
Product Dimensions (D x W x H)	36.5 cm x 25 cm x 20.5 cm
Product Weight	5 kg
Power Source	Power Cord
Voltage	100 Volts
Power Consumption	1240 W
Care Method	Hand wash, wipe with a damp cloth
Country of Origin	Japan
Included Accessories	Rice scoop, instruction manual, white rice measuring cup
Special Features	Alarm, Guided User Interface, Steam Vent, Timer, Non-stick, Lockable Lid, Retractable Cord, Removable Bowl, Removable Lid, Variable Temperature Control, Pressure Control Device, Airtight Lid, Automatic Keep Warm, Induction Heating
Color	Slate Black

7. WARRANTY AND SUPPORT

Your Zojirushi Pressure IH Rice Cooker NW-YB10AM comes with a manufacturer's warranty. Please refer to the warranty card included with your product for specific terms and conditions.

7.1 Instruction Manual Access

A 2D code is provided with the product to access the digital instruction manual for comprehensive details and additional information.

7.2 International Use Disclaimer

As stated previously, this product is designed for 100V domestic use in Japan. Use in countries with different power specifications will invalidate the manufacturer's warranty and any associated after-sales services. Zojirushi cannot provide support for products used outside their intended region.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question