MATEIN 119702GRN

MATEIN Extra Large 45L Travel Backpack

USER MANUAL

Introduction

This manual provides essential information for the proper setup, operation, and maintenance of your MATEIN Extra Large 45L Travel Backpack. Designed for versatility and convenience, this backpack is suitable for various travel needs, including airline carry-on, business trips, and daily use. Please read this manual thoroughly to ensure optimal use and longevity of your product.

Product Overview

The MATEIN Extra Large 45L Travel Backpack is engineered to meet airline carry-on requirements while offering substantial storage capacity and organizational features. Key features include a dedicated laptop compartment, a separate shoe compartment, an integrated USB charging port, and water-resistant material.



Image: Front view of the MATEIN Extra Large 45L Travel Backpack in green, showcasing its sleek design and front pockets.

Setup

1. **Unpacking:** Remove the backpack from its packaging. Inspect for any shipping damage.
2. **Strap Adjustment:** Adjust the shoulder straps to a comfortable length. The breathable, adjustable straps are designed for stress-free carrying.

3. **USB Charging Port Preparation:** The external USB port requires your own portable charger (power bank) to function. Connect your power bank to the internal charging cable located within the backpack.
4. **Shoe Compartment:** The dedicated shoe compartment at the bottom is designed to fit shoe sizes 10-12. It features breathable venting holes to prevent odors. This compartment can also be used for toiletries or other accessories.



Image: Close-up of the external USB charging port on the side of the backpack.



Image: The dedicated shoe compartment at the bottom of the backpack, shown with a pair of white shoes inside.

Operating Instructions

- **Main Compartment:** The large main compartment offers ample space for 3-4 days of clothing and travel essentials, similar to a suitcase. Utilize the double zippers for easy access.
- **Laptop Compartment:** A separate, padded compartment is designed to protect laptops up to 18 inches. Secure your laptop using the internal strap.
- **Organizer Compartment:** The front compartment features multiple pockets for organizing smaller items such as pens, notebooks, and electronic accessories.
- **Hidden Pocket:** A secure hidden pocket is integrated for valuables like passports, wallets, and other important documents.
- **TSA-Friendly Design:** The backpack features a 90-180° opening design, allowing for quick and easy security checks at airports without removing your laptop.
- **Luggage Strap:** Use the integrated luggage strap on the back to slide the backpack over the handle of your rolling luggage for convenient transport.
- **Side Mesh Pocket:** This pocket is suitable for holding water bottles or umbrellas.



Image: The main compartment of the backpack, open and filled with rolled clothing, demonstrating its 45L capacity.



Image: Views of the padded laptop compartment and the multi-pocket organizer compartment, showing items like a laptop, tablet, and pens.



Image: The backpack secured onto the handle of a rolling suitcase using its luggage strap.



Image: A close-up of the hidden anti-theft pocket on the back panel, shown with a wallet and cash inside.

Maintenance

- **Cleaning:** The backpack is made from water-repellent, high-density polyester. For general cleaning, wipe with a damp cloth and mild soap. Do not machine wash or tumble dry.
- **Drying:** Air dry the backpack completely before storing to prevent mildew.
- **Zippers:** Periodically check zippers for smooth operation. If a zipper becomes stiff, apply a small amount of zipper lubricant or wax.
- **Storage:** Store the backpack in a cool, dry place away from direct sunlight when not in use.

Troubleshooting

- **USB Charging Port Not Working:**
  - Ensure your portable charger (power bank) is fully charged and correctly connected to the internal USB cable.
  - Verify that your device's charging cable is securely plugged into the external USB port.
- **Zipper Sticking:**
  - Avoid forcing the zipper. Gently pull the fabric away from the zipper teeth.
  - Apply a small amount of graphite (from a pencil) or zipper lubricant to the teeth and gently work the zipper back and forth.
- **Backpack Appears Smaller Than Expected:**
  - The 45L capacity is measured when the backpack is fully expanded and packed efficiently. Ensure all compartments are utilized.

Specifications

Feature	Detail
Product Dimensions	8.5 x 13.5 x 21 inches (D x W x H)
Item Weight	2.3 pounds
Capacity Total	45 Liters
Laptop Compartment Fit	Up to 18 inch laptop
Shoe Compartment Fit	Sizes 10-12

Feature	Detail
Material	Water-repellent, high-density polyester
Model Number	119702GRN



Image: Visual representation of the backpack's dimensions (21"H x 13.5"L x 8.5"W) and its suitability for various activities like traveling, carry-on, business, and college.

Warranty and Support

MATEIN products are designed for durability and performance. For any questions, concerns, or support regarding your MATEIN Extra Large 45L Travel Backpack, please refer to the official MATEIN website or contact customer service through your purchase platform. Keep your proof of purchase for any warranty claims.
Visit the official MATEIN Store for more information:MATEIN Store

© 2025 MATEIN. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question