

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [BANDAI SPIRITS](#) /

› [Bandai Spirits One Piece Chopper Robo 3 & 5 Model Kit Instruction Manual](#)

**BANDAI SPIRITS 2753018**

# Bandai Spirits One Piece Chopper Robo 3 & 5 Model Kit

**Model:** 2753018

**Brand:** BANDAI SPIRITS

## SAFETY INFORMATION

Please read all safety warnings before assembly and use.

- **WARNING: CHOKING HAZARD** - Small parts. Not for children under 3 years.
- Recommended age for assembly and use is 15 years and up.
- Keep all packaging materials away from children.

## PRODUCT OVERVIEW

The Bandai Spirits One Piece Chopper Robo 3 & 5 Model Kit allows for the assembly of two distinct Chopper Robo units: the Chopper Submarine (Robo 3) and the Chopper Crane (Robo 5). These kits feature snap-fit assembly, requiring no glue, and utilize Bandai's multi-color runner technology for easy color recreation without painting. This product is an officially licensed Bandai Namco item.



Image: The assembled Chopper Robo 3 (Chopper Submarine) and Chopper Robo 5 (Chopper Crane) models.

## PACKAGE CONTENTS

Verify that all components are present before beginning assembly.

- One Piece - Chopper Robo 3 & 5 (Chopper Submarine & Chopper Crane) Model Kit parts runners
- Instruction manual (this document)



Image: The product box art, illustrating the Chopper Submarine and Chopper Crane models.

## ASSEMBLY INSTRUCTIONS

This model kit features snap-fit assembly. No glue is required. Carefully detach parts from the runners using a hobby nipper or knife to avoid damage. Follow the numbered steps provided in the included pictorial guide for best results.

### Assembling Chopper Robo 3 (Chopper Submarine)

1. Begin by assembling the main body of the submarine.
2. Attach the front propeller and side fins.
3. Assemble the clear cockpit canopy and attach it to the top of the submarine.
4. Attach the rear fin and propulsion unit.



©尾田栄一郎/集英社・フジテレビ・東映アニメーション

Image: Front view of the assembled Chopper Submarine (Robo 3).



©尾田栄一郎/集英社・フジテレビ・東映アニメーション

Image: Side view of the assembled Chopper Submarine (Robo 3).

### Assembling Chopper Robo 5 (Chopper Crane)

1. Assemble the central body and wheel base.
2. Attach the four barrel-shaped leg/wheel units.
3. Connect the two large crane arms to the central body.
4. Attach the crane claws to the ends of the arms.



©尾田栄一郎/集英社・フジテレビ・東映アニメーション

Image: Front view of the assembled Chopper Crane (Robo 5).



©尾田栄一郎/集英社・フジテレビ・東映アニメーション

Image: Side view of the assembled Chopper Crane (Robo 5).

### Assembling the Chopper Figures

Each Chopper Robo comes with a small Chopper figure designed to pilot the unit. Assemble these figures according to the pictorial instructions, ensuring all small parts are securely attached.



©尾田栄一郎/集英社・フジテレビ・東映アニメーション

Image: The Chopper figure designed for the Submarine, wearing a blue diving helmet.



©尾田栄一郎/集英社・フジテレビ・東映アニメーション

Image: The Chopper figure designed for the Crane, wearing a red samurai helmet.

## OPERATING INSTRUCTIONS

Once assembled, the Chopper Robo units can be posed and displayed. The Chopper figures can be placed inside their respective cockpits. These models are designed to be combined with other Chopper Robo units (sold separately) to form a larger, combined robot.

- **Posing:** Gently adjust the joints of the models to achieve desired poses. Avoid excessive force to prevent breakage.
- **Combining:** To combine Chopper Robo 3 and 5, follow the specific instructions provided in the pictorial guide. The Chopper Submarine can attach to the Chopper Crane to create a unique combined form.



©尾田栄一郎/集英社・フジテレビ・東映アニメーション

Image: The Chopper Submarine and Chopper Crane combined into a larger robot form.

## MAINTENANCE

Proper care will ensure the longevity of your model kit.

- **Cleaning:** Use a soft, dry cloth to gently wipe away dust. Avoid using harsh chemicals or abrasive materials, as these can damage the plastic and paint.
- **Storage:** Store the model in a cool, dry place away from direct sunlight and extreme temperatures to prevent discoloration or warping of plastic parts.
- **Handling:** Handle the model by its main body parts rather than small, delicate protrusions to avoid accidental breakage.

## TROUBLESHOOTING

If you encounter any issues during assembly or use, refer to the following common solutions:

- **Parts not fitting:** Ensure you are using the correct parts for the step. Check for any excess plastic ("nubs") left over from the runners and carefully trim them.
- **Loose joints:** If a joint feels too loose, you may apply a thin layer of clear nail polish or hobby cement to the peg and let it dry completely before reassembling to create a tighter fit.
- **Missing parts:** Double-check the runners and packaging. If a part is genuinely missing, contact Bandai Spirits customer support.

## SPECIFICATIONS

Feature	Detail
Product Dimensions	10.23 x 2 x 5.9 inches
Item Weight	14.8 ounces
Item Model Number	2753018
Manufacturer Recommended Age	15 years and up
Release Date	October 1, 2025
Manufacturer	Bandai Spirits

## WARRANTY AND SUPPORT

This product is manufactured by Bandai Spirits. For any inquiries regarding manufacturing defects or missing parts, please refer to the contact information provided on the product packaging or visit the official Bandai Spirits website.

As an officially licensed Bandai Namco product, it adheres to high-quality standards. Keep your proof of purchase for any warranty claims.

For additional product information and other Bandai Hobby products, you can visit the [BANDAI SPIRITS Store on Amazon](#).