#### Manuals+

Q & A | Deep Search | Upload

#### manuals.plus /

- Blaupunkt /
- > Blaupunkt Rock & Roll Hitz 75W Wireless Speaker Instruction Manual

# **Blaupunkt Rock & Roll Hitz**

# Blaupunkt Rock & Roll Hitz 75W Wireless Speaker Instruction Manual

#### 1. Introduction

Thank you for choosing the Blaupunkt Rock & Roll Hitz 75W Wireless Speaker. This manual provides essential information for the safe and efficient operation of your new speaker. Please read it thoroughly before use and retain it for future reference.

#### 2. IMPORTANT SAFETY INFORMATION

To ensure safe operation and prevent damage, please observe the following precautions:

- Do not expose the speaker to extreme temperatures, direct sunlight, or high humidity.
- Avoid dropping or subjecting the speaker to strong impacts.
- · Do not disassemble, repair, or modify the unit yourself. Contact qualified service personnel for any repairs.
- · Keep the speaker away from water and other liquids.
- · Use only the provided power adapter for charging.
- Ensure proper ventilation around the speaker during use.

## 3. PACKAGE CONTENTS

Please check that all items are present in the package:

- 1 x Blaupunkt Rock & Roll Hitz Wireless Speaker
- 1 x Wired Microphone
- 1 x Power Adaptor
- 1 x Remote Control

#### 4. PRODUCT OVERVIEW

The Blaupunkt Rock & Roll Hitz speaker features a robust design with dynamic RGB lights and multiple connectivity options. Familiarize yourself with the speaker's components:



Image 4.1: Front view of the Blaupunkt Rock & Roll Hitz speaker with wired microphone.



Image 4.2: Internal structure highlighting the Hi-Fidelity Tweeter and Twin Massive Woofers for enhanced sound.



Image 4.3: The speaker's built-in dynamic RGB mood lights in operation.



Image 4.4: Overview of key features and connectivity options.

### 5. SETUP

## 5.1 Charging the Speaker

- 1. Connect the provided power adapter to the speaker's charging port.
- 2. Plug the power adapter into a suitable power outlet.
- 3. The charging indicator will illuminate. A full charge takes approximately 6 hours.
- 4. Once fully charged, the speaker provides an average of 3 hours of playback time.

#### 5.2 Powering On/Off

- To power on, press and hold the Power button located on the control panel.
- To power off, press and hold the Power button again.

#### 5.3 Connecting the Wired Microphone

- Insert the microphone cable into the designated microphone input jack on the speaker.
- Ensure the connection is secure.

#### 6. OPERATING INSTRUCTIONS

#### 6.1 Bluetooth Pairing

- 1. Power on the speaker. It will automatically enter Bluetooth pairing mode, indicated by a flashing LED.
- 2. Enable Bluetooth on your mobile device (smartphone, tablet, etc.).

- 3. Search for available Bluetooth devices and select "Blaupunkt Rock & Roll Hitz" from the list.
- 4. Once paired, the speaker will emit a confirmation sound, and the LED indicator will stop flashing.

#### 6.2 AUX-In Mode

- 1. Connect one end of a 3.5mm audio cable (not included) to the AUX-In port on the speaker.
- 2. Connect the other end of the cable to the audio output of your external device.
- 3. The speaker will automatically switch to AUX mode or you may need to select it using the Mode button.

#### 6.3 USB Playback

- 1. Insert a USB flash drive containing MP3 audio files into the USB port on the speaker.
- 2. The speaker will automatically detect the USB drive and begin playing music.
- 3. Use the control panel or remote to navigate tracks and adjust volume.

#### 6.4 Karaoke Function




Image 6.1: Using the wired microphone for karaoke.

- Ensure the wired microphone is securely connected to the speaker.
- Play music from your preferred source (Bluetooth, AUX, USB).
- Adjust the microphone volume using the dedicated control on the speaker or remote.

#### 6.5 Dynamic RGB Lights

- The speaker features dynamic RGB lights on the front panel.
- These lights can be activated or changed using the dedicated light mode button on the control panel or remote control.

## 6.6 True Wireless Stereo (TWS) Function

To pair two Blaupunkt Rock & Roll Hitz speakers for a stereo experience:

- 1. Ensure both speakers are powered on and not connected to any Bluetooth device.
- 2. On one speaker (this will be the primary speaker), press and hold the TWS button.
- 3. The primary speaker will search for the secondary speaker. Once connected, both speakers will emit a confirmation sound.
- 4. Now, connect your device to the primary speaker via Bluetooth as described in section 6.1. Audio will play in stereo across both speakers.

## 7. MAINTENANCE

## 7.1 Cleaning

- Wipe the speaker's exterior with a soft, dry cloth.
- · Do not use abrasive cleaners, waxes, or solvents.

## 7.2 Storage

- Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- If storing for an extended period, charge the battery periodically to maintain its lifespan.

# 8. TROUBLESHOOTING

Problem	Possible Cause	Solution			
Speaker does not power on	Battery is depleted; Power adapter not connected	Charge the speaker fully; Ensure power adapter is securely connected and power outlet is functional			
No sound output	Volume too low; Incorrect input mode; Device not connected	Increase volume on speaker and connected device; Select correct input mode (Bluetooth, AUX, USB); Reconnect device			
Bluetooth pairing fails	Speaker not in pairing mode; Device too far; Interference	Ensure speaker is in pairing mode; Move device closer to speaker; Turn off other Bluetooth devices			
Microphone not working	Microphone not connected properly; Microphone volume too low	Ensure microphone is securely plugged in; Increase microphone volume			
Remote control not working	Battery depleted; Obstruction between remote and speaker	Replace remote control battery; Ensure clear line of sight to speaker's IR receiver			

# 9. SPECIFICATIONS

Model Rock & Roll Hitz	Feature	Detail
	Model	Rock & Roll Hitz

Feature	Detail		
Audio Wattage	75 Watts		
Mounting Type	Floor Standing		
Power Source	Battery Powered		
Connector Type	Aux, USB		
Item Weight	5.7 kg		
Audio Input	Wired Microphone, AUX-In		
Frequency Response	20 KHz		
Product Dimensions (LxWxH)	38 x 31.5 x 70.5 cm		
Battery Type	1 Lithium Polymer battery required		
Battery Capacity	2400 mAh		
Battery Average Life	3 Hours		
Charging Time	6 Hours		
Special Features	Lightweight, Portable, Dynamic RGB Lights		
Speaker Connectivity	Wireless (Bluetooth)		
Signal-to-noise ratio (dB)	80 dB		
Colour	Black		
Compatible Devices	Smartphone, Laptop, MP3 Player, Microphone		

# 10. WARRANTY AND SUPPORT

## **10.1 Warranty Information**

This product is covered by a manufacturer's warranty. Please refer to the warranty card included in your package for specific terms and conditions. Keep your purchase receipt as proof of purchase for warranty claims.

# **10.2 Customer Support**

For technical assistance, service, or warranty inquiries, please contact:

• Manufacturer: Envent World Wide Private Limited

• Email: wecare@enventworld.com

• Contact Number: 8860022600

#### Related Documents - Rock & Roll Hitz

