



[Manuals.plus](#) /

> [EDISLIVE](#) /

> EDISLIVE Modern Milk Globe Chandelier User Manual

EDISLIVE B0D62MQQGP

EDISLIVE Modern Milk Globe Chandelier User Manual

Model: B0D62MQQGP

1. INTRODUCTION

Thank you for purchasing the EDISLIVE Modern Milk Globe Chandelier. This user manual provides essential information for the safe installation, operation, and maintenance of your new lighting fixture. Please read this manual thoroughly before installation and retain it for future reference.



Figure 1.1: EDISLIVE Modern Milk Globe Chandelier (Gold-Frosted Bubble, 39.4in-5 Light)

2. SAFETY INFORMATION

Always follow basic safety precautions when installing and operating electrical products. Failure to do so may result in fire, electric shock, or serious injury.

- **WARNING:** To avoid electric shock, ensure power is turned off at the circuit breaker or fuse box before installation, maintenance, or bulb replacement.
- All electrical connections must be in accordance with local codes, ordinances, or the National Electric Code (NEC). Consult a qualified electrician if you are unsure about wiring.
- Use only E26 base bulbs as specified. Do not exceed the maximum wattage indicated on the fixture.
- Handle glass globes with care to prevent breakage.
- Do not install the fixture in wet or damp locations. This product is designed for indoor use only.
- Ensure the mounting surface can support the weight of the fixture.

3. PACKAGE CONTENTS

Carefully unpack all components and inspect for any damage. Keep all packaging materials until you are sure all parts are present and in good condition. If any parts are missing or damaged, do not attempt to assemble or install the fixture. Contact customer support immediately.

- Chandelier Fixture Assembly
- Mounting Hardware (Ceiling Plate, Screws, Wire Nuts)
- Adjustable Hanging Rods (various lengths)
- Frosted Glass Globes (5 pieces)
- User Manual
- *Note: E26 Bulbs are NOT included.*



Figure 3.1: Key components of the chandelier.

4. PRODUCT SPECIFICATIONS

Feature	Detail
Brand	EDISLIVE
Model Number	B0D62MQQGP
Color	Gold-Frosted Bubble
Material	Metal, Glass
Style	Modern
Light Fixture Form	Chandelier
Product Dimensions (L x W x H)	39.37" x 5.91" x 58.07" (Adjustable Height)
Specific Uses	Home (Kitchen, Dining Room, Living Room)
Indoor/Outdoor Usage	Indoor
Power Source	AC
Control Method	App, Remote Control
Light Source Type	LED (Bulbs not included)
Finish Type	Brushed
Shade Material	Glass
Number of Light Sources	5
Voltage	120 Volts
Light Color	Warm White (Bulb dependent)
Bulb Base	E26
Brightness	2000 lumen (Bulb dependent)
Mounting Type	Ceiling Mount
Assembly Required	Yes
Item Weight	12.23 pounds
Average Life	50000 Hours (Bulb dependent)




Figure 4.1: Detailed dimensions of the chandelier fixture.

5. INSTALLATION GUIDE

Professional installation is recommended. If you are not familiar with electrical wiring, consult a qualified electrician. Ensure power is OFF at the circuit breaker before beginning installation.

5.1 Tools Required (Not Included)

- Phillips Head Screwdriver
- Flat Head Screwdriver
- Wire Strippers
- Electrical Tape
- Ladder
- Safety Glasses

5.2 Installation Steps

1. **Turn Off Power:** Locate the circuit breaker controlling the light fixture's power supply and turn it OFF. Verify power is off using a voltage tester.
2. **Prepare Mounting Surface:** Remove the existing fixture (if any) and its mounting bracket. Ensure the junction box is

securely mounted to the ceiling joist and can support the chandelier's weight.

3. **Attach Mounting Plate:** Secure the provided mounting plate to the junction box using the screws.
4. **Assemble Hanging Rods:** Determine the desired hanging height. The chandelier comes with adjustable rods of various lengths (e.g., 2x5.9", 2x7.87", 6x11.81"). Connect the appropriate rods to achieve your preferred length.
5. **Wire Connections:**
 - Connect the fixture's ground wire (bare copper or green) to the house's ground wire.
 - Connect the fixture's neutral wire (white) to the house's neutral wire (white).
 - Connect the fixture's hot wire (black or smooth) to the house's hot wire (black or ribbed).
 - Secure all connections with wire nuts and wrap with electrical tape for added safety.
6. **Mount Fixture Canopy:** Carefully lift the fixture and align the canopy with the mounting plate. Secure the canopy to the mounting plate using the provided screws.
7. **Install Glass Globes:** Carefully screw each frosted glass globe onto its respective lamp holder on the fixture. Do not overtighten.
8. **Install Bulbs:** Insert E26 base bulbs (not included) into each socket. Ensure bulbs are fully seated.
9. **Restore Power:** Turn the power back ON at the circuit breaker. Test the light fixture.




Figure 5.1: Adjustable hanging rod and sturdy ceiling plate details.

6. OPERATING INSTRUCTIONS

The EDISLIVE Modern Milk Globe Chandelier is designed for ease of use once installed.

6.1 Turning On/Off

Control the light fixture using your wall switch. For advanced control, including dimming, use the compatible remote control or a smart home application if connected to a smart system.

6.2 Dimming Functionality

This fixture supports dimming when used with dimmable E26 bulbs and a compatible dimmer switch or smart control system (App/Remote Control). Refer to your dimmer switch or smart system's instructions for specific dimming operations.

7. MAINTENANCE

Regular maintenance will help preserve the appearance and functionality of your chandelier.

7.1 Cleaning

- **Always turn off power before cleaning.**
- For the metal frame, wipe with a soft, dry cloth. Do not use abrasive cleaners or polishes as they may damage the finish.

- For the glass globes, gently wipe with a soft, damp cloth. A mild glass cleaner can be used if necessary, applied to the cloth first, not directly to the glass. Dry immediately with a clean, dry cloth to prevent water spots.

7.2 Bulb Replacement

- **Ensure power is turned off at the circuit breaker before replacing bulbs.**
- Allow bulbs to cool completely before touching them.
- Unscrew the old E26 bulb counter-clockwise.
- Screw in the new E26 bulb clockwise until snug. Do not overtighten.
- Restore power and test the new bulb.

8. TROUBLESHOOTING

If you encounter issues with your chandelier, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Light does not turn on.	<ul style="list-style-type: none"> ◦ Power is off at the circuit breaker. ◦ Loose wire connections. ◦ Faulty bulb(s). ◦ Faulty wall switch. 	<ul style="list-style-type: none"> ◦ Check the circuit breaker and turn it on. ◦ Turn off power, check all wire connections and re-secure them. ◦ Replace bulb(s) with known good ones. ◦ Test the wall switch; replace if necessary.
Light flickers or dims unexpectedly.	<ul style="list-style-type: none"> ◦ Loose bulb. ◦ Incompatible dimmer switch or non-dimmable bulbs. ◦ Loose wire connections. 	<ul style="list-style-type: none"> ◦ Tighten bulbs. ◦ Ensure you are using dimmable bulbs with a compatible dimmer switch. ◦ Turn off power, check and re-secure all wire connections.
Glass globe is loose or falls off.	<ul style="list-style-type: none"> ◦ Globe not screwed in properly. 	<ul style="list-style-type: none"> ◦ Carefully re-screw the globe onto the lamp holder until snug.

If the problem persists after trying these solutions, please contact EDISLIVE customer support.

9. WARRANTY AND SUPPORT

EDISLIVE products are manufactured to high-quality standards. For specific warranty details, please refer to the warranty card included with your purchase or contact EDISLIVE customer support directly. Keep your proof of purchase for warranty claims. For technical assistance, missing parts, or any other inquiries, please contact the seller or manufacturer through the platform where you purchased the product. You can also visit the official EDISLIVE store on Amazon for more information: [EDISLIVE Store](#).



