

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [RELPOM](#) /

› [RELPOM 2FT Mini Christmas Tree Instruction Manual](#)

RELPOM LZZK-IR21-13-02

RELPOM 2FT Mini Christmas Tree Instruction Manual

MODEL: LZZK-IR21-13-02

1. Product Overview

This manual provides instructions for the assembly, operation, and care of your RELPOM 2FT Mini Christmas Tree. Designed for tabletop display, this pre-lit tree features 100 branch tips and comes with over 80 DIY ornaments, offering a festive decoration for various indoor settings. Its compact size and battery-operated lights make it versatile for placement on nightstands, dining tables, or mantles.



Image 1: The RELPOM 2FT Mini Christmas Tree, showcasing its pre-lit design and included ornaments. Key features such as 8 lighting modes, battery operation, water resistance, and abundant ornaments are highlighted.

2. Important Safety Instructions

- This product is intended for indoor use only.
- Keep the tree away from open flames, heat sources, and direct sunlight to prevent damage or fire hazards.
- Ensure the tree is placed on a stable, flat surface to prevent tipping.
- Do not overload the branches with excessive ornaments.
- Batteries for the LED lights are not included. Use only the specified battery type (3 AA batteries) and ensure correct polarity.
- Remove batteries if the product is not used for an extended period.
- This product is not a toy. Keep out of reach of small children and pets to avoid choking hazards from small ornaments.

3. Package Contents

Verify that all components are present in the package:

- 1 x Tree Body (2FT Mini Christmas Tree)
- 1 x Base
- 1 x LED String Light Set (pre-installed)
- Various Ornaments (80+ pieces, 11 types)



Image 2: An example of the fully assembled tree with its included ornaments, demonstrating the complete package contents.

4. Setup Instructions

Follow these steps to assemble and decorate your Christmas tree:

1. **Unpack:** Carefully remove the tree body and all accessories from the packaging.
2. **Position the Base:** Place the tree base on a stable, level surface where you intend to display the tree.
3. **Fluff the Branches:** The tree branches are pre-installed. Gently unfold and separate each branch tip, working from the bottom upwards, to achieve a full and natural appearance. This process helps to shape the tree and maximize its volume.



Image 3: Detail of the tree's PVC branches, showing the quality and density that can be achieved by proper fluffing.

4. **Install Batteries for Lights:** Locate the battery box for the LED string lights. Open the battery compartment and insert 3 AA batteries (not included), ensuring correct polarity. Close the compartment securely.
5. **Decorate with Ornaments:** Begin hanging the provided DIY ornaments onto the tree branches. Arrange them evenly to create a balanced and festive look.



Image 4: A visual guide to the diverse range of DIY ornaments included, such as star toppers, bells, ball ornaments,

and more.

5. Operating Instructions (LED Lights)

Your RELPOM Mini Christmas Tree comes with 60 warm white LED string lights offering 8 dynamic lighting modes to enhance your festive ambiance.

- **Power On/Off:** Press the button on the battery pack to turn the lights ON. Continue pressing to cycle through the different lighting modes. Pressing it after the last mode will turn the lights OFF.
- **Lighting Modes:** The available modes are:
 1. Combination
 2. In wave
 3. Sequential
 4. Slo glo
 5. Chasing/Flash
 6. Slow fade
 7. Twinkle/Flash
 8. Steady on
 9. Off
- **Timer Function:** The lights feature an automatic timer. Once activated, the lights will stay ON for 6 hours and then turn OFF for 18 hours, repeating the cycle daily.



**60
LED LIGHTS**



**3AA Waterproof
Battery Pack**

8 Dynamic Lighting Modes

1. Combination	4. Slo glo	7. Twinkle/Flash
2. In wave	5. Chasing/Flash	8. Steady on
3. Sequential	6. Slow fade	9. Off

Image 5: The battery pack for the LED lights, detailing the control button and the list of 8 lighting modes.



Image 6: A visual comparison showing the tree's appearance in daylight versus its illuminated state at night.

6. Maintenance

- **Cleaning:** To clean the tree, gently wipe it with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Storage:** When not in use, carefully remove all ornaments and lights. Gently compress the branches and store the tree in its original box or a suitable storage container in a cool, dry place.
- **Battery Care:** Always remove batteries from the LED light compartment before storing the tree for extended periods to prevent leakage and damage.

7. Troubleshooting

Issue	Possible Solution
LED lights are not turning on.	Check if 3 AA batteries are correctly installed in the battery pack with the correct polarity. Replace old batteries with new ones if necessary. Ensure the battery pack button has been pressed to activate the lights.

Issue	Possible Solution
Tree appears sparse or not full.	Gently separate and fluff each individual branch tip, working from the inside out, to expand the tree to its full shape.
Tree is unstable or wobbles.	Ensure the tree base is placed on a completely flat and stable surface. Distribute ornaments evenly to maintain balance.

8. Product Specifications

Feature	Detail
Brand	RELPOM
Model Number	LZZK-IR21-13-02
Product Dimensions	13.5"D x 13.5"W x 24"H
Color	Pine Green
Material	Polyvinyl Chloride (PVC)
Item Weight	2.5 Pounds
Tip Count	100
Light Color	Warm White
Special Features	Bendable Branch, Lifelike pine, Lightweight, Powered by batteries, Prelit
Power Source	3 AA Batteries (not included)

9. Warranty and Support

For warranty details, customer support, or to inquire about replacement parts, please refer to the contact information provided by RELPOM at the point of purchase. You may also visit the official RELPOM store for additional information and assistance.

RELPOM Official Store: <https://www.amazon.com/stores/RELPOM/page/336B13E7-3191-4AD4-912B-1C91D29196C0>



Image 7: The official RELPOM brand logo.