

Easytry22995

Generic Remote Control Instruction Manual

For Thermal-Zone Air Conditioners (Models ZHF/LW-17-1, MSC424HP13230EB, MSC424HP13230EA, MSC418HP14230B, MSC424HP13230B, MSC424HP13230E)

INTRODUCTION

This manual provides instructions for the setup, operation, and basic maintenance of your new Generic replacement infrared remote control. This remote is designed to be compatible with specific Thermal-Zone air conditioner models, including ZHF/LW-17-1, MSC424HP13230EB, MSC424HP13230EA, MSC418HP14230B, MSC424HP13230B, and MSC424HP13230E. Please ensure your air conditioner model is listed for proper compatibility. This replacement remote may not offer all functions present on your original remote control.

SETUP

Battery Installation

The remote control requires two (2) AAA batteries (not included) for operation. Follow these steps to install the batteries:

1. Locate the battery compartment cover on the back of the remote control.
2. Press down on the tab and slide the cover downwards to open the compartment.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.



Image: Back of the remote control with the battery compartment open. This image illustrates the correct orientation for inserting two AAA batteries into the remote control.

After battery installation, the remote control is ready for use. No programming is typically required for this infrared replacement remote.

OPERATING INSTRUCTIONS

Point the remote control directly at the infrared receiver on your air conditioner unit. Ensure there are no obstructions between the remote and the unit.



Image: Front view of the remote control. This image displays the layout of all buttons and the LCD screen for operation.

Button Functions

- **ON/OFF:** Powers the air conditioner unit on or off.

- **Temperature Up/Down (▲/▼):** Adjusts the desired temperature setting. This remote supports Celsius only.
- **MODE:** Cycles through available operating modes such as Cool, Heat, Fan, Dry, or Auto.
- **FAN SPEED:** Adjusts the fan speed (e.g., Low, Medium, High, Auto).
- **SLEEP:** Activates or deactivates the sleep mode, which typically adjusts temperature and fan speed for comfortable sleep.
- **OUT FLAP / IN FLAP:** Controls the horizontal or vertical louver movement for air direction.
- **AUTOSTART:** Sets a timer for the air conditioner to automatically turn on.
- **AUTOSTOP:** Sets a timer for the air conditioner to automatically turn off.
- **HOUR / MIN:** Used to set the hour and minute for timer functions (AUTOSTART/AUTOSTOP).

MAINTENANCE

Cleaning

To clean the remote control, wipe it gently with a soft, dry cloth. Do not use liquid cleaners, abrasive materials, or chemical solvents, as these can damage the remote's surface or internal components.

Battery Replacement

Replace batteries when the remote's range decreases or if the air conditioner does not respond to commands. Always replace both batteries at the same time with new AAA batteries. Do not mix old and new batteries or different types of batteries.

TROUBLESHOOTING

- **Remote not responding to air conditioner:**
 - Check if the batteries are inserted correctly and are not depleted. Replace if necessary.
 - Ensure there is a clear line of sight between the remote control and the air conditioner's infrared receiver.
 - Verify that the remote is within the maximum operating range of 8 meters.
 - Confirm that your air conditioner model is listed as compatible with this remote.
- **Some functions do not work:**
 - As a replacement remote, it may not support all advanced or specific functions of your original air conditioner remote. Refer to your air conditioner's original manual for specific function requirements.

SPECIFICATIONS

Brand	Generic
Manufacturer	Easytry
Model Number	Easytry22995
Item Type	Remote controller
Compatible Devices	Air Conditioner
Connectivity Technology	Infrared
Maximum Range	8 meters

Number of Supported Devices	1
Battery Type	2 AAA batteries required
Special Features	Celsius Only, Cooling & Heating
Color	Grey

WARRANTY AND SUPPORT

Warranty Information

This product comes with a 90-day warranty. This warranty covers manufacturing defects and ensures hassle-free returns within the specified period.

Customer Support

For any questions, troubleshooting assistance, or warranty claims, please contact the seller directly through your purchase platform. Provide your order details and a clear description of the issue for prompt support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0D62YW8S7>

More documents and user manuals: <https://manuals.plus/>