

[Manuals.plus](#) /

› [HEKIWAY](#) /

› HEKIWAY 4-in-1 Multifunction LED Desk Lamp User Manual

HEKIWAY TD202406

HEKIWAY 4-in-1 Multifunction LED Desk Lamp User Manual

Model: TD202406 | Brand: HEKIWAY

1. PRODUCT OVERVIEW

The HEKIWAY 4-in-1 Multifunction LED Desk Lamp is a versatile device designed to enhance your workspace or living area. It integrates an LED desk lamp with adjustable lighting, a 15W wireless charger, a Bluetooth speaker, and a digital alarm clock, offering convenience and functionality in a compact design.



Figure 1.1: The HEKIWAY 4-in-1 Multifunction LED Desk Lamp in a home office setting, highlighting its integrated features.

2. PACKAGE CONTENTS

Please check the package for the following items:

- 1 x Wireless Charger Desk Lamp
- 1 x 1m USB Charging Cable (Note: 5V/3A or higher power adapter is NOT included and required for optimal performance)



Figure 2.1: Included components: the desk lamp and its USB charging cable.

3. SAFETY INFORMATION

Important Safety Precautions:

- Use only a DC 5V/3A (or higher) wall charger for power supply. Using a lower output power supply may cause the product to function sub-optimally, such as the light turning off during wireless charging due to insufficient power.
- Do not disassemble, repair, or modify the product.
- Keep the product away from water, fire, and high temperatures.
- Avoid dropping or subjecting the product to strong impacts.
- This product is designed for indoor use only.

The LED desk lamp has passed FCC, CE, and RoHS safety certifications, ensuring it meets US safety standards.

4. SETUP

1. **Connect Power:** Insert the provided USB charging cable into the lamp's power input port. Connect the other end of the USB cable to a compatible DC 5V/3A (or higher) wall adapter (not included) and plug it into a power outlet.
2. **Initial Power On:** The lamp will power on automatically or can be turned on by touching the power icon on the lamp head.
3. **Clock Setup:** The digital clock will display the time. Refer to the 'Digital Clock' section for instructions on setting the time and alarm.

5. OPERATING INSTRUCTIONS

5.1 Light Function

The LED desk lamp offers adjustable lighting to suit various needs:

- **Power On/Off:** Lightly touch the power icon on the lamp head to turn the light on or off.
- **Adjust Color Temperature:** With the light on, repeatedly touch the power icon to cycle through three color temperatures: Warm Light (2700K), Natural Light (4500K), and Cold Light (6500K).
- **Adjust Brightness (Dimmable):** Use the rotary knob located on the base of the lamp to continuously adjust the brightness level. Rotate clockwise to increase brightness and counter-clockwise to decrease it.



Figure 5.1.1: Touch switch for power and color temperature selection.



Figure 5.1.2: Visual representation of the three adjustable light color temperatures.

5.2 Wireless Charging

The lamp features a 15W fast wireless charging pad:

- **To Charge:** Simply place your Qi-compatible smartphone on the designated wireless charging pad located on the lamp's base. Ensure the phone is centered on the charging symbol for optimal connection.
- **Charging Indicator:** The digital clock display may show a charging icon or the phone's screen will indicate charging status.
- **Note:** For 15W fast wireless charging, ensure your power adapter provides sufficient output (DC 5V/3A or higher).



Figure 5.2.1: Using the 15W wireless charging feature.

5.3 Bluetooth Speaker

Enjoy your audio through the integrated Bluetooth 5.0 speaker:

- **Pairing:** Press and hold the volume knob on the lamp's base until you hear an audible prompt indicating "Bluetooth mode." The lamp is now in pairing mode.
- **Connect Device:** On your smartphone or other Bluetooth-enabled device, search for available Bluetooth

devices and select the lamp (usually named "BT Speaker" or similar). Once connected, you will hear a confirmation sound.

- **Volume Control:** Rotate the knob to adjust the speaker volume.

Video 5.3.1: Demonstration of Bluetooth pairing and sound adjustment on the HEKIWAY desk lamp.

This video illustrates the process of connecting a mobile device to the lamp's Bluetooth speaker and adjusting the volume using the control knob.

5.4 Digital Clock

The integrated digital clock helps you manage your time:

- **Time Display:** The clock displays the current time.
- **Setting Time/Alarm:** Specific buttons or combinations of presses on the clock unit (refer to the small icons near the display) are used to set the time and alarm. Typically, a 'Mode' button or long-press on a button allows you to enter setting mode, and '+' / '-' buttons (or the rotary knob) adjust values.
- **Alarm Function:** Set an alarm to wake you up or remind you of important tasks.



4-In-1 Multi-function Wireless Desk Lamp



Figure 5.4.1: The digital clock display with alarm function.

5.5 Flexible Gooseneck

The lamp features a 360° adjustable flexible gooseneck, allowing you to direct the light precisely where needed for reading, working, or studying.

- **Adjustment:** Gently bend and twist the gooseneck to position the lamp head at your desired angle and height.
- **Stability:** The flexible design maintains its position once adjusted.

360 FLEXIBLE GOOSENECK

The 360° rotatable neck easily adjusts the light to the desired angle



Figure 5.5.1: The 360° adjustable flexible gooseneck.

6. MAINTENANCE

- **Cleaning:** Disconnect the power before cleaning. Use a soft, dry cloth to wipe the lamp. Do not use abrasive cleaners or solvents.
- **Storage:** When not in use for extended periods, unplug the lamp and store it in a cool, dry place.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Lamp does not turn on.	No power supply or loose connection.	Ensure the USB cable is securely connected and the power adapter is plugged into a working outlet. Verify the power adapter meets 5V/3A or higher requirements.
Wireless charging is slow or not working.	Phone not aligned, phone case too thick, or insufficient power supply.	Ensure your phone is centered on the charging pad. Remove thick phone cases. Use a 5V/3A or higher power adapter.
Bluetooth speaker cannot connect or has poor sound.	Not in pairing mode, too far from device, or interference.	Ensure the lamp is in Bluetooth pairing mode. Move your device closer to the lamp. Reduce interference from other electronic devices.
Clock display is incorrect.	Time not set correctly.	Refer to the 'Digital Clock' section for instructions on how to set the time.

8. SPECIFICATIONS

Feature	Specification
Model Number	TD202406
Product Dimensions	9.8"D x 5.1"W x 4"H
Item Weight	1.3 Pounds
Material	Acrylonitrile Butadiene Styrene, Serpentine Tube
Light Source Type	LED
Color Temperatures	2700K (Warm), 4500K (Natural), 6500K (Cold)
Wireless Charging Output	15W
Bluetooth Version	5.0
Power Source	Corded Electric (Requires DC 5V/3A or higher adapter)
Certifications	FCC, CE, RoHS

9. WARRANTY AND SUPPORT

HEKIWAY offers a **36-month warranty** for this product. Additionally, a **90-day refund or replacement** policy is available.

For any questions or assistance regarding your desk lamp, please contact us via Amazon. We are committed to providing professional support and resolving any issues you may encounter.

