

[Manuals.plus](#) /

› [Zopsc](#) /

› Zopsc Mini DV Camera Camcorder Zopscunw3hgg8k-11 User Manual

Zopsc Zopscunw3hgg8k-11

Zopsc Mini DV Camera Camcorder User Manual

Model: Zopscunw3hgg8k-11

1. INTRODUCTION

This manual provides detailed instructions for the Zopsc Mini DV Camera Camcorder, model Zopscunw3hgg8k-11. Please read this manual thoroughly before using the device to ensure proper operation and to maximize its performance and lifespan.



Image 1.1: The Zopsc Mini DV Camera Camcorder, a compact device designed for portable video recording.

Key Features:

- **1080P High Definition Lens:** Captures clear videos and images.
- **1.44-inch Color Screen:** Provides real-time preview for accurate framing.
- **Integrated Flashlight:** Enhances visibility in low-light conditions.
- **Charging Case:** Extends battery life up to one week.
- **Automatic Loop Recording:** Ensures continuous recording by overwriting old files.
- **OTG Connection:** Facilitates direct transfer and viewing on Android 8.0 and above smartphones.



Image 1.2: Visual representation of the camera's core features including HD video, long battery life, HD screen, flash, 6 filters, and 512GB memory card support.

2. WHAT'S IN THE BOX

Carefully unpack the box and ensure all items are present and in good condition. If any items are missing or damaged, please contact customer support.

- Zopsc Mini DV Camera Camcorder
- Charging Case
- USB Charging Cable
- Wrist Strap



Image 2.1: The camera, charging case, USB cable, and wrist strap included in the product package.

3. SETUP

3.1 Charging the Battery

Before first use, fully charge the camera and its charging case. Connect the provided USB cable to the charging case and a power source. The camera can be charged by placing it inside the charging case.

- The camera has a 480mAh battery.
- The charging case extends the total battery life to approximately one week of use.

**Equipped with charging case makes
it to be used for up to 1 week**



Image 3.1: The camera being charged by its dedicated charging case, which provides extended power.

3.2 Inserting a Memory Card

The camera requires a memory card (up to 512GB supported) to store photos and videos. Locate the memory card slot, typically on the side or bottom of the camera. Insert the memory card with the contacts facing the correct direction until it clicks into place.

3.3 Powering On/Off

To power on the camera, press and hold the power button located on the top of the device. The 1.44-inch screen will illuminate. To power off, press and hold the power button again until the screen turns off.

4. OPERATING INSTRUCTIONS

4.1 Navigating the Menu

Use the buttons on the side of the camera to navigate through the menu options displayed on the 1.44-inch color screen. Options typically include Photo, Video, and Gallery modes.

Large 1.44 inch display

Real time preview

Better help you take clear photos



Image 4.1: The camera's 1.44-inch display screen showing a real-time preview, aiding in clear photo capture.

4.2 Shooting Modes

- **Photo Mode:** Select this mode to capture still images. Press the shutter button to take a photo.
- **Video Mode:** Select this mode to record videos. Press the record button to start and stop recording. The camera supports 1920x1080 resolution.
- **Gallery Mode:** View your captured photos and videos.

Vlog creation, recording a different perspective to record the bits and pieces of campus life



Image 4.2: The camera displaying a 1080P recording interface, suitable for capturing various moments.

4.3 Using the Flashlight

The camera is equipped with a flip-up flashlight. Activate the flashlight in low-light environments to improve photo and video quality. The flash can be reversed for different lighting needs.

Comes with a flash **The night photos are also clear**

The flash can be reversed, easy to control the low light indoor environment and night scenes, and you can shoot people and scenes



Image 4.3: The camera with its integrated flashlight flipped up, designed to illuminate subjects in dark settings.

4.4 Automatic Loop Recording

When the memory card is full, the camera's automatic loop recording feature will overwrite the oldest segmented video files to ensure continuous recording without manual intervention.

4.5 OTG Connection for Data Transfer

The camera supports OTG (On-The-Go) connection for instant transfer and viewing of photos and videos on compatible Android 8.0 and newer smartphones. Connect the camera to your smartphone using an appropriate OTG cable (not included) to access your media files directly.



Image 4.4: Illustrates the OTG instant sharing capability, allowing quick transfer of media to a smartphone.

4.6 Product Overview Video

Your browser does not support the video tag.

Video 4.1: A brief overview demonstrating the physical appearance and handling of the Zopsc Mini DV Camera Camcorder.

5. MAINTENANCE

5.1 Cleaning

- Use a soft, dry cloth to clean the camera body.
- For the lens, use a specialized lens cleaning cloth and solution to avoid scratches.
- Do not use harsh chemicals or abrasive materials.

5.2 Storage

- Store the camera in a cool, dry place away from direct sunlight and extreme temperatures.

- Remove the memory card if storing for extended periods.

6. TROUBLESHOOTING

6.1 Camera Not Powering On

- Ensure the battery is fully charged.
- Verify that the power button is pressed and held correctly.

6.2 Poor Image/Video Quality

- Check if the lens is clean and free from smudges.
- Ensure adequate lighting; use the built-in flashlight if necessary.
- Confirm the camera is set to 1080P resolution in settings.

6.3 Memory Card Error

- Ensure the memory card is inserted correctly.
- Try formatting the memory card (this will erase all data).
- Test with a different, compatible memory card.

7. SPECIFICATIONS

Powerful core




Image 7.1: An illustrative view of the camera's internal components, highlighting its powerful core processing unit.

Feature	Detail
Brand	Zopsc
Model Name	Zopscunw3hgg8k-11
Video Capture Resolution	1920x1080 (1080P)
Effective Still Resolution	7776000 Pixels
Screen Size	1.44 Inches (LCD screen)
Special Features	Built-In Flash, Automatic Loop Recording
Shooting Modes	Photo, Video, Gallery
File Format	MP4, JPEG
Battery Capacity	480mAh (Camera)

Feature	Detail
Battery Average Life	Up to 7 days (with charging case)
Memory Card Support	Up to 512GB
OTG Compatibility	Android 8.0 and systems
Water Resistance Level	Not Water Resistant
Color	Black

8. WARRANTY AND SUPPORT

Warranty information and specific customer support details are not provided in the product data. Please refer to the product packaging or the seller's website for warranty terms and contact information for support.

© 2026 Zopsc. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question