

Manuals.plus /

› Lanteso /

› Lanteso P3 PRO Wireless Earbuds User Manual

Lanteso P3 PRO

Lanteso P3 PRO Wireless Earbuds User Manual

Model: P3 PRO | Brand: Lanteso

INTRODUCTION

Thank you for choosing Lanteso P3 PRO Wireless Earbuds. This user manual provides detailed instructions on how to set up, operate, and maintain your earbuds to ensure optimal performance and longevity. Please read this manual carefully before using the product.

KEY FEATURES

- **Bluetooth 5.3 Technology:** Ensures a stable, dependable, and steady transmission for continuous music and calls with lower latency.
- **HiFi Stereo Sound:** Equipped with 10mm audio drivers for balanced and immersive sound performance.
- **Clear & Smooth Calls:** Built-in 4 microphones enhance call quality.
- **Smart Touch Control:** Directly control music playback, calls, and voice assistant with simple taps.
- **Extended Battery Life:** Up to 4 hours of listening time per earbud, and over 30 hours total with the portable charging case.
- **IPX5 Waterproof:** Designed to withstand sweat and light splashes, suitable for workouts and outdoor activities.
- **Lightweight & Comfortable Design:** Each earbud weighs only 3.1g, with three sizes of liquid silicone ear tips for a secure and comfortable fit.
- **Fast & Wireless Charging:** The charging case supports both Type-C fast charging and wireless charging.

PACKAGE CONTENTS

Please check the package for the following items:

- Lanteso P3 Pro Wireless Earbuds
- P3 Pro Charging Case
- Type-C Charging Cable
- User Manual (this document)
- Ear Caps (S/M/L sizes)

Superior Battery Life with Charging Case

Provides you with a concert-like experience no matter where you are



Image: Contents of the Lanteso P3 PRO Wireless Earbuds package, including earbuds, charging case, cable, manual, and ear tips.

PRODUCT OVERVIEW



Image: The Lanteso P3 PRO Wireless Earbuds resting in their open charging case, showcasing their sleek design and compact form factor.

Smart Touch Control

Directly controlled on the earbuds at your finger tips



Image: A close-up view of a single Lanteso P3 PRO earbud, highlighting the touch control area and various function icons (call, volume, play/pause, skip tracks).

Extra Long-Lasting Battery

More than 60 hrs of battery life with multiple additional charges in the case (Up to 4 hrs of listening time on one charge)



1 Hrs
Full Charge



60 Hrs
Charging case



4 Hrs
Play Time

Image: The Lanteso P3 PRO earbuds in their charging case, with visual indicators showing battery life: 1 hour for full earbud charge, 60 hours for charging case, and 4 hours play time.




Image: Diagram illustrating Bluetooth 5.3 technology and one-step pairing, emphasizing wider transmission range, more stable connection, and lower latency.



Image: Visual guide to the intuitive touch controls, showing icons for Play/Pause, Previous Song, Next Song, Hang Up, Answer Call, Activate Siri, Volume Up, and Volume Down.



Image: The earbuds and charging case shown alongside a laptop and smartphone, indicating stable Bluetooth 5.3 connection with Apple, Android, and Windows devices.

Your browser does not support the video tag.

Video: An official product video showcasing the Lanteso P3 Pro Wireless Earbuds, highlighting their features and design. This video is provided by the seller.

SETUP

1. Initial Charging

Before first use, fully charge the Lanteso P3 PRO earbuds and their charging case. Connect the provided Type-C charging cable to the charging port on the case and a power source. The indicator lights on the case will show the charging status. A full charge for the earbuds takes approximately 1 hour, and the charging case takes about 1 hour.



Image: The charging case connected via a Type-C cable, illustrating the fast charging capability. The image also shows "1 Hrs Charging Time" and "60 Hrs Standby Time".

2. Pairing with Your Device

1. Ensure the earbuds are in the charging case and the case lid is closed.
2. Open the charging case. The earbuds will automatically power on and enter pairing mode.
3. On your device (smartphone, tablet, laptop), enable Bluetooth and search for available devices.
4. Select "P3 Pro" from the list of found devices to connect.
5. Once connected, you will hear a confirmation tone, and the earbuds will be ready for use.

The earbuds feature one-step auto-pairing, meaning they will automatically connect to the last paired device when you open the charging case after the first successful pairing.

One-Step Auto Pairing

Auto-connect immediately when you open the charging case after first pairing



Image: Depicts the one-step auto-pairing process, showing the earbuds in their case and a smartphone screen indicating "P3 Pro" as a discoverable and connectable device.

OPERATING INSTRUCTIONS

The Lanteso P3 PRO earbuds feature intuitive touch controls on each earbud. Refer to the table below for common operations:

Function	Action
Play/Pause Music	Single tap on either earbud
Next Song	Double tap on the Right earbud
Previous Song	Double tap on the Left earbud
Answer/End Call	Single tap on either earbud

Function	Action
Reject Call	Long press on either earbud
Activate Voice Assistant (Siri, Google Assistant)	Triple tap on either earbud
Volume Up	Long press on the Right earbud
Volume Down	Long press on the Left earbud




Image: A woman using the Lanteso P3 PRO earbuds while working on a laptop, demonstrating the clear call functionality provided by the built-in microphones.

MAINTENANCE

- **Cleaning:** Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth. Do not use harsh chemicals or abrasive materials.

- **Water Resistance:** The earbuds are IPX5 waterproof, meaning they are resistant to sweat and light splashes. Do not submerge them in water or expose them to heavy rain. Dry them thoroughly before placing them back in the charging case.
- **Storage:** When not in use, store the earbuds in their charging case to protect them from dust and damage. Store in a cool, dry place.
- **Battery Care:** To prolong battery life, avoid fully discharging the earbuds and charging case frequently. Charge them regularly, even if not in constant use.

TROUBLESHOOTING

If you encounter any issues with your Lanteso P3 PRO earbuds, please refer to the following common solutions:

- **No Sound:**
 - Ensure earbuds are charged.
 - Check if earbuds are properly paired with your device.
 - Adjust volume on both your device and the earbuds.
 - Try re-pairing the earbuds.
- **Pairing Issues:**
 - Ensure Bluetooth is enabled on your device.
 - Make sure earbuds are in pairing mode (open case).
 - Forget "P3 Pro" from your device's Bluetooth list and try pairing again.
 - Move closer to your device (within 10 meters).
- **Charging Problems:**
 - Check the Type-C cable and charging adapter.
 - Ensure the charging contacts on the earbuds and case are clean and dry.
 - Try a different charging cable or power source.
- **Earbuds Not Syncing:**
 - Place both earbuds back into the charging case and close the lid.
 - Open the lid again to allow them to re-sync.

If the issue persists, please contact Lanteso customer support for further assistance.

SPECIFICATIONS

Feature	Detail
Model Name	P3 PRO
Connectivity Technology	Wireless (Bluetooth 5.3)
Bluetooth Range	10 Meters
Audio Driver Size	10 Millimeters
Control Type	Touch Control

Feature	Detail
Water Resistance Level	IPX5 Waterproof
Earbud Weight	3.1g (each)
Earbud Battery Life	4 Hours (listening time)
Total Battery Life (with case)	Up to 30 Hours
Charging Time (Earbuds)	1 Hour
Charging Time (Case)	1 Hour
Charging Port	Type-C
Compatible Devices	Cellphones, Laptops, Tablets (Android, iOS, Windows)
Item Weight (Total)	2.08 ounces
Package Dimensions	2.83 x 2.6 x 1.3 inches

WARRANTY & SUPPORT

Lanteso products come with a standard manufacturer's warranty. For specific warranty details, please refer to the warranty card included in your package or visit the official Lanteso website.

If you require technical support, have questions about your product, or need to claim warranty, please contact our customer service team:

- **Email:** support@lanteso.com (example email)
- **Website:** [Visit the Lanteso Store on Amazon](#)

Please have your product model number (P3 PRO) and purchase information ready when contacting support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0D66G8XMH>

More documents and user manuals: <https://manuals.plus/>