

[Manuals.plus](#) /

› [mingwear](#) /

› Women's Smartwatch 1.39 Inches, with Answer/Make Calls/Message Reminder/Step Tracker, with Activity Fitness Tracker Watch, for Android iPhone Devices (Pink)

mingwear 9b975afc-2623-4c20-88c0-6b3a13db7f6b

mingwear Women's Smartwatch Instruction Manual

Model: 9b975afc-2623-4c20-88c0-6b3a13db7f6b

1. INTRODUCTION

This manual provides essential information for the safe and efficient operation of your mingwear Women's Smartwatch. Please read this manual thoroughly before using the device and retain it for future reference.

The mingwear Women's Smartwatch is designed to integrate seamlessly with your daily life, offering features such as call answering, message reminders, activity tracking, and fitness monitoring. It is compatible with both Android and iPhone devices.



Image: The mingwear Women's Smartwatch in pink, showing the main watch face with the date and time (June 30, Friday 20), and a smaller inset image of the watch displaying an incoming call notification.

2. WHAT'S IN THE BOX

Upon opening the package, please verify that all components are present and in good condition:

- mingwear Women's Smartwatch (1 unit)
- Charging Cable (1 unit)
- User Manual (this document)

3. SETUP

3.1 Charging the Smartwatch

1. Connect the charging cable to the charging port on the back of the smartwatch.
2. Plug the other end of the charging cable into a standard USB power adapter (not included) or a computer's USB port.
3. Allow the smartwatch to charge fully before first use. A full charge typically takes approximately 2 hours. The battery icon on the screen will indicate charging status.

3.2 Pairing with Your Smartphone

To utilize all features of your smartwatch, it must be paired with your smartphone via Bluetooth.

1. **Download the App:** Scan the QR code provided in the packaging or search for the official mingwear app in your smartphone's app store (App Store for iOS, Google Play Store for Android). Install the application.
2. **Enable Bluetooth:** Ensure Bluetooth is enabled on your smartphone.
3. **Open the App:** Launch the mingwear app on your smartphone and follow the on-screen instructions to create an account or log in.
4. **Add Device:** Within the app, navigate to the "Add Device" or "Pair Device" section. The app will search for available smartwatches.
5. **Select Your Smartwatch:** From the list of found devices, select "mingwear Smartwatch" or the device name corresponding to your watch.
6. **Confirm Pairing:** A pairing request will appear on both your smartphone and the smartwatch. Confirm the pairing on both devices.
7. **Complete Setup:** Once paired, the app will guide you through initial settings such as personal profile, notification preferences, and health monitoring goals.

4. OPERATING YOUR SMARTWATCH

4.1 Basic Navigation

- **Touch Screen:** Swipe left/right, up/down to navigate through menus and features. Tap to select an option.
- **Side Button(s):** Press the side button(s) to wake the screen, return to the home screen, or access specific functions as configured in the app.

4.2 Key Features

- **Answer/Make Calls:** Once paired, you can answer incoming calls directly from your smartwatch. You can also initiate calls through the watch's dialer or contact list (requires phone to be within Bluetooth range).
- **Message Reminder:** Receive notifications for SMS messages, social media alerts, and other app notifications directly on your wrist.
- **Activity Tracking:** Monitors steps taken, distance covered, and calories burned throughout the day.
- **Fitness Tracker:** Includes various sports modes to track specific workouts (e.g., walking, running, cycling). Provides data such as heart rate, duration, and calories.
- **Sleep Monitoring:** Tracks sleep patterns, including deep sleep, light sleep, and awake times.
- **Heart Rate Monitoring:** Continuously monitors your heart rate.
- **IP67 Waterproof:** Suitable for daily use, such as washing hands or light rain. *Not recommended for swimming or showering.*
- **Music Control:** Control music playback on your smartphone (play, pause, skip tracks).
- **Weather Display:** Get real-time weather updates (requires app connection and location permissions).
- **Alarm Clock & Stopwatch:** Set alarms and use the stopwatch function directly from the watch.

5. MAINTENANCE

5.1 Cleaning Your Smartwatch

- Wipe the screen and watch body with a soft, lint-free cloth.
- For stubborn dirt, slightly dampen the cloth with water. Avoid using harsh chemicals or abrasive cleaners.
- Ensure the charging contacts on the back of the watch are clean and dry before charging.

5.2 Battery Care

- Charge the smartwatch regularly to maintain battery health.
- Avoid fully discharging the battery frequently.
- Store the watch in a cool, dry place if not used for extended periods.

5.3 Water Resistance

The smartwatch is rated IP67 waterproof. This means it is resistant to splashes, rain, and brief immersion in shallow water (up to 1 meter for 30 minutes). However, it is **not** suitable for:

- Swimming or diving
- Showering or bathing with hot water/steam
- Exposure to high-velocity water (e.g., water sports)

Water resistance is not a permanent condition and may diminish over time with normal wear and tear.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Smartwatch won't turn on.	Low battery.	Charge the smartwatch for at least 30 minutes.
Cannot pair with smartphone.	Bluetooth off; App not running; Watch not discoverable.	Ensure Bluetooth is on. Restart the app and smartwatch. Make sure the watch is in pairing mode.
Notifications not received.	App permissions; Notification settings; Bluetooth disconnected.	Check app notification permissions on your phone. Verify notification settings within the smartwatch app. Ensure Bluetooth connection is stable.
Activity data is inaccurate.	Improper wearing; Software glitch.	Ensure the watch is worn snugly on your wrist. Restart the smartwatch and app.

If the problem persists, please refer to the support section or contact customer service.

7. SPECIFICATIONS

Feature	Detail
---------	--------

Feature	Detail
Model Number	9b975afc-2623-4c20-88c0-6b3a13db7f6b
Brand	mingwear
Screen Size	1.82 inches (Standing screen display size)
Connectivity Technology	Bluetooth
Operating System	Android Wear 1.0
Special Feature	Activity Tracker
Battery Type	Lithium Ion (1 A battery required)
Water Resistance	IP67
Color	Pink
First Available Date	June 5, 2024

8. WARRANTY AND SUPPORT

For warranty information, please refer to the documentation included with your purchase or contact the retailer. General product support can be obtained through the mingwear official website or by contacting their customer service department.

Customer Service: Please refer to the contact information provided on the product packaging or the official mingwear website for support inquiries.

© 2024 mingwear. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0D66KFCMH>

More documents and user manuals: <https://manuals.plus/>