

[Manuals.plus](#) /

› [Lafocuse](#) /

› Lafocuse 12 Inch Solid Wood Silent Day of The Week Clock Instruction Manual

Lafocuse B0D66S312X

Lafocuse 12 Inch Solid Wood Silent Day of The Week Clock

Brand: Lafocuse | **Model:** B0D66S312X

INTRODUCTION

Thank you for purchasing the Lafocuse 12 Inch Solid Wood Silent Day of The Week Clock. This unique timepiece is designed to not only display the current time but also the day of the week, making it an ideal addition for any living space, especially for those who appreciate clear daily orientation. Crafted with a solid wood frame and featuring a silent, precise movement, this clock ensures a quiet and accurate timekeeping experience. Please read this manual carefully to ensure proper setup, operation, and maintenance of your new clock.

PRODUCT FEATURES

- **Day of the Week Display:** Features a unique red hand that indicates the current day of the week, helping you keep track of your schedule.
- **Silent Movement:** Equipped with a silent, non-ticking quartz movement for a peaceful environment, suitable for bedrooms, offices, and living rooms.
- **Solid Wood Frame:** Encased in a durable and aesthetically pleasing solid wood frame, each with its unique grain, adding a touch of natural elegance to your decor.
- **Clear and Easy-to-Read Dial:** The 12-inch diameter dial features large, clear numbers and day labels for excellent readability from a distance.
- **Battery Operated:** Requires one AA battery (not included) for convenient, cord-free operation.
- **Broad Application:** Suitable for various indoor settings including living rooms, kitchens, dining rooms, bedrooms, study rooms, offices, and more.



Figure 1: Front view of the Lafocuse Day of the Week Clock, showcasing its clear dial and solid wood frame.

SETUP INSTRUCTIONS

Follow these steps to set up your Lafocuse Day of the Week Clock:

1. **Insert Battery:** Locate the battery compartment on the back of the clock. Insert one AA battery (not included), ensuring the correct polarity (+/-).
2. **Set the Time:** Use the time setting dial (usually located on the clock mechanism at the back) to adjust the hour and minute hands to the current time. Rotate the dial clockwise until the correct time is displayed.
3. **Set the Day of the Week:** Use the day setting dial (usually located on the clock mechanism at the back). Rotate this dial until the red day-of-the-week hand points to the current day. It is recommended to set the day when the time is around 12:00 AM (midnight) to ensure the day changes correctly at the start of a new day.
4. **Mounting:** Choose a suitable location on a wall. The clock can be hung using the integrated hanging slot on the back.


Ensure it is securely mounted.

■ **Note:** The clock doesn't have a second hand, it needs at least 1 minute that you can see the black minute hand will move after installing a new battery.

1. Indicates hour

2. Indicates minute

3. Indicates **the day of the week**



4. Set the day of the week

5. Set the time

Figure 2: Rear view of the clock illustrating the battery compartment and the two setting dials for time and day of the week. The red hand indicates the day of the week.

OPERATING INSTRUCTIONS

Once set up, your Lafocus Day of the Week Clock operates continuously. The hour and minute hands will display the current time, while the distinct red hand will slowly advance throughout the day to indicate the current day of the week. The day changes automatically as the clock passes midnight.

- **Time Display:** The black hour and minute hands move in a standard clockwise direction.
- **Day Display:** The red hand points to the current day of the week. It completes one full rotation every seven days.
- **Silent Operation:** The clock's silent sweep movement ensures no ticking sounds, providing a quiet environment.



Figure 3: Detail of the clock face, highlighting the red hand indicating the day of the week.

MAINTENANCE

- **Cleaning:** To clean the clock, gently wipe the surface with a soft, dry cloth. Avoid using abrasive cleaners or solvents, as they may damage the finish.
- **Battery Replacement:** When the clock hands begin to slow down or stop, it's time to replace the AA battery. Always use a fresh, high-quality battery for optimal performance.
- **Environment:** Keep the clock away from direct sunlight, extreme temperatures, and high humidity to prevent damage to the wood and internal components.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Clock not working or hands stopped.	Dead or low battery; incorrect battery insertion.	Replace with a new AA battery, ensuring correct polarity.
Time is incorrect.	Time setting dial was not set accurately; battery low.	Re-adjust the time using the time setting dial. Replace battery if needed.
Day of the week is incorrect.	Day setting dial was not set accurately; day hand not synchronized with time.	Re-adjust the day using the day setting dial, ideally around midnight for proper synchronization.
Clock makes noise.	Not applicable, as this clock features a silent sweep movement.	If any noise is heard, contact customer support.

SPECIFICATIONS

- Brand:** Lafocuse
- Model:** B0D66S312X
- Display Type:** Analog
- Special Feature:** Shows day of the week, silent sweep movement, wood frame
- Product Dimensions:** 12"W x 12"H (Diameter: 12" / 30 cm)
- Power Source:** Battery Powered (1 x AA battery, not included)
- Material:** Wood (Frame Material: Wood)
- Color:** Brown
- Item Weight:** 1.72 pounds
- Mounting Type:** Wall Mount
- Operation Mode:** Electrical
- Manufacturer:** Quarebest
- Date First Available:** May 30, 2024

WARRANTY AND SUPPORT

The Lafocuse Day of the Week Clock comes with a**Three-Year Movement Assurance**. If the clock experiences any quality problems with its movement within 3 years from the date of purchase, please contact the manufacturer or seller for assistance.

For any questions, concerns, or technical support regarding your product, please refer to your purchase platform or contact Lafocuse customer service directly. Please have your model number (B0D66S312X) and purchase date ready when contacting support.

© 2024 Lafocuse. All rights reserved.
This manual is for informational purposes only. Product specifications are subject to change without notice.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question