

Manuals.plus /

› Solimpia /

› Solimpia HT-6228 Electric Lady Shaver User Manual

Solimpia HT-6228

Solimpia HT-6228 Electric Lady Shaver User Manual

Model: HT-6228 | Brand: Solimpia

1. IMPORTANT SAFETY INFORMATION

Please read all safety instructions carefully before using the Solimpia HT-6228 Electric Lady Shaver. Failure to follow these instructions may result in injury or damage to the device.

- **Water and Charging:** Always keep the shaver away from water while charging.
- **Operation While Charging:** Avoid using the shaver while it is plugged in.
- **Delicate Areas:** Be cautious when using the shaver on delicate areas to prevent cuts and skin irritation.
- **Cleaning:** Always clean the shaver after each use and allow it to dry completely before storing.
- **Submersion:** Do not submerge the shaver in water. The device is IPX6 waterproof for wet use and cleaning, but not for full submersion.
- **Power:** The shaver operates at 5 Watt-hours.

2. PRODUCT OVERVIEW

The Solimpia HT-6228 Electric Lady Shaver is designed for effective and comfortable hair removal across various body areas. It features a multi-blade system, ergonomic design, and convenient charging options.



Figure 2.1: Solimpia HT-6228 Electric Lady Shaver and included accessories.




Figure 2.2: LCD Battery Indicator and Power Button.

Key Features:

- **Multipurpose Shaving Head:** Features skincare blade teeth, a foil blade, and an ultra-thin cutting net for efficient hair removal.
- **Ergonomic Design:** Vertical design with a comfortable non-slip grip handle and a moving cutter head that adapts to body contours.
- **LCD Indicator:** Displays battery power percentage, indicating when charging is needed.
- **Built-in LED Light:** Automatically illuminates during operation to ensure no unwanted hairs are missed.
- **Wet & Dry Use:** IPX6 waterproof rating allows for safe use in the shower or bath, and easy cleaning under running water.
- **Dual Charging Options:** Supports USB charging and includes a cordless charging base for convenience and storage.

3. SETUP AND CHARGING

3.1 Initial Charge

Before first use, fully charge the shaver. A full charge takes approximately 1.5 hours and provides over 50 minutes of working time.

1. Connect the USB charging cable to the shaver or place the shaver on the charging base.
2. Connect the other end of the USB cable to a suitable USB power adapter (not included) or a computer USB port.
3. The LCD display will show the battery percentage increasing during charging.
4. Once the display shows 100%, the shaver is fully charged. Disconnect it from the power source.

FASTER CHARGING, LONGER RUNNING TIME



1.5 HOURS
CHARGING TIME



**MORE THAN
50
MINUTES**
RUNNING TIME



USB
CHARGING BASE



Figure 3.1: Charging the Solimpia HT-6228 Electric Lady Shaver.

3.2 Checking Battery Level

The LCD indicator on the shaver displays the current battery percentage, allowing you to monitor power levels and know when recharging is necessary.

4. OPERATING INSTRUCTIONS

4.1 General Usage

The Solimpia HT-6228 is suitable for removing hair from various body areas, including the back, arms, armpits, legs, and bikini area.




Figure 4.1: Shaver head components and recommended usage areas.

4.2 Wet and Dry Shaving

This shaver can be used for both wet and dry shaving. For wet shaving, you may use it with foam or gel in the shower or bath. For dry shaving, ensure your skin is clean and dry.



Figure 4.2: Wet and Dry Shaving with the Solimpia HT-6228.

4.3 Shaving Technique

- **For Longer Hair:** Apply the shaver against the direction of hair growth to quickly remove hair over larger areas.
- **For Shorter/Residual Hair:** Use the shaver vertically, moving it back and forth to effectively trim shorter or remaining hairs.



Figure 4.3: Recommended shaving techniques.

4.4 Built-in LED Light

The shaver includes a built-in LED light that automatically activates when the device is turned on. This light helps illuminate the skin, ensuring better visibility and preventing missed hairs, especially in less visible areas.

BUILT-IN LED LIGHT

THE ILLUMINATED PERSPECTIVE ENSURES
A MORE COMPREHENSIVE HAIR REMOVAL EXPERIENCE




Figure 4.4: Built-in LED light for enhanced visibility.

5. MAINTENANCE AND CLEANING

5.1 Cleaning the Shaver

Regular cleaning ensures optimal performance and hygiene. The shaver is fully washable (IPX6 waterproof).

1. Turn off the shaver and disconnect it from any charging source.
2. Rinse the shaver head and body under running water. You may use the included cleaning brush to remove any trapped hairs.
3. Ensure all hair residue is removed from the blades and foil.
4. Shake off excess water and allow the shaver to air dry completely before storing or recharging.

5.2 Storage

After cleaning and drying, store the shaver in a cool, dry place. The charging base can also be used for convenient

storage.

6. TROUBLESHOOTING

If you encounter any issues with your Solimpia HT-6228 Electric Lady Shaver, please refer to the following common solutions:

Problem	Possible Cause	Solution
Shaver does not turn on.	Low battery or no charge.	Charge the shaver for at least 1.5 hours. Check the LCD display for battery percentage.
Poor shaving performance.	Blades are clogged with hair or dull. Incorrect shaving technique.	Clean the shaver head thoroughly. Ensure you are using the correct shaving technique for hair length (refer to Section 4.3).
Skin irritation after shaving.	Sensitive skin. Shaver not clean. Dry shaving without proper preparation.	Ensure skin is clean before shaving. Consider wet shaving with foam or gel. Clean the shaver thoroughly after each use. If irritation persists, discontinue use.
Shaver not charging.	Loose connection. Faulty cable/adapter.	Ensure the USB cable is securely connected to both the shaver/base and the power source. Try a different USB cable or power adapter.

7. SPECIFICATIONS

Model Name	HT-6228
Brand	Solimpia
Power Source	Battery Powered
Battery Type	1 Lithium Ion battery (included)
Charging Time	Approx. 1.5 hours
Running Time	More than 50 minutes
Waterproof Rating	IPX6 (Washable, suitable for wet use)
Wattage	5 Watt-hours
Recommended Uses	Armpit, Arms, Back, Bikini, Leg
Special Features	Battery Indicator, Dry Shave, Ergonomic Design, Lighted, Low Noise, Wet Shave
Package Dimensions	8.27 x 3.94 x 2.8 inches
Item Weight	9 ounces

8. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation included with your purchase or contact Solimpia customer service directly. Contact details can typically be found on the product packaging or the official Solimpia

website.

Legal Disclaimer: Statements regarding dietary supplements have not been evaluated by the FDA and are not intended to diagnose, treat, cure, or prevent any disease or health condition. This product is a personal care appliance and not a dietary supplement.

© 2024 Solimpia. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question