

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [REWARD](#) /

› [REWARD Men's 44mm Square Case Quartz Chronograph Watch Instruction Manual](#)

REWARD RD831509M-C

REWARD Men's 44mm Square Case Quartz Chronograph Watch

INSTRUCTION MANUAL FOR MODEL RD831509M-C

Introduction

This manual provides essential information for the setup, operation, maintenance, and troubleshooting of your REWARD Men's 44mm Square Case Quartz Chronograph Watch, Model RD831509M-C. Please read these instructions carefully to ensure proper use and longevity of your timepiece.

Watch Components and Features

Your REWARD watch features a sophisticated design with multiple functions. Familiarize yourself with the key components:

Detailed Features

Bold color, effortless elegance on your wrist

30
Fashionable Dial



Luminous Display



Dust-free
Silicone Band



Metallic Square
Case



Image: Detailed diagram highlighting the 1/10 seconds dial, minute dial, seconds dial, calendar, luminous display, dust-free silicone band, and metallic square case.

- **Main Dial:** Displays hours, minutes, and seconds.
- **Chronograph Dials:** Includes a 1/10 seconds dial, minute dial, and seconds dial for stopwatch functionality.
- **Calendar Display:** Shows the current date.
- **Luminous Display:** Hands and markers glow in low light conditions for improved visibility.
- **Metallic Square Case:** Durable alloy case providing protection.
- **Silicone Band:** Comfortable and dust-free for daily wear.

Setup and Initial Adjustment

Before wearing your watch, you may need to set the time and date.



Image: Illustration of the watch's side controls, indicating the functions of the crown and push-buttons.

1. Setting the Time:

- Pull the crown (center knob) out to the furthest position.
- Rotate the crown to adjust the hour and minute hands to the correct time.
- Push the crown back in to its original position to start the watch.

2. Setting the Date:

- Pull the crown out to the first position (halfway).
- Rotate the crown to adjust the date.
- Push the crown back in to its original position.

3. Adjusting the Band:

The silicone band is designed for comfort. Adjust the buckle to fit securely but comfortably on your wrist. Ensure the watch is not too tight to allow for proper circulation.

Operating the Chronograph

Your watch is equipped with a chronograph function for measuring elapsed time.

1. **Start/Pause:** Press the top push-button (labeled "Start/Pause Button" in the diagram) to start the chronograph. Press it again to pause.
2. **Reset:** While the chronograph is paused, press the bottom push-button (labeled "Restart Button" in the diagram) to reset all chronograph hands to zero.

Water Resistance



Image: The watch partially submerged in water, illustrating its 30-meter water resistance. This level is suitable for daily activities like hand washing, car washing, and light splashing.

This watch is rated for 3ATM (30 meters) water resistance. This means it is suitable for everyday use and can withstand splashes, rain, and brief immersion in water, such as during hand washing or car washing. It is **not** suitable for swimming, diving, or showering with hot water, as steam can penetrate the seals.

Care and Maintenance

Proper care will help maintain the appearance and functionality of your watch.

- **Cleaning:** Wipe the watch case and band regularly with a soft, dry cloth. For the silicone band, a mild soap and water solution can be used, then rinse thoroughly and dry.
- **Mineral Glass:** The watch features mineral glass, which is scratch-resistant. However, avoid harsh impacts or abrasive materials to prevent damage.



Image: Close-up of the watch crystal, emphasizing its mineral glass construction for scratch resistance and clarity.

- **Temperature:** Avoid exposing the watch to extreme temperatures (hot or cold) or sudden temperature changes, as this can affect the movement and seals.
- **Chemicals:** Keep the watch away from solvents, detergents, perfumes, and cosmetics, which can damage the case, band, or seals.
- **Battery:** The watch uses a quartz movement powered by a battery. When the battery runs low, have it replaced by a qualified watch technician to ensure proper sealing and function.

Troubleshooting

If you encounter issues with your watch, refer to the following common solutions:

- **Watch Not Running:**
 - Check if the crown is fully pushed in.
 - The battery may need replacement. Consult a professional watch repair service.
- **Incorrect Time/Date:**
 - Refer to the "Setup and Initial Adjustment" section to correctly set the time and date.
- **Chronograph Not Resetting to Zero:**
 - Ensure the chronograph is paused before attempting to reset. If the issue persists, a professional adjustment may be required.
- **Water Inside Watch:**
 - If condensation or water appears inside the watch, immediately take it to a professional watch repair service. Do not attempt to open the watch yourself.

Specifications

Detailed specifications for your REWARD watch:

PARAMETER



REWARD

Model: RD831509M

Movement: Quartz

Case Material: Alloy

Water Resistance: 3ATM

Crystal Material: Mineral glass

Band Material: Silicone Band


Plating: Environmental Vacuum Plating




**Case Size
44 mm**



**Case Thickness
13 mm**



**Band Width
24*20 mm**



**Band length
240 mm**



**Watch Weight
95 g**

Attention: Due to manual measurements, the actual size of the product may be slightly different from the data we provide

Image: A graphic detailing the watch's technical specifications, including dimensions and materials.

Model Number	RD831509M-C
Movement	Quartz
Case Material	Alloy
Water Resistance	3 ATM (30 meters)
Crystal Material	Mineral Glass
Band Material	Silicone
Plating	Environmental Vacuum Plating
Case Size	44 mm
Case Thickness	13 mm

Band Width	24/20 mm
Band Length	240 mm
Watch Weight	95 grams

Warranty Information

Specific warranty details for your REWARD watch are typically provided with your purchase documentation or can be found on the official REWARD website. Please retain your proof of purchase for any warranty claims.

Customer Support

For further assistance, technical support, or inquiries regarding your REWARD watch, please contact the seller or visit the official REWARD store online:

[REWARD Official Store on Amazon](#)