

Bingo B0102

Bingo Keeppley Pokemon Mini Eevee Building Set

INSTRUCTION MANUAL

1. Introduction

Thank you for purchasing the Bingo Keeppley Pokemon Mini Eevee B0102 Building Set. This manual provides detailed instructions for assembly, operation, maintenance, and troubleshooting to ensure a safe and enjoyable experience. Please read this manual thoroughly before beginning assembly and keep it for future reference.

2. Safety Information

- **Recommended Age:** This product is suitable for ages 6 years and up.
- **Choking Hazard:** This set contains small parts. Not suitable for children under 3 years due to potential choking hazards.
- **Adult Supervision:** Adult supervision is recommended during assembly and play, especially for younger children.
- **Material Safety:** The building blocks are made from non-toxic plastic.
- **Proper Use:** Do not put parts in mouth or nose. Do not throw or misuse the blocks.

3. Package Contents

Carefully unpack the box and verify that all components are present. The package should contain:

- 63 x Building Block Pieces
- 1 x Instruction Booklet (this manual)

If any parts are missing or damaged, please contact customer support.




Image 1: The Bingo Keeppley Pokemon Mini Eevee B0102 Building Set packaging, showing the Poke Ball container and Eevee character.

4. Setup and Assembly

Follow these steps to assemble your Mini Eevee building set:

1. **Unpack Components:** Carefully remove all building blocks from their packaging.
2. **Organize Pieces:** Sort the blocks by color or shape to make assembly easier.
3. **Follow Diagrams:** Refer to the step-by-step diagrams provided in the instruction booklet. Each step will show which pieces to use and where to place them.
4. **Connect Firmly:** Ensure each block is firmly connected to the previous one to create a stable structure.
5. **Review:** After completing all steps, review your model to ensure all pieces are correctly placed according to the diagrams.

Note: If you encounter difficulty, re-examine the previous steps and diagrams. Do not force pieces together.

5. Operating

Once assembled, the Mini Eevee model is ready for display or imaginative play. This is a static model designed for creative interaction.

- **Display:** Place your completed Eevee model on a flat, stable surface.

- **Play:** Engage in imaginative play, creating stories and scenarios with your Eevee figure.
- **Handling:** Handle the model gently to prevent accidental disassembly.

6. Maintenance

Proper care will help maintain the condition of your building set.

- **Cleaning:** To clean the blocks or assembled model, gently wipe with a soft, dry cloth. For stubborn dirt, a slightly damp cloth can be used, followed by immediate drying. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** Store the building blocks or assembled model in a cool, dry place away from direct sunlight and extreme temperatures to prevent material degradation. Keep loose pieces in a container to avoid loss.
- **Disassembly:** If disassembling the model, do so carefully to avoid damaging the connection points of the blocks.

7. Troubleshooting

If you encounter any issues during assembly or use, refer to the following common solutions:

- **Missing Pieces:** Double-check the packaging and surrounding area. If a piece is genuinely missing, contact customer support with details of the missing part.
- **Difficulty Connecting Pieces:** Ensure the pieces are correctly oriented according to the instructions. Apply gentle, even pressure. Do not force pieces, as this can cause damage.
- **Model Instability:** Review the assembly steps to ensure all connections are firm and correct. Loose connections can lead to an unstable model.
- **Damaged Pieces:** If any pieces are damaged upon arrival, do not attempt to use them. Contact customer support for replacements.

8. Specifications

Feature	Detail
Model Number	B0102 (DF-KPLY-B0102)
Brand	Bingo Keeppley
Product Dimensions	11 x 8.5 x 11 cm
Item Weight	0.06 Kilograms (60 g)
Number of Pieces	63
Material	Plastic
Color	Multi
Recommended Age	6 - 10 years
Educational Objective	Analytical Skill
Special Features	Non Toxic

9. Warranty and Support

This product is manufactured by Bingo. For any questions, concerns, or support regarding missing parts or product defects, please refer to the contact information provided on the product packaging or the retailer's website where the product was purchased.

Please retain your proof of purchase for any warranty claims or support requests.

© 2026 Bingo. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question