



Manuals.plus /

- › **Bingo** /
- › Bingo Qman Pokemon Quest Building Blocks 73013 Instruction Manual

Bingo 73013

Bingo Qman Pokemon Quest Building Blocks 73013 Instruction Manual

Model: 73013 (DF-KPLY-73013)

INTRODUCTION

Welcome to the instruction manual for your Bingo Qman Pokemon Quest Building Blocks, Model 73013. This product is part of a popular series of collectible building block sets, featuring various Pokémon characters. Each blind box contains one random Pokémon character from the 3rd wave, designed for assembly and play. This manual provides essential information regarding the assembly, safe use, and maintenance of your building block set. Please read it carefully before beginning assembly and keep it for future reference.



Image: The packaging for the Bingo Qman Pokémon Quest Blind Box 3rd Wave, displaying several possible characters including Snorlax, Gengar, Pikachu, Geodude, Grimer, and Slowpoke. The box indicates "6+" for age and "73013 Season Three".

SAFETY INFORMATION

WARNING: CHOKING HAZARD - Small Parts. Not for children under 3 years.

This product is recommended for ages **6 years and up**. Adult supervision is recommended for younger children during assembly.

- Keep all packaging materials away from children to prevent suffocation.
- Ensure all small building block pieces are kept out of reach of infants and toddlers.
- Do not put any pieces in the mouth.
- Inspect pieces regularly for damage. Discard any broken or damaged pieces to prevent injury.

PACKAGE CONTENTS

Each Bingo Qman Pokémon Quest Blind Box (Model 73013) contains:

- One set of building block pieces for a single, randomly selected Pokémon character.
- One instruction sheet specific to the character included in the box.

Note: The specific character received is random and cannot be chosen. There are 8 different styles available in the 3rd wave.

SETUP AND ASSEMBLY

Follow these general steps to assemble your Bingo Qman Pokemon Quest Building Blocks. Refer to the specific instruction sheet included in your box for detailed, step-by-step guidance for your character.

1. **Unpack:** Carefully open the blind box and remove all building block pieces and the instruction sheet.
2. **Identify Pieces:** Lay out all pieces on a clean, flat surface. Compare them with the parts list or diagrams on your character's instruction sheet.
3. **Follow Instructions:** Begin assembly by following the numbered steps on the instruction sheet. Ensure pieces are firmly connected.
4. **Printed Graphics:** All character details, patterns, and graphics are pre-printed on the blocks, eliminating the need for stickers.
5. **Completion:** Assembly typically takes approximately 5-10 minutes, depending on the character and individual experience.



Image: A fully assembled Pikachu building block figure, showcasing its blocky design, black-tipped ears, and brown stripes on its back. The tail appears to be articulated.




Image: A fully assembled Magnemite building block figure, featuring a light blue body, a single eye, and red and blue magnets extending from its sides. Additional white blocks with black crosses are visible on its underside.

OPERATING (PLAY)

Once assembled, your Pokémon building block character is ready for display or imaginative play.

- **Display:** Place your assembled character on a shelf, desk, or any flat surface as a collectible item.
- **Play:** Engage in creative play scenarios. Some characters include movable wheels or articulated parts, allowing for dynamic posing and interaction.
- **Collection:** Collect all 8 styles from the 3rd wave to complete your Pokémon Quest series.

MAINTENANCE

To ensure the longevity and appearance of your building blocks, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the blocks gently with a soft, slightly damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these can damage the plastic or printed graphics.
- **Storage:** Store the assembled character or loose blocks in a clean, dry place away from direct sunlight and extreme temperatures. This helps prevent discoloration and material degradation.
- **Handling:** Handle the assembled character with care to prevent pieces from detaching.

TROUBLESHOOTING

If you encounter any issues during assembly or use, consider the following:

- **Missing Pieces:** If you believe a piece is missing, first double-check the packaging and your work area. If a piece is genuinely missing, please contact the retailer or manufacturer's customer support for assistance.

- **Difficulty Assembling:** Review the instruction sheet carefully. Ensure you are using the correct pieces for each step and that they are oriented correctly. Sometimes, a firm push is needed to connect pieces securely.
- **Loose Connections:** If pieces are not holding together, ensure they are fully pressed into place. Worn or damaged pieces may not connect properly and should be replaced if possible.

SPECIFICATIONS

Feature	Detail
Product Model Number	DF-KPLY-73013
Product Dimensions	8 x 8 x 8 cm
Product Weight	30 g
Material Type	Plastic
Recommended Age	6 - 10 years
Assembly Required	Yes
Batteries Required	No
Educational Objective	Engineering Skills
Number of Pieces (per box)	Varies by character (one character set per box)
Theme	Pokemon
Special Features	Randomly Selected Style, Includes Movable Wheels (for some characters)

WARRANTY AND SUPPORT

For any questions, concerns, or issues regarding your Bingo Qman Pokemon Quest Building Blocks, please contact the retailer where the product was purchased. Keep your proof of purchase for any warranty claims or support inquiries.

For general inquiries about Bingo products, please refer to the manufacturer's official website or contact their customer service department if available.