

Keeppley DF-KPLY-B0108

Keeppley Pokemon Charizard Building Toy

Model: DF-KPLY-B0108

Brand: Keeppley

1. INTRODUCTION

This instruction manual provides essential information for the assembly, operation, and maintenance of your Keeppley Pokemon Charizard Building Toy, Model DF-KPLY-B0108. Please read this manual carefully before beginning assembly to ensure correct usage and to maximize your enjoyment of the product.

This building toy brings the famous Charizard character to life. It features a highly interactive classic character figure once assembled.

2. WHAT'S IN THE BOX

Carefully unpack the contents and verify that all items are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Building Blocks for Charizard Figure
- Instruction Manual (this document)




Image: The product packaging for the Keeppley Pokémon Charizard Building Toy, showing the assembled Charizard figure and the Keeppley and Pokémon logos.

3. SAFETY INFORMATION

Please observe the following safety precautions:

- **Choking Hazard:** This product contains small parts and is not suitable for children under 3 years of age.
- **Recommended Age:** Suitable for ages 6 years and up.
- Keep packaging materials away from children to prevent suffocation.
- Do not put parts in mouth.
- Adult supervision is recommended during assembly and play.

4. SETUP AND ASSEMBLY

The Keeppley Pokémon Charizard Building Toy requires assembly. Follow the step-by-step instructions provided in the included assembly guide.

1. Open the product packaging and lay out all the building blocks on a clean, flat surface.

2. Refer to the separate assembly instruction booklet for detailed visual steps.
3. Carefully connect the blocks according to the diagrams, ensuring each piece is securely fitted.
4. Pay close attention to the orientation of each block to achieve the correct final structure.
5. Once all blocks are connected, verify the stability and completeness of the Charizard figure.



Image: Front view of the fully assembled Keeppley Pokemon Charizard figure, showcasing its detailed design and vibrant orange color.



Image: Side view of the fully assembled Keeppley Pokemon Charizard figure, highlighting its wings and tail details.

5. OPERATING INSTRUCTIONS

Once assembled, the Charizard figure is ready for interactive play.

- The figure is designed for manual operation and tabletop play.
- Pose the figure by gently adjusting its movable parts, such as wings or limbs, if applicable.
- Engage in imaginative play scenarios with your Charizard figure.
- No batteries are required for operation.

6. MAINTENANCE

To ensure the longevity of your building toy, follow these maintenance guidelines:

- **Cleaning:** Wipe the figure with a soft, dry cloth to remove dust. For stubborn dirt, use a slightly damp cloth and mild soap, then dry thoroughly. Do not immerse in water.
- **Storage:** Store the figure in a cool, dry place away from direct sunlight and extreme temperatures to prevent material degradation.
- **Handling:** Handle the figure gently to avoid accidental disassembly or damage to delicate parts.

7. TROUBLESHOOTING

If you encounter any issues with your Keeppley Pokemon Charizard Building Toy, refer to the following common solutions:

| Problem | Possible Cause | Solution |
|---------|----------------|----------|
|---------|----------------|----------|

| Problem | Possible Cause | Solution |
|---|--|--|
| Figure is unstable or falls apart easily. | Blocks not fully connected. Incorrect assembly step. | Review the assembly instructions and ensure all blocks are firmly pressed together. Reassemble any sections that appear loose. |
| Missing a specific building block. | Packaging error. Part lost during unpacking. | Carefully check all packaging materials. If still missing, contact customer support with proof of purchase. |
| Difficulty connecting blocks. | Incorrect orientation. Excess force applied. | Ensure blocks are oriented correctly as per instructions. Apply gentle, even pressure. Do not force pieces together. |

8. SPECIFICATIONS

| Feature | Detail |
|--------------------------|-----------------------|
| Brand Name | Keeppley |
| Model Name | DF-KPLY-B0108 |
| Animal Theme | Charizard |
| Main Theme | Animated Cartoon |
| Figure Toy Type | Action Figure |
| Color | Multi-color |
| Material | Plastic |
| Target Character | Charizard |
| Assembly Required | Yes |
| Minimum Manufacturer Age | 72 months (6 years) |
| Maximum Manufacturer Age | 120 months (10 years) |
| Unit Count | 1 Count |
| Country of Origin | China |
| Included Components | Instruction manual |
| Product Type Name | Building Blocks |
| Manufacturer | Sandy |
| Special Features | Interactive |
| Batteries Required | No |
| Play Activity Location | Tabletop |

| Feature | Detail |
|-----------------------------|----------------|
| Operation Mode | Manual |
| Power Source | Manual |
| Item Dimensions (L x W x H) | 23 x 23 x 6 cm |
| Scale | Mini |

9. WARRANTY AND SUPPORT

Warranty: This product is provided without warranty, as indicated by the manufacturer.

Customer Support: For any questions, missing parts, or assistance, please refer to the contact information provided on the product packaging or the retailer's website where the product was purchased.