



[Manuals.plus](#) /

> [Ariete](#) /

> Ariete 2846/01 Breakfast Kettle User Manual

Ariete 2846W

Ariete 2846/01 Breakfast Kettle User Manual

Model: 2846W

[Components](#) [Setup](#) [Operation](#) [Introduction](#) [Safety Instructions](#) [Product](#)
[Maintenance](#) [Troubleshooting](#) [Specifications](#) [Warranty & Support](#)

1. INTRODUCTION

Thank you for purchasing the Ariete 2846/01 Breakfast Kettle. This manual provides important information regarding the safe use, operation, and maintenance of your new appliance. Please read these instructions carefully before first use and keep them for future reference.

2. IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons, including the following:

- Read all instructions.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against fire, electric shock, and injury to persons, do not immerse cord, plugs, or kettle in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, or has been damaged in any manner. Return appliance to the nearest authorized service facility for examination, repair, or adjustment.
- The use of accessory attachments not recommended by the appliance manufacturer may result in fire, electric shock, or personal injury.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.

- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off," then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Scalding may occur if the lid is removed during the heating cycle.
- This appliance is for household use only.

3. PRODUCT COMPONENTS

Familiarize yourself with the parts of your Ariete Breakfast Kettle:

- **Lid:** Hinged lid for easy filling.
- **Handle:** Ergonomic handle for safe pouring.
- **Water Level Indicator:** Transparent window to view water volume.
- **Power Switch:** On/Off switch, often with an indicator light.
- **Spout with Filter:** Designed for smooth pouring and to catch limescale.
- **Heating Base:** Cordless base with power connection.
- **Kettle Body:** The main water reservoir.



Image 1: The Ariete 2846/01 Breakfast Kettle with its lid open, showing the interior and the water level markings. This view highlights the kettle's capacity and design.

4. SETUP AND FIRST USE

1. **Unpacking:** Carefully remove the kettle and all accessories from the packaging. Retain packaging for future storage or disposal.
2. **Cleaning:** Before first use, wipe the exterior of the kettle with a damp cloth. Fill the kettle with clean water to the MAX level, boil, and then discard the water. Repeat this process 2-3 times to remove any manufacturing residues.
3. **Placement:** Place the power base on a dry, flat, stable, and heat-resistant surface. Ensure the power cord is not dangling or in contact with hot surfaces.
4. **Power Connection:** Plug the power base into a suitable grounded electrical outlet.

5. OPERATING INSTRUCTIONS

1. **Filling the Kettle:** Open the lid and fill the kettle with the desired amount of fresh water. Do not fill below the MIN mark or above the MAX mark indicated on the water level indicator. Close the lid securely.
2. **Placing on Base:** Place the kettle firmly onto its power base.
3. **Switching On:** Press the ON/OFF switch (usually located on the handle or near the base). An indicator light will illuminate, signifying that the kettle is heating.
4. **Boiling:** The kettle will automatically switch off once the water has boiled. The indicator light will turn off.
5. **Pouring:** Carefully lift the kettle from its base and pour the hot water. Always pour slowly and steadily to avoid splashing.
6. **Re-boiling:** If the kettle has just boiled, allow a few moments for the internal thermostat to reset before attempting to re-boil.



Image 2: The Ariete 2846/01 Breakfast Kettle positioned next to two cups of tea, lemons, and cookies, illustrating its intended use for preparing hot beverages.

6. MAINTENANCE AND CLEANING

Regular cleaning and maintenance will prolong the life of your kettle.

6.1. Exterior Cleaning

- Always unplug the kettle and allow it to cool completely before cleaning.
- Wipe the exterior with a soft, damp cloth. Do not use abrasive cleaners or scouring pads.
- Never immerse the kettle body or power base in water or any other liquid.

6.2. Interior Cleaning and Descaling

Limescale can build up inside the kettle, especially in hard water areas. Descale regularly to maintain performance.

- **Vinegar Method:** Fill the kettle with 1 part white vinegar and 2 parts water. Bring to a boil and let it stand for several hours or overnight. Empty the kettle and rinse thoroughly several times with fresh water.
- **Citric Acid Method:** Dissolve 2 tablespoons of citric acid in 1 liter of water. Pour into the kettle, bring to a boil, and let it stand for 15-30 minutes. Empty and rinse thoroughly.
- **Commercial Descaler:** Follow the instructions provided with a suitable commercial descaling product.

6.3. Filter Cleaning

The removable filter in the spout helps prevent limescale from entering your cup. Clean it regularly.

1. Ensure the kettle is cool and unplugged.
2. Open the lid and carefully remove the filter from its slot in the spout.
3. Rinse the filter under running water and gently brush away any limescale deposits.
4. Reinsert the clean filter firmly into its original position.



Image 3: A hand demonstrating the removal of the anti-limescale filter from the spout of the Ariete 2846/01 Breakfast Kettle, essential for cleaning and maintenance.

7. TROUBLESHOOTING

Before contacting customer support, please refer to the following troubleshooting guide:

Problem	Possible Cause	Solution
Kettle does not heat up.	<ul style="list-style-type: none">• Kettle not properly seated on base.• No power to the outlet.• Power switch not pressed.	<ul style="list-style-type: none">• Ensure kettle is correctly placed on the base.• Check the power outlet and circuit breaker.• Press the ON/OFF switch firmly.
Kettle switches off before boiling.	<ul style="list-style-type: none">• Too much limescale buildup.• Kettle is empty or has insufficient water.	<ul style="list-style-type: none">• Descale the kettle (refer to Section 6.2).• Ensure water is filled between MIN and MAX levels.
Water tastes metallic or has particles.	<ul style="list-style-type: none">• New kettle residue.• Limescale buildup.	<ul style="list-style-type: none">• Perform initial cleaning (refer to Section 4).• Descale the kettle and clean the filter (refer to Section 6.2 and 6.3).

8. SPECIFICATIONS

Brand:	Ariete
Model Number:	2846W
Capacity:	1.7 Liters
Wattage:	2200 watts
Item Weight:	0.75 Kilograms
Container Type:	Kettle

9. WARRANTY AND CUSTOMER SUPPORT

This Ariete product is covered by a manufacturer's warranty. Please refer to the warranty card included with your purchase for specific terms and conditions, including the warranty period and coverage details. Keep your proof of purchase for warranty claims.

For technical assistance, spare parts, or warranty service, please contact Ariete customer support. Contact information can typically be found on the manufacturer's official website or on the warranty card.

Online Support: Visit the official [Ariete Store on Amazon](#) for product information and support resources.



