

[Manuals.plus](#) /

› [ELS PET](#) /

› ELS PET Dog Grooming Vacuum & Dryer Kit Instruction Manual

ELS PET B0D69JLJ8X

ELS PET Dog Grooming Vacuum & Dryer Kit - Instruction Manual

Model: B0D69JLJ8X

INTRODUCTION

Thank you for choosing the ELS PET Dog Grooming Vacuum & Dryer Kit. This comprehensive system is designed to simplify pet grooming at home, offering both vacuuming for shedding and drying capabilities. Please read this manual thoroughly before operating the device to ensure safe and efficient use.

IMPORTANT SAFETY INFORMATION

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and personal injury.

- Read all instructions before use.
- Keep the appliance away from water or other liquids.
- Do not operate with a damaged cord or plug.
- Unplug from outlet when not in use and before cleaning.
- Do not allow children to operate this appliance.
- Ensure pets are calm and comfortable during grooming.
- Use only manufacturer-recommended attachments.
- Do not block air openings.
- Store the appliance in a dry place.

PACKAGE CONTENTS

Verify that all items are present in your package:

- ELS PET Grooming Vacuum & Dryer Main Unit
- Deshedding Brush
- Electric Dog Clipper
- Flat Nozzle Head
- Cleaning Brush
- Hose
- Power Adapter
- User Manual (this document)



Image: The ELS PET Grooming Vacuum and Dryer Kit, showcasing the main unit, hose, and various grooming attachments including the deshedding brush, clipper, and nozzle heads.

PRODUCT OVERVIEW

The ELS PET Grooming Vacuum & Dryer Kit features a dual-channel design for separate drying and vacuuming functions, a large dust cup, and multiple grooming tools.

Main Unit Features:

- **Dual-Channel Function:** Dedicated channels for drying and vacuuming to prevent cross-contamination and optimize performance.
- **Smart Display:** For independent control of wind speed and temperature.
- **2.5L Dust Cup:** Large capacity for extended grooming sessions without frequent emptying.
- **Integrated Storage:** Compartment for organizing all accessories.

Included Attachments:

- **Deshedding Brush:** For removing loose hair and promoting a healthy coat.
- **Electric Dog Clipper:** For trimming and styling pet fur.
- **Flat Nozzle Head:** For vacuuming pet hair from surfaces like carpets and sofas.
- **Cleaning Brush:** For general cleaning and collecting stray hairs.



Dual-channel
Function



Unique Storage
Feature



4 Functions
in 1 Product



High
Efficiency



Independent
Control



Image: The ELS PET Grooming Vacuum and Dryer Kit positioned between a cat and a dog, illustrating its suitability for both animals.

SETUP INSTRUCTIONS

1. **Unpack:** Carefully remove all components from the packaging. Retain packaging for future storage or transport.
2. **Main Unit Placement:** Place the main unit on a stable, flat surface. Ensure adequate ventilation around the unit.
3. **Attach Hose:** Connect the flexible hose to the appropriate port on the main unit. Ensure it clicks securely into place.
4. **Select Attachment:** Choose the desired grooming tool (deshedding brush, clipper, flat nozzle, or cleaning brush) and attach it to the end of the hose.
5. **Power Connection:** Plug the power adapter into the main unit, then into a standard electrical outlet.

ELS PET

Pet Grooming Vacuum Kit




Image: An internal diagram illustrating the dual-channel function, showing separate airflows for vacuuming (Channel 1) and drying (Channel 2).

OPERATING INSTRUCTIONS

General Operation:

1. **Power On:** Press the power button on the main unit's smart display.
2. **Select Mode:** The device has two primary functions: vacuuming (for grooming/shedding) and drying. The system automatically switches channels based on the selected function.
3. **Adjust Settings:** Use the controls on the smart display to adjust wind speed (for drying) or suction level (for vacuuming), and temperature (for drying).

Grooming (Vacuum Function):

Use the deshedding brush, electric clipper, flat nozzle head, or cleaning brush with the vacuum function.

- Attach the desired grooming tool.
- Select a suitable suction level (3 levels available). Start with the lowest setting and increase as needed, observing your pet's comfort.
- Gently brush or clip your pet's fur. The vacuum will collect loose hair directly into the dust cup.
- For cleaning surfaces, use the flat nozzle head or cleaning brush to vacuum pet hair from carpets, sofas, or floors.

Unique Storage Feature



Image: A woman using the deshedding brush attachment on a dog, demonstrating the vacuum's ability to collect loose fur during grooming.

Drying Function:

After bathing your pet, use the drying function to quickly and comfortably dry their fur.

- Attach the dryer nozzle to the hose.
- Adjust the temperature within the range of 86°F-158°F (30°C-70°C).
- Adjust the wind speed (five positions available).
- Direct the airflow over your pet's fur, moving continuously to ensure even drying and prevent overheating.

Professional Pet Grooming Vacuum



Monthly
Clipper



Whenever
Vacuum



Image: A Golden Retriever being dried with the ELS PET grooming dryer attachment, showing the warm airflow.

MAINTENANCE AND CLEANING

Regular maintenance ensures optimal performance and longevity of your ELS PET Grooming Kit.

Emptying the Dust Cup:

1. Ensure the unit is powered off and unplugged.
2. Detach the dust cup from the main unit.
3. Open the dust cup and empty collected pet hair into a waste bin.
4. Clean the interior of the dust cup with a damp cloth if necessary. Ensure it is completely dry before reattaching.



Image: A visual representation of the large dust cup, indicating its capacity and ease of removal for emptying.

Cleaning Filters:

- Locate the filters within the dust cup assembly.
- Remove filters and gently tap them to dislodge trapped hair and dust.
- If washable, rinse under cool water. Allow to air dry completely before reinserting. Do not use detergents or hot water.

Cleaning Attachments:

- Remove any hair or debris from brushes and clipper blades using the provided cleaning brush.
- Wipe down attachments with a damp cloth.
- Store all attachments in the integrated storage box on the main unit.



Image: The ELS PET grooming kit with its top lid open, revealing the internal storage compartment designed to hold all accessories neatly.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Unit does not power on.	Not plugged in; power outlet issue; damaged cord.	Ensure power cord is securely plugged into a working outlet. Check for visible damage to the cord or plug.
Low suction power.	Dust cup full; clogged hose/attachment; dirty filter.	Empty the dust cup. Check hose and attachments for blockages. Clean or replace filters.
No or weak airflow (drying).	Hose/nozzle blocked; filter issue.	Check hose and dryer nozzle for obstructions. Ensure filters are clean and properly installed.
Unit is noisy.	Normal operation sound; internal blockage.	Some operational noise is normal. If noise is excessive or unusual, check for internal blockages or contact support.
Clipper not cutting effectively.	Blades dull; hair tangled in blades.	Clean clipper blades thoroughly. Consider blade replacement if dullness persists.

PRODUCT SPECIFICATIONS

- **Model:** B0D69JLJ8X
- **Brand:** ELS PET
- **Suction Power:** Up to 15000Pa
- **Dust Cup Capacity:** 2.5 Liters
- **Temperature Range (Drying):** 86°F - 158°F (30°C - 70°C)
- **Wind Speed Settings:** 5 levels
- **Suction Modes:** 3 levels
- **Power Source:** Corded Electric
- **Product Dimensions:** 11.81 x 7.09 x 16.57 inches
- **Weight:** 11.66 Pounds
- **Material:** Plastic
- **Color:** White

WARRANTY AND CUSTOMER SUPPORT

ELS PET products are manufactured to high-quality standards. For warranty information, technical support, or service inquiries, please refer to the warranty card included with your purchase or visit the official ELS PET website. Please have your model number (B0D69JLJ8X) and purchase date available when contacting support.

Online Support: [Visit the ELS PET Store on Amazon](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question