

[manuals.plus](#) /› [GRIFEMA](#) /› [GRIFEMA GB1054B Adjustable Laptop Stand User Manual](#)**GRIFEMA GB1054B**

GRIFEMA GB1054B Adjustable Laptop Stand User Manual

Model: GB1054B | Brand: GRIFEMA

1. INTRODUCTION

Thank you for choosing the GRIFEMA GB1054B Adjustable Laptop Stand. This product is designed to enhance your computing experience by providing an ergonomic setup, improved posture, and efficient heat dissipation for your device. This manual provides essential information for the proper setup, operation, and maintenance of your laptop stand.



Figure 1: GRIFEMA GB1054B Laptop Stand in use.

2. PRODUCT FEATURES

- **Ergonomic Design & Adjustable Angles:** Features 6 adjustable angle levels (10° to 40°) to achieve an optimal viewing height and angle, promoting better posture and reducing neck and back strain.

GRIFEMA
CALIDAD SUPERIOR

Foldable laptop stand



Figure 2: Illustration of the 6 adjustable height and angle settings for ergonomic use.

- **Portable & Foldable Design:** Lightweight (222g) and compact (255 x 44 x 20 mm when folded), making it easy to carry and store. Includes a carrying bag for convenience.



Figure 3: The laptop stand folded for portability and storage in its carrying bag.

- **Sturdy & Anti-Slip Construction:** Constructed from durable aluminum with a triangular support structure for enhanced stability. Equipped with anti-slip silicone pads on the top surface and feet to prevent sliding and protect your device from scratches.



Figure 4: Close-up of the anti-slip silicone pads and triangular structure for stability.

- **Efficient Heat Dissipation:** The open, hollow design allows for natural airflow around your laptop, preventing overheating during prolonged use.



Figure 5: Illustration of airflow beneath a laptop placed on the stand, demonstrating heat dissipation.

- **Universal Compatibility:** Compatible with laptops and tablets ranging from 10 to 17.3 inches, including popular brands like Mac, MacBook Pro, Microsoft Surface, and HP.

Figure 6: Examples of compatible laptops and tablets on the stand.

3. PACKAGE CONTENTS

Please check the package for the following items:

- GRIFEMA GB1054B Laptop Stand
- Carrying Bag

4. SETUP INSTRUCTIONS

The GRIFEMA GB1054B laptop stand is designed for quick and easy setup. No assembly is required.

1. Remove the laptop stand from its carrying bag.
2. Place the folded stand on a flat, stable surface.
3. Gently pull the two halves of the stand apart to unfold it into its 'X' shape.
4. Extend the support arms to their full length.
5. Adjust the angle to your desired ergonomic position (refer to Section 5 for operating instructions).




Figure 7: Visual guide for unfolding and preparing the laptop stand for use.

5. OPERATING INSTRUCTIONS

To adjust the angle of your laptop stand:

1. Ensure no device is placed on the stand before adjusting the angle.
2. Gently lift the support arms and move them to engage with the desired notch on the base. There are 6 available angle settings, ranging from 10° to 40°.
3. Once the desired angle is set, ensure both support arms are securely locked into corresponding notches.

4. Carefully place your laptop or tablet onto the stand, ensuring it rests securely against the front stoppers and on the silicone pads.

For optimal ergonomic benefits, position your screen so that the top edge is at or slightly below eye level.

6. MAINTENANCE

To ensure the longevity and proper function of your GRIFEMA GB1054B laptop stand:

- **Cleaning:** Wipe the stand with a soft, damp cloth. Avoid using abrasive cleaners or solvents that could damage the finish or silicone pads.
- **Storage:** When not in use, fold the stand and store it in its provided carrying bag to protect it from dust and scratches.
- **Inspection:** Periodically check the hinges and silicone pads for any signs of wear or damage.

7. TROUBLESHOOTING

If you encounter any issues with your laptop stand, please refer to the following common solutions:

- **Stand feels unstable:** Ensure the stand is fully unfolded and both support arms are securely engaged in the corresponding notches. Make sure it is placed on a flat, stable surface.
- **Laptop slides on the stand:** Verify that the anti-slip silicone pads are clean and intact. Ensure your laptop is placed correctly against the front stoppers.
- **Difficulty adjusting angle:** Remove the laptop from the stand before attempting to adjust the angle. Apply gentle, even pressure when moving the support arms.

8. SPECIFICATIONS

Brand	GRIFEMA
Model Number	GB1054B
Material	Aluminum
Color	Black
Adjustable Angles	6 levels (10° to 40°)
Compatible Devices	Laptops and Tablets (10 to 17.3 inches)
Folded Dimensions	255 x 44 x 20 mm
Net Weight	222 g
Special Features	Ergonomic, Foldable, Adjustable, Heat Dissipation, Anti-slip
Recommended Use	Office, Travel

9. WARRANTY AND SUPPORT

For warranty information or technical support, please contact the manufacturer, Ibergrif Griferias S.L, or your point of purchase. Please retain your proof of purchase for any warranty claims.

