

[Manuals.plus](#) /

› [Fastrack](#) /

› Fastrack Gambit Micromotor Analog Watch 3309NM01 User Manual

Fastrack 3309NM01

Fastrack Gambit Micromotor Analog Watch 3309NM01 User Manual

Model: 3309NM01

[Overview](#)

[Setup](#)

[Operating](#)

[Maintenance](#)

[Troubleshooting](#)

[Specifications](#)

[Warranty & Support](#)

1. PRODUCT OVERVIEW

The Fastrack Gambit Micromotor Analog Watch (Model 3309NM01) is a precision timepiece designed for reliability and style. It features an analog display with a grey dial and a durable stainless steel strap. This manual provides essential information for the proper use and care of your watch.



Figure 1: Front view of the Fastrack Gambit Micromotor Analog Watch.

2. INITIAL SETUP

2.1 Unboxing and Inspection

- Carefully remove the watch from its packaging.
- Inspect the watch for any visible damage or defects.
- Ensure all components, including the watch and any accompanying documentation, are present.

2.2 Adjusting the Strap

The stainless steel strap can be adjusted to fit your wrist. This typically requires specialized tools to remove or add links. It is recommended to have this procedure performed by a qualified jeweler or watch technician to prevent damage to the strap or watch case.



Figure 2: Angled view of the watch, highlighting the stainless steel strap.

2.3 Setting the Time

1. Locate the crown on the side of the watch case.
2. Pull the crown out to the first or second click position (refer to specific model instructions if multiple clicks are present for date/time).
3. Rotate the crown to adjust the hour and minute hands to the correct time.
4. Once the time is set, push the crown back into its original position to engage the movement.

3. OPERATING INSTRUCTIONS

3.1 Reading the Analog Display

The watch features a traditional analog display with hour, minute, and second hands. Some models may include additional sub-dials for specific functions such as 24-hour display or minute/hour indicators, as seen in the Micromotor design.



Figure 3: Detailed view of the watch dial, illustrating the micromotor design and sub-dials.

3.2 Water Resistance

This watch is rated for 50 meters (5 ATM) water resistance. This means it is suitable for everyday use and can withstand splashes, rain, and brief immersion in water. It is **not** suitable for swimming, diving, or showering with hot water, as steam and temperature changes can compromise the seals.

4. CARE AND MAINTENANCE

4.1 Cleaning Your Watch

- Wipe the watch case and strap regularly with a soft, dry cloth to remove dust and dirt.
- For stainless steel components, a slightly damp cloth can be used, followed by immediate drying.
- Avoid using harsh chemicals, solvents, or abrasive cleaners, as these can damage the watch's finish.

4.2 Battery Replacement

The watch is powered by a Lithium Polymer battery. When the battery life diminishes, the watch may stop or exhibit irregular timekeeping. Battery replacement should be performed by an authorized service center or a professional watch repairer to ensure proper sealing and functionality.



Figure 4: Rear view of the watch, showing the stainless steel case back where battery access is located.

4.3 Storage

When not in use, store your watch in a cool, dry place away from direct sunlight, extreme temperatures, and strong magnetic fields. Keeping it in its original box or a watch case can help protect it from scratches and impacts.

5. TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Watch stops or runs intermittently	Low battery; Impact or shock; Internal mechanism issue	Replace battery (professional service recommended); Avoid impacts; Contact service center
Condensation inside the crystal	Exposure to extreme temperature changes; Compromised water resistance seal	Avoid sudden temperature changes; Have seals checked by a professional
Time is incorrect	Crown not pushed in; Time not set correctly	Ensure crown is fully pushed in; Re-set the time as per instructions

If the problem persists after attempting these solutions, please contact Fastrack customer support or an authorized service center.

6. PRODUCT SPECIFICATIONS

Feature	Detail
Brand	Fastrack
Model Number	3309NM01
Display Type	Analog
Movement	Micromotor Quartz
Case Material	Stainless Steel
Strap Material	Stainless Steel
Water Resistance	50 Meters (5 ATM)
Power Source	Battery Powered
Battery Type	Lithium Polymer (1 required, included)
Product Dimensions	13 x 9 x 6 cm
Item Weight	250 g
Country of Origin	India

7. WARRANTY AND SUPPORT

7.1 Warranty Information

Fastrack watches typically come with a manufacturer's warranty covering defects in materials and workmanship. Please refer to the warranty card included with your purchase for specific terms, conditions, and duration. Keep your proof of purchase for warranty claims.

7.2 Customer Support

For any questions, service requests, or technical assistance, please contact Fastrack customer support. You can find contact details on the official Fastrack website or through the documentation provided with your watch.

Manufacturer: Titan Company Limited, Sipcot Industrial Complex, Hosur, Tamil Nadu - 635129, India.
For online support, visit the official [Fastrack Store on Amazon](#).

© 2025 Fastrack. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question