



[Manuals.plus](#) /

› [Fastrack](#) /

› Fastrack Gambit Micromotor Quartz Multifunction Watch NT3309QL01 User Manual

Fastrack NT3309QL01

Fastrack Gambit Micromotor Quartz Multifunction Watch User Manual

Model: NT3309QL01

1. INTRODUCTION

Thank you for choosing the Fastrack Gambit Micromotor Quartz Multifunction Watch. This manual provides essential information for the proper setup, operation, maintenance, and care of your new timepiece. Please read these instructions carefully to ensure optimal performance and longevity of your watch.



Image 1.1: Front view of the Fastrack Gambit Micromotor Quartz Multifunction Watch. This image displays the green dial with copper-tone accents and the brown leather strap.

2. PRODUCT OVERVIEW

The Fastrack Gambit watch is designed with a distinctive green dial, rose-gold tone case, and a comfortable brown leather strap. It features a micromotor quartz movement for precise timekeeping and includes functional sub-dials.

Key Features:

- **Eye-Catching Dial:** Green dial with copper-tone accents for a distinctive style.
- **Functional Display:** Includes minute and date sub-dials for convenience.
- **Premium Build:** Rose-gold tone case with durable construction.
- **Comfortable Fit:** Soft brown leather strap for all-day wear.
- **Water Resistance:** Rated for 50 meters (5 ATM).



**MAKE A
BOLD MOVE
WITH GAMBIT**

Image 2.1: Close-up view of the watch dial, illustrating the high-end 3D formed dial, micromotor technology, and the contrasting color elements.

3. SETUP

3.1 Unboxing

Carefully remove your watch from its packaging. Inspect the watch for any visible damage. Ensure all protective films are removed from the crystal and case back before wearing.

3.2 Setting Time and Date

Your Fastrack Gambit watch features a crown and potentially pushers for setting. Follow these general steps:

1. **Setting the Time:** Gently pull the crown (located on the side of the watch case) out to its outermost position. Rotate the crown to move the hour and minute hands until the correct time is displayed. Push the crown back in to its normal position to start the watch.
2. **Setting the Date:** Pull the crown out to the first click position (if applicable, otherwise use the outermost position). Rotate the crown (or use a dedicated pusher if present) to adjust the date in the date sub-dial. Once the correct date is set, push the crown back in. Avoid setting the date between 9 PM and 3 AM, as this can interfere with the date change mechanism.



Image 3.1: Side view of the watch, illustrating the crown and pushers used for setting time and date.

3.3 Strap Adjustment

The watch comes with a brown leather strap and a buckle clasp. Adjust the strap by selecting the appropriate hole for a comfortable and secure fit on your wrist. Ensure the watch is not too tight or too loose.

4. OPERATING YOUR WATCH

4.1 Reading the Time

The main dial displays hours and minutes using the central hands. The 'HR' marking on the dial indicates the primary hour display.

4.2 Using the Multifunction Sub-dials

- **Minute Sub-dial:** The sub-dial labeled 'MIN' (typically on the left side of the main dial) indicates minutes, possibly as part of a chronograph function or a specific time-tracking feature. Refer to the specific movement instructions if detailed chronograph operation is required.
- **Date Sub-dial:** The sub-dial displaying numbers up to 31 (typically on the right side of the main dial) indicates the current date. This sub-dial automatically advances daily.

4.3 Water Resistance

Your watch has a water resistance rating of 50 meters (5 ATM). This means it is suitable for short periods of recreational swimming, showering, or washing hands. It is **not** suitable for diving, snorkeling, or prolonged water activities. Avoid operating the crown or pushers when the watch is wet or submerged to prevent water ingress.

5. MAINTENANCE

5.1 Cleaning

Wipe your watch regularly with a soft, dry cloth to remove dust and dirt. For water-resistant watches, a slightly damp cloth can be used, followed by drying. Avoid using chemical cleaners, solvents, or abrasive materials, as these can damage the watch case, crystal, or strap.

5.2 Battery Replacement

This watch is powered by a quartz movement, which uses a battery. When the watch stops or the second hand starts skipping (if present), it indicates a low battery. Battery replacement should be performed by a qualified watch technician or an authorized service center to ensure proper sealing and water resistance.

5.3 Strap Care

The brown leather strap is durable but requires care. Avoid prolonged exposure to direct sunlight, extreme temperatures, and moisture, which can cause the leather to dry, crack, or discolor. Clean the strap with a soft, damp cloth and allow it to air dry naturally. Do not use harsh chemicals on the leather.

6. TROUBLESHOOTING

6.1 Watch Not Running

- Check if the crown is pushed all the way in. If it is pulled out, the watch will not run.
- The battery may be depleted. Refer to Section 5.2 for battery replacement.

6.2 Incorrect Time or Date

- Refer to Section 3.2 for instructions on how to correctly set the time and date.
- Ensure the crown is fully pushed in after setting to prevent accidental changes.

6.3 Water Inside the Watch

If you notice condensation or water inside the watch, immediately take it to an authorized service center. Do not attempt to open the watch yourself, as this will void the warranty and can cause further damage.

6.4 Other Issues

For any other issues not covered in this section, please contact Fastrack customer support or visit an authorized service center.

7. SPECIFICATIONS



Image 7.1: Side profile view of the watch, showcasing its thickness and case design.

Feature	Detail
Brand	Fastrack
Model Name	Gambit
Model Number	NT3309QL01
Display Type	Analog
Movement Type	Quartz
Power Source Type	Battery Powered
Water Resistance Depth	50 Metres (5 ATM)
Strap Type	Two Piece Strap
Clasp Type	Buckle

Feature	Detail
Band Material	Leather
Case Material	Metal
Crystal Material	Mineral Glass
Case Diameter	45 Millimetres
Band Width	25.95 Millimetres
Case Thickness	10.7 Millimetres
Band Colour	Brown
Dial Colour	Green
Item Weight	200 Grams
Country of Origin	India

8. WARRANTY INFORMATION

Your Fastrack Gambit watch comes with a **12-month manufacturer warranty** on manufacturing defects. This warranty covers defects in materials and workmanship under normal use.

How to Avail Warranty:

To avail warranty services, you only need to present your original purchase invoice at any authorized Titan Service Center. A separate warranty card is not required.

The warranty does not cover:

- Damage resulting from improper handling, lack of care, accidents, or normal wear and tear.
- Water damage if the watch was used beyond its specified water resistance limits or if the crown/pushers were operated while wet.
- Damage caused by unauthorized repairs or modifications.



Image 8.1: Back view of the watch, displaying the stainless steel case back and water resistance marking.

9. CUSTOMER SUPPORT

For further assistance, service-related queries, or warranty claims, please contact Fastrack customer support:

- **Toll-Free Number:** 1800-266-0123 (Available 10 AM to 7 PM, all days of the week)
- **Email:** customercare@titan.co.in
- **Manufacturer:** Titan Company Limited, Sipcot Industrial Complex, Hosur, Tamil Nadu - 635129, India

10. IMPORTANT SAFETY INFORMATION

- Keep the watch away from strong magnetic fields, as this can affect the accuracy of the quartz movement.
- Avoid exposing the watch to extreme temperatures (below 0°C or above 60°C) or sudden temperature changes.
- Do not attempt to open the watch case or replace the battery yourself, as this can compromise water resistance and void the warranty.

- If the watch crystal breaks, seek immediate professional repair to prevent injury or damage to the internal components.

© 2026 Fastrack. All rights reserved.