

[Manuals.plus](#) /

› [OLEVS](#) /

› OLEVS Watches Men Waterproof Luxury Big Face Mens Watch Stainless Steel Quartz Analog Dress Watches for Men Luminous Multifunction Man Watch Relojes De Hombre Black Band and Black Face

OLEVS SC-S-G2859GH-HH

OLEVS Men's Multifunction Quartz Watch User Manual

Model: SC-S-G2859GH-HH

Brand: OLEVS

INTRODUCTION

This manual provides comprehensive instructions for the OLEVS Men's Multifunction Quartz Watch (Model SC-S-G2859GH-HH). Designed for durability and style, this timepiece features a precise quartz movement, luminous hands, and multiple sub-dials for enhanced functionality. Please read this manual carefully to ensure proper use and maintenance of your watch.



Front view of the OLEVS Men's Multifunction Quartz Watch, showcasing its black dial, gold accents, and stainless steel band.

SETUP

1. Setting the Time and Date

1. **Pull out the crown:** Gently pull the crown (the knob on the side of the watch) to the first click position to adjust the date, or to the second click position to adjust the time.
2. **Adjust the date:** If in the first click position, turn the crown clockwise or counter-clockwise to set the desired date.
3. **Adjust the time:** If in the second click position, turn the crown to move the hour and minute hands to the correct time. Ensure to account for AM/PM if your watch has a 24-hour sub-dial or moon phase indicator.
4. **Push in the crown:** Once the time and date are set, push the crown back into its normal position to start the watch movement.

2. Adjusting the Watch Band

The stainless steel band can be adjusted for a comfortable fit. It is recommended to have a professional jeweler adjust the band by removing or adding links. A tool may be included for self-adjustment; refer to the specific instructions provided with your watch for details on using this tool.



The OLEVS watch worn on a wrist, demonstrating its fit and appearance.

OPERATING INSTRUCTIONS

1. Chronograph Function

The watch features a chronograph (stopwatch) function with dedicated sub-dials:

- **Chronograph Minute Hand:** Located at the 9 o'clock position.
- **Chronograph Second Dial:** Located at the 6 o'clock position.

To operate the chronograph:

1. **Start/Pause:** Press the top button on the side of the watch to start the chronograph. Press it again to pause.
2. **Reset:** Press the bottom button to reset the chronograph hands to zero.

2. 24-Hour Moon Phase Indicator

The sub-dial at the 3 o'clock position indicates the 24-hour cycle and moon phase. This indicator rotates with the main time, providing a visual representation of day/night and the moon's position.

3. Luminous Function

The hands and markers of the watch are equipped with a luminous material. To activate the luminous function, expose the watch to strong light (natural or artificial) for 30-40 seconds. The stored light energy will allow the watch to glow in low-light conditions, providing visibility at night.



Detailed view of the watch face, highlighting the chronograph minute hand, chronograph second dial, and 24-hour moon phase indicator.

Your browser does not support the video tag.

Official product video demonstrating the OLEVS Luxury All Black Watch for Men, showcasing its design, features, and quality. This video highlights the fashion style, high-quality movement, and exquisite workmanship of the watch.

MAINTENANCE

- **Cleaning:** Wipe the watch regularly with a soft, dry cloth to remove dust and smudges. For the stainless steel band, a slightly damp cloth can be used, followed by immediate drying.
- **Water Resistance:** This watch is water-resistant to 30 meters (100 feet). This means it is generally resistant to splashing or brief submersion, such as during hand washing or light rain. **It is not suitable for swimming, bathing, diving, or any prolonged water activities.** Avoid pressing buttons or pulling the crown while the watch is wet or submerged.
- **Temperature:** Avoid exposing the watch to extreme temperatures (hot or cold) or sudden temperature changes, as this can affect the movement and seals.
- **Chemicals:** Keep the watch away from chemicals such as solvents, detergents, perfumes, and cosmetics, which can damage the case, band, or seals.
- **Impact:** While durable, avoid strong impacts or shocks to the watch, as this can damage the internal components or the glass mirror.
- **Luminous Function:** The luminous material requires light exposure to glow. If the glow fades, simply expose it to light again.



The watch demonstrating its 30-meter water resistance by being submerged in a glass of water. Note: This is for illustrative purposes; avoid prolonged submersion.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Watch stops or loses time	Low battery; Crown not fully pushed in; Strong magnetic field exposure.	Replace battery (professional service recommended); Push crown fully in; Move away from magnetic sources.
Date does not change at midnight	Time set incorrectly (AM/PM issue).	Advance the time by 12 hours.
Chronograph hands do not reset to zero	Minor misalignment.	Consult a professional watch repair service for adjustment.
Condensation under crystal	Water ingress due to damaged seal or improper water exposure.	Immediately take to a professional watch repair service to prevent further damage.

If you encounter issues not listed here or if the suggested solutions do not resolve the problem, please contact OLEVS customer support or a certified watch repair technician.

SPECIFICATIONS

- Brand:** OLEVS
- Model Number:** SC-S-G2859GH-HH
- Movement:** Original Quartz Movement
- Mirror Material:** High hardness coated glass mirror
- Case Diameter:** 41 mm (1.6 inches)
- Case Thickness:** 11 mm (0.43 inches)
- Band Length:** 180 mm (7 inches) - adjustable

Watch Weight: 132 g (4.65 ounces)

Water Resistance: 30 Meters (100 Feet)

Clasp Type: Butterfly double buckle

Features: Luminous hands, Chronograph, 24-hour Moon Phase



A chart detailing the product parameters including dimensions, movement type, and water resistance.

WARRANTY AND SUPPORT

OLEVS watches are crafted with attention to quality. For specific warranty information, please refer to the warranty card included with your purchase or visit the official OLEVS website. If you require technical assistance or have questions regarding your watch, please contact OLEVS customer support through their official channels.

For more information, visit the [OLEVS Store on Amazon](#).

© 2025 OLEVS. All rights reserved.

This manual is for informational purposes only. Specifications are subject to change without notice.