ChooChoo SB2401-1TWL

ChooChoo 47-inch Farmhouse Console Table

Model: SB2401-1TWL

Brand: ChooChoo

Important Safety Information

Please read and understand all instructions and safety warnings before assembly and use of this product. Failure to follow these instructions may result in injury or product damage.

- Always assemble the cabinet according to the provided instructions.
- Keep the cabinet away from heat sources.
- Do not place heavy objects on the doors or drawers.
- Use caution when opening and closing the doors and drawers to prevent pinching.
- Always unplug and turn off any electrical appliances before cleaning the cabinet.
- Ensure all fasteners are securely tightened before use. Periodically check and re-tighten as needed.

Product Overview

The ChooChoo 47-inch Farmhouse Console Table (Model SB2401-1TWL) is a versatile furniture piece designed for living rooms, entryways, hallways, and dining areas. It features a soft white frame with a brown top, two drawers, and four doors concealing adjustable shelves, along with a slatted bottom shelf for additional storage or display.



Image: The ChooChoo 47-inch Farmhouse Console Table, showcasing its soft white frame, brown top, two drawers, and four cabinet doors with black handles. A slatted bottom shelf is visible.



Image: A diagram illustrating the dimensions of the console table: 47.2 inches (width), 13.8 inches (depth), and 33.5 inches (height).

Assembly Instructions

Assembly is required for this console table. It is recommended to have two people for assembly. Please ensure all parts are present before beginning.

1. Unpack and Identify Parts

Carefully unpack all components from the packaging. Lay them out on a clean, soft surface to prevent scratches. Refer to the included parts list and hardware diagram to identify each piece.

2. Frame Assembly

Begin by assembling the main frame of the console table. Attach the side panels to the top and bottom support beams using the provided fasteners. Do not overtighten screws until the entire frame is loosely assembled.

3. Drawer and Shelf Installation

Install the drawer slides into the designated slots. Assemble the drawers according to the photo directions, ensuring the bottom panel is correctly seated. Insert the adjustable shelves into the cabinet sections.

4. Door Attachment and Adjustment

Attach the hinges to the cabinet doors and then to the main frame. Once the doors are attached, adjust the hinges

to ensure proper alignment and smooth opening/closing. This may require minor adjustments to the screws on the hinges.

5. Final Tightening

Once all components are assembled and aligned, securely tighten all fasteners. Avoid overtightening to prevent damage to the wood. Place the console table in its desired location.

Your browser does not support the video tag.

Video: A detailed overview of the console table's features and potential assembly steps. This video provides visual guidance for understanding the product's construction and functionality.

Operating and Usage

This console table is designed for versatile use in various rooms of your home.

Storage Features

- **Drawers:** Two spacious drawers are located at the top for storing smaller items, keeping them organized and out of sight.
- **Cabinet Storage:** Four doors open to reveal interior storage space with adjustable shelves. These shelves can be repositioned to accommodate items of different heights, such as dishes, books, or decorative objects.
- **Bottom Slatted Shelf:** The decorative slatted bottom shelf is ideal for displaying larger items, storage baskets, or additional decor.

Recommended Applications

- **Entryway Table:** Place in your entryway to hold keys, mail, and other essentials.
- **Sofa Table:** Position behind a sofa for lamps, books, or decorative accents.
- **Buffet Sideboard:** Use in the dining room for serving dishes or storing dinnerware.
- **Coffee Bar:** Set up a coffee machine and accessories on the top surface, utilizing cabinet space for mugs and coffee supplies.
- **TV Stand:** Can function as a TV stand for smaller televisions, with storage for media devices.



Image: The console table positioned in an entryway, adorned with a lamp, mirror, and floral arrangement, demonstrating its use as a decorative and functional piece.



Image: The console table set up as a coffee bar, featuring a coffee machine, mugs, and storage items, highlighting its versatility.



Image: The console table with its drawers pulled out and cabinet doors open, revealing the interior storage space and adjustable shelves.

Maintenance and Care

Proper care will ensure the longevity and appearance of your console table.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these can damage the finish.
- **Spills:** Clean up spills immediately to prevent staining or damage to the wood.
- **Heat and Moisture:** Protect the top surface from direct heat and excessive moisture. Use coasters under drinks and hot pads under warm items.
- **Sunlight:** Avoid prolonged exposure to direct sunlight, which can cause fading or discoloration.
- **Fasteners:** Periodically check all screws and fasteners to ensure they remain tight. Re-tighten as necessary to maintain stability.

Troubleshooting

If you encounter any issues with your console table, refer to the following common solutions:

Problem	Possible Cause	Solution
Table is wobbly or unstable.	Fasteners are loose. Uneven floor.	Ensure all screws and bolts are securely tightened. Place shims under legs if the floor is uneven.
Drawers do not slide smoothly.	Drawer slides are misaligned or damaged.	Check that drawer slides are correctly installed and free of obstructions. Ensure drawers are assembled squarely.
Cabinet doors do not align or close properly.	Hinges require adjustment.	Adjust the screws on the hinges to align the doors. Refer to the assembly instructions for detailed hinge adjustment steps.
Missing or damaged parts.	Manufacturing defect or shipping damage.	Contact ChooChoo customer support for assistance.

Specifications

Feature	Detail
Brand	ChooChoo
Model Name	SB2401-1TWL
Color	Soft White & Brown
Product Dimensions	13.8"D x 47.2"W x 33.5"H
Material	Engineered Wood
Item Weight	61 Pounds
Mounting Type	Floor Mount
Number of Drawers	2
Number of Doors	4
Number of Shelves	2 (adjustable within cabinets)
Assembly Required	Yes
Room Type	Dining Room, Entryway, Hallway, Kitchen, Living Room

Warranty and Support

ChooChoo offers customer support for product inquiries and assistance.

- **Returns:** This product is eligible for 30-day easy returns. Please refer to your purchase platform's return policy for details.
- **Protection Plans:** Extended protection plans may be available for purchase. Check your retailer for options such as 2-Year or 3-Year Protection Plans.

- **Customer Support:** For any questions, missing parts, or issues not covered in this manual, please contact ChooChoo customer support through the retailer's platform or the official ChooChoo website.

© 2024 ChooChoo. All rights reserved.