## Manuals+

Q & A | Deep Search | Upload

### manuals.plus /

- > PELONIS /
- > PELONIS Oscillating Pedestal Fan with DC Motor, Remote Control, Voice Control, 9 Speeds, 3 Modes, Adjustable Height, 9 Hour Timer, White Ultra with LED Light User Manual

# PELONIS PFS10D0APWW

# **PELONIS Oscillating Pedestal Fan User Manual**

Brand: PELONIS | Model: PFS10D0APWW

### INTRODUCTION

The PELONIS Oscillating Pedestal Fan (Model PFS10D0APWW) is designed to provide flexible and efficient air circulation for your home or office. Featuring a quiet DC motor, remote control, voice control capabilities, and adjustable height, this smart fan offers enhanced comfort and convenience. Its omni-directional oscillation ensures wide area coverage, distributing air effectively throughout your space. The fan also includes a built-in dimmable LED light and a programmable timer for personalized use.





Figure 1: Main view of the PELONIS Oscillating Pedestal Fan with remote and smartphone app interface.

### **Key Features:**

- Omni-directional Oscillation: 120° horizontal and 105° vertical oscillation for comprehensive air distribution.
- **Ultra Quiet Operation:** Meticulously designed with a Brushless DC Motor and 7 Bionic seagull fan blades, operating at an extraordinary noise level of just 20dB.
- Smart Control: Voice control compatible with Alexa and Google, smartphone app control, and convenient remote control.
- **Multiple Speed & Modes:** 9 wind speeds and 3 energy-efficient modes (Normal, Sleep, Circulation) including a 1-touch circulating mode.
- Adjustable Height: Fan height can be adjusted from 50 to 53.5 inches.
- 9-Hour Programmable Timer: Set the fan to automatically turn off after a desired period.
- Built-in Dimmable LED Light: Adds functionality and ambiance.

## SETUP

Follow these steps to assemble your PELONIS Oscillating Pedestal Fan:

1. Unpack Components: Carefully remove all components from the packaging. Ensure all parts listed in the instruction

manual are present.

- 2. **Assemble the Base:** Attach the column pipe to the base bar. Secure it using the provided screw and screwdriver. The base is designed for stability.
- 3. Connect Fan Head: Insert the fan head assembly onto the top of the column pipe. Ensure it clicks securely into place.
- 4. **Adjust Height:** The fan's height can be adjusted by loosening the knob on the column pipe, extending or retracting the inner pole, and then tightening the knob to secure the desired height (from 50 to 53.5 inches).
- 5. **Insert Remote Batteries:** Open the battery compartment on the remote control and insert the two AAA batteries (included).
- 6. **Power Connection:** Connect the DC power adapter to the fan's power input port and then plug it into a standard electrical outlet.



Figure 2: The fan's adjustable height feature, allowing customization from 50 to 53.5 inches.

# **Setup Video Guide:**

# Your browser does not support the video tag.

Video 1: Official PELONIS guide demonstrating unboxing, assembly, and initial setup of the oscillating pedestal fan.

# **Control Panel:**

The intuitive control panel located on the fan's column allows for direct operation. It features buttons for power, timer, oscillation, and fan speed adjustments. The built-in display shows the current settings.




Figure 3: Close-up of the fan's control panel with illuminated display and touch buttons.

Use the included remote control for convenient operation from a distance. The remote mirrors the functions of the control panel, allowing you to power on/off, adjust speeds, change modes, control oscillation, and set the timer.




Figure 4: The compact remote control for the PELONIS fan, showing various function buttons.

# **Smartphone App & Voice Control:**

For ultimate convenience, download the PELONIS Smart Home app to control your fan from your smartphone. The app allows you to effortlessly switch modes, adjust oscillation angles and speeds, and check the device status. This fan is also compatible with voice assistants like Alexa and Google, enabling hands-free operation.



Figure 5: Demonstrates smartphone app control and voice command compatibility with the fan.

# **Modes and Speeds:**

- 9 Wind Speeds: Customize the airflow intensity to your preference.
- 3 Energy-Efficient Modes:
  - Normal Mode: Provides a consistent airflow at your selected speed.
  - Sleep Mode: Operates at a lower, quieter setting for undisturbed rest.

- Circulation Mode: Optimizes airflow for whole-room air circulation.
- 1-Touch Circulating Mode: Quickly activate optimal air circulation with a single touch.

#### Oscillation:

The fan offers omni-directional oscillation to ensure air reaches every corner of your room:

- 120° Horizontal Oscillation: Sweeps air across the room from side to side.
- 105° Vertical Oscillation: Moves air up and down, ensuring comprehensive coverage.
- The fan will automatically reset to its initial position after oscillation is turned off.

#### **Timer Function:**

Set the 9-hour programmable timer to automatically turn off the fan, conserving energy and providing convenience, especially during sleep.

### **Dimmable LED Light:**

The integrated LED light can be dimmed to provide ambient lighting, making the fan a versatile addition to any room.

### MAINTENANCE

Regular cleaning ensures optimal performance and longevity of your PELONIS fan.

- 1. Power Off and Unplug: Always ensure the fan is turned off and unplugged from the power outlet before cleaning.
- 2. **Clean Exterior:** Wipe the exterior surfaces of the fan with a soft, damp cloth. Avoid using abrasive cleaners or solvents that may damage the finish.
- 3. **Clean Fan Blades:** The fan blades can be easily accessed for cleaning. Follow the instructions in the detailed manual for removing the front grille and fan blades. Once removed, wipe the blades with a soft, damp cloth to remove dust and debris. Ensure they are completely dry before reassembling.
- 4. **Reassembly:** Reattach the fan blades and front grille securely.




Figure 6: Visual guide for effortless cleaning of the fan's internal components.

### **T**ROUBLESHOOTING

If you encounter issues with your PELONIS fan, refer to the following common troubleshooting tips:

### • Fan Not Turning On:

- Ensure the power cord is securely plugged into a working electrical outlet.
- Check if the power button on the control panel or remote is pressed.

### • Remote Control Not Working:

- Verify that the batteries in the remote control are correctly inserted and not depleted. Replace if necessary.
- Ensure there are no obstructions between the remote and the fan's sensor.

#### · Fan Not Oscillating:

- Press the oscillation button on the control panel or remote to activate the feature.
- Check for any physical obstructions preventing the fan head from moving.

# Weak Airflow:

- Increase the fan speed setting.
- Ensure the fan blades are clean and free from dust buildup (refer to Maintenance section).
- Position the fan in an open area, away from walls or furniture that might obstruct airflow.

#### • Voice Control Issues:

- Ensure the fan is properly connected to your Wi-Fi network and linked to your smart home assistant (Alexa/Google).
- Check your internet connection and the status of your smart home assistant.
- Verify that the voice commands are correctly phrased as per the app's instructions.

If the issue persists after trying these steps, please contact PELONIS customer support for further assistance.

# **SPECIFICATIONS**

Feature	Detail
Brand	PELONIS
Model Name	FS25C1L-PL (Item model number: PFS10D0APWW)
Color	White
Electric Fan Design	Pedestal Fan / Floor Fan
Power Source	AC/DC
Product Dimensions (D x W x H)	14.96"D x 14.96"W x 53.54"H
Adjustable Height	50 to 53.5 inches
Noise Level	20 dB (at lowest wind speed)
Wattage	25 watts
Voltage	24 Volts (DC)

Feature	Detail
Number of Blades	7 (Bionic Seagull Fan Blades)
Air Flow Capacity	850 Cubic Feet Per Minute (CFM)
Wind Speed	Up to 23 Feet Per Second
Number of Power Levels	9 Speeds
Control Method	Touchpad, Remote Control, Voice Control (Alexa, Google), Smartphone App
Oscillation	120° Horizontal, 105° Vertical
Timer	9-Hour Programmable Timer
Light Type	Dimmable LED Light (4000K, RA ≥ 95)
Item Weight	11.9 Pounds
Included Components	Remote (requires 2 AAA batteries)
Indoor/Outdoor Usage	Indoor
Manufacturer	Pelonis
UPC	810049711702

# WARRANTY AND SUPPORT

PELONIS stands behind the quality of its products. This fan typically comes with a manufacturer's warranty covering defects in materials and workmanship. For specific warranty details, please refer to the warranty card included in your product packaging or visit the official PELONIS website.

**Protection Plans:** Extended protection plans may be available for purchase to provide additional coverage beyond the standard manufacturer's warranty. These plans can offer peace of mind for longer periods.

- 3-Year Protection Plan
- 4-Year Protection Plan
- Complete Protect (monthly renewal option)

**Customer Support:** For technical assistance, troubleshooting not covered in this manual, or warranty claims, please contact PELONIS customer support. Contact information can typically be found in your product manual or on the official PELONIS website.

Visit the PELONIS Store for more products and information.

© 2025 PELONIS. All rights reserved.

# **Related Documents - PFS10D0APWW**

PELONIS Pedestal Fan Owner's Manual - Models PFS40A4BBB, PFS40A4BWW Comprehensive owner's manual for PELONIS 16-inch Pedestal Fans (PFS40A4BBB, PFS40A4BWW) with remote control, 7-hour timer, 3-speed settings, and adjustable height. Includes safety rules, installation, operation, servicing, and cleaning instructions. Also covers Lasko 18-inch Adjustable Performance Pedestal Fan Model 1820. PELONIS 16" Pedestal Remote Control Oscillating Stand Fan User Manual User manual for PELONIS 16-inch Pedestal Remote Control Oscillating Stand Fans, models PFS40A4BBB and PFS40A4BWW. Features include a 7-hour timer, 3-speed settings, and adjustable height, designed for home, office, and bedroom use. This guide covers safe operation, installation, usage instructions for the remote and fan body, user servicing, and cleaning. PELONIS 16" Pedestal Fan Owner's Manual | PFS40A4BBB, PFS40A4BWW Comprehensive owner's manual for the PELONIS 16-inch Pedestal Remote Control Oscillating Stand Up Fan (models PFS40A4BBB, PFS40A4BWW), featuring a 7-hour timer, 3-speed settings, and adjustable height. Includes safety rules, installation instructions, operation guide, user servicing, and cleaning procedures. PELONIS PFS45A5BBB and PFS40A4BBB Series Pedestal Stand Fan Owner's Manual Comprehensive owner's manual for PELONIS PFS45A5BBB, PFS40A4BBB, and PFS40A4BWW series pedestal stand fans, covering important safety instructions, installation, remote control and body operation, maintenance, cleaning, and user servicing for optimal performance and longevity. PELONIS Stand Fan Owner's Manual: PFS45A5BBB, PFS40A4BBB, PFS40A4BWW Discover the PELONIS Stand Fan Owner's Manual for models PFS45A5BBB, PFS40A4BBB, and PFS40A4BWW. This comprehensive guide covers installation, safe operation, remote control functions, LED display settings, 5-speed and 3-speed options, 7-hour timer, oscillation control, tilt adjustment, height adjustment, maintenance, cleaning, and user servicing instructions for these oscillating pedestal fans with LED displays and remote controls. PELONIS Tower and Pedestal Fan User Manual: Aromatherapy, Remote Control, and Oscillating Features Comprehensive user manual for PELONIS 42" Oscillating Tower Fan (PFT42A5BGB) with aromatherapy diffuser and 16" Pedestal Remote Control Oscillating Stand Up Fan (PFS40A4BBB, PFS40A4BWW). Includes safety precautions, assembly, operation, servicing, and maintenance

instructions for optimal use in home and office environments.