

Livoo DOD209

Livoo DOD209 Wireless Kettle User Manual

Model: DOD209

1. IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons, including the following:

- Read all instructions before use.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against fire, electric shock, and personal injury, do not immerse cord, plugs, or the appliance base in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner. Contact customer service for examination, repair, or adjustment.
- The use of accessory attachments not recommended by the appliance manufacturer may result in fire, electric shock, or personal injury.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off," then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Scalding may occur if the lid is removed during the brewing cycle.
- Ensure the lid is securely closed before operating.
- Do not overfill the kettle beyond the maximum fill line.

2. PRODUCT OVERVIEW

The Livoo DOD209 Wireless Kettle is an automatic tea maker designed for convenience and precision. It features a glass body, a stainless steel infuser, and a control panel with an LCD display for easy operation.

Components:

- Glass Kettle with Handle
- Power Base with Control Panel
- Lid
- Removable Stainless Steel Infuser



Image 1: The Livoo DOD209 Wireless Kettle, showing the glass body, handle, and the infuser basket containing tea.

3. SETUP AND FIRST USE

Unpacking:

Carefully remove all packaging materials and inspect the kettle for any damage. Keep packaging for future storage or disposal.

Initial Cleaning:

1. Before first use, fill the kettle with clean water up to the 'MAX WATER' line.
2. Boil the water without any tea leaves.
3. Discard the boiled water. Repeat this process 2-3 times to remove any manufacturing residues.
4. Wipe the exterior of the kettle and the power base with a damp cloth.

Assembly:

1. Place the power base on a stable, flat, and dry surface.
2. Ensure the kettle is empty and dry before placing it on the power base.
3. Insert the stainless steel infuser into the kettle, ensuring it is properly seated.
4. Place the lid securely on top of the kettle.



Image 2: Exploded view showing the kettle's lid, infuser, glass body, and power base, illustrating how components fit

together.

4. OPERATING INSTRUCTIONS

Filling the Kettle:

- Remove the kettle from the power base.
- Open the lid and fill the kettle with fresh, cold water. Observe the water level indicator.
- For tea, fill between 'MIN' (0.5L) and 'MAX TEA' (1.0L). For boiling water only, fill up to 'MAX WATER' (1.7L). Do not overfill.
- If making tea, add your desired amount of loose leaf tea into the stainless steel infuser.
- Close the lid securely and place the kettle back on the power base.

Using the Control Panel:



Image 3: Close-up of the Livoo DOD209 kettle's control panel with LCD display and various function buttons.

1. **Power On/Off:** Press the **ON/OFF** button to activate the kettle. The LCD display will illuminate.
2. **Select Tea Program:** Press the **Thé** (Tea) button to cycle through 5 preset tea programs (e.g., Green Tea, Black Tea, White Tea, Oolong, Infusion). The corresponding indicator light will illuminate.
3. **Adjust Infusion Mode:** Press the **Durée** (Duration) button to select one of 3 preset infusion modes (Fort/Strong, Moyen/Medium, Doux/Mild) or a customizable mode.
4. **Customizing Temperature and Time:** Use the **Up/Down arrows** next to 'TEMP' and 'BREW' on the LCD to manually adjust the desired water temperature and infusion duration.
5. **Delayed Start:** Press the **DÉPART DIFFÉRÉ** (Delayed Start) button and use the Up/Down arrows to set a specific time for the kettle to begin operation.

6. **Keep Warm Function:** After brewing, the kettle may automatically enter a keep warm mode, or you can activate it by pressing the **SSS** (Keep Warm) button. This maintains the water temperature for a set period.
7. **Start Brewing:** Once settings are selected, the kettle will automatically begin the heating and infusion process. The infuser will descend into the water, infuse, and then automatically rise.

5. MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and extends the lifespan of your kettle.

General Cleaning:

1. Always unplug the kettle from the power outlet and allow it to cool completely before cleaning.
2. Wipe the exterior of the kettle and the power base with a soft, damp cloth. Do not use abrasive cleaners or scouring pads.
3. Never immerse the power base or the kettle's electrical components in water or any other liquid.

Cleaning the Infuser:

- The stainless steel infuser is removable for easy cleaning.
- After each use, remove the infuser and rinse it under running water. Use a small brush if necessary to remove tea leaf residues.
- Ensure the infuser is completely dry before reassembling or storing.

Descaling:

Over time, mineral deposits (limescale) may build up inside the kettle, especially in hard water areas. Descaling is recommended periodically.

- Fill the kettle with a mixture of water and white vinegar (e.g., 1 part vinegar to 2 parts water) or a commercial descaling solution according to product instructions.
- Boil the solution.
- Let it soak for at least 30 minutes, or longer for heavy buildup.
- Discard the solution and rinse the kettle thoroughly with fresh water several times to remove any vinegar odor or descaling residue.

6. TROUBLESHOOTING

- **Kettle does not turn on or heat:**
 - Ensure the kettle is properly plugged into a working power outlet.
 - Check if the kettle is correctly placed on the power base.
 - Verify that the ON/OFF button has been pressed.
- **Infuser does not descend or rise automatically:**
 - Ensure the infuser is correctly assembled and not obstructed by tea leaves or other debris.
 - Check that the lid is securely closed.
 - If the issue persists, try restarting the brewing cycle.
- **Water tastes unusual:**
 - Perform the initial cleaning steps (boiling and discarding water) again.
 - Ensure the kettle is regularly descaled.

- **Kettle leaks:**
 - Do not overfill the kettle beyond the 'MAX WATER' line.
 - Ensure the lid is properly closed.

7. SPECIFICATIONS

Brand	Livoo
Model Number	DOD209
Color	Grey
Capacity	1.7 Liters
Power	1850-2200 Watts
Material	Glass
Dimensions (L x W x H)	21.5 x 16.3 x 28 cm
Item Weight	1.75 Kilograms
Special Features	Automatic infuser, delayed start, customizable programs/modes, keep warm function, LCD display
Country of Origin	China

8. WARRANTY AND SUPPORT

Information regarding specific warranty terms and conditions for the Livoo DOD209 kettle is not available in the provided product details.

For warranty claims, technical support, or inquiries about spare parts, please contact Livoo customer service directly or refer to the documentation included with your purchase.

Spare parts availability: Information unavailable.