

ZAY-F013

Generic ZAY-F013 Portable Waist Fan Instruction Manual

Model: ZAY-F013

1. INTRODUCTION

Thank you for purchasing the Generic ZAY-F013 Portable Waist Fan. This device is designed to provide personal cooling in various environments, offering convenience and comfort. Please read this manual thoroughly before using the product to ensure safe and optimal operation. Keep this manual for future reference.

1.1 Intended Use

The ZAY-F013 Portable Waist Fan is intended for personal cooling during outdoor activities, work, camping, hiking, or in any hot environment where a portable, hands-free cooling solution is desired. It is designed to be clipped onto clothing or a belt, directing airflow to the body.

1.2 Key Features

- **Bladeless Design:** Ensures safe operation and prevents hair or clothing from getting caught.
- **Dual Clamp System:** Allows for secure attachment to waistbands, belts, or other clothing.
- **Three Adjustable Speeds:** Customize airflow intensity for personal comfort.
- **Quiet Operation:** Designed for minimal noise, suitable for various settings.
- **Long Battery Life:** Up to 10 hours of continuous use on a single charge (4500mAh battery).
- **Compact and Portable:** Lightweight design for easy transport and wear.

2. SAFETY INSTRUCTIONS

Please observe the following safety precautions to prevent injury or damage to the device:

- Do not insert fingers or foreign objects into the fan's air inlet or outlet.
- Keep the device away from water or other liquids. Do not use in wet environments.
- Do not disassemble, repair, or modify the device yourself. Contact customer support for assistance.
- Keep out of reach of children and pets.
- Do not expose the device to extreme temperatures, direct sunlight, or open flames.
- Use only the provided charging cable or a certified equivalent.
- If the device exhibits unusual behavior, emits smoke, or has a strange odor, discontinue use immediately and disconnect the power source.

3. PACKAGE CONTENTS

Verify that all items are present in the package:

- 1 x Generic ZAY-F013 Portable Waist Fan
- 1 x USB Charging Cable
- 1 x User Manual

4. PRODUCT OVERVIEW

The Generic ZAY-F013 Portable Waist Fan is designed for efficient personal cooling. Its compact form factor and robust construction make it suitable for various activities.



Image: The ZAY-F013 Portable Waist Fan shown in various colors (black, green, white) alongside ice cubes and mint, illustrating its cooling purpose. The fan features a compact, rectangular design with an air outlet at the top and a clip mechanism.

The fan features a bladeless design for safety and a dense protective grid over the air intake. It is constructed from durable materials to withstand outdoor use.



**Compact and
portable**

Dense grid

Fine material



Image: A collage of three close-up images highlighting the fan's features: its compact and portable size, the dense protective grid over the air intake, and the fine material used in its construction, emphasizing durability and design.

5. SETUP AND WEARING

The ZAY-F013 fan offers versatile wearing options due to its dual-clamp design. Ensure the fan is securely attached before use.

5.1 Attaching the Fan

1. Identify the primary clip on the back of the fan and the secondary clip on the side.
2. For waist wear, slide the primary clip over your waistband or belt. The secondary clip can be used to secure the fan to an inner layer of clothing, preventing movement.
3. For chest wear (e.g., on a backpack strap), use the primary clip to attach it to the strap.

4. Ensure the air outlet is facing upwards or towards your body for optimal airflow.

Cool Clip Fan Under Shirt

cool down fast

long battery life

compact and portable

fine material



Image: A person demonstrating how to wear the ZAY-F013 fan. The fan is clipped to the waistband of pants, positioned discreetly under a shirt, with a visual representation of cool air flowing upwards from the fan.

5.2 Wearing Styles

The fan can be worn in several configurations to suit your activity and preference:

- **Chest Wear:** Clip to backpack straps or front of clothing.
- **Side-mounted Wear:** Clip to the side of a waistband or belt.
- **Back Wear:** Clip to the back of a waistband or belt.
- **Handheld:** Can be held directly for targeted cooling.



Chest Wear



Side-mounted Wear



Back Wear



Handheld

Image: A visual guide illustrating four common ways to use the ZAY-F013 fan: clipped to a backpack strap for chest wear, clipped to a waistband for side-mounted wear, clipped to the back of shorts for back wear, and held in hand for handheld use.

6. OPERATING INSTRUCTIONS

Follow these steps to operate your ZAY-F013 Portable Waist Fan:

6.1 Power On/Off

- To power on the fan, press and hold the power button located on the side of the device for approximately 2 seconds. The fan will start at the lowest speed setting.
- To power off the fan, press and hold the power button again for approximately 2 seconds.

6.2 Adjusting Fan Speed

The fan has three speed settings:

- **First Gear (Soft Wind):** Provides a gentle breeze. Press the power button once after turning on.
- **Second Gear (Natural Wind):** Offers a moderate airflow. Press the power button a second time.
- **Third Gear (Strong Wind):** Delivers maximum airflow. Press the power button a third time.
- Pressing the button a fourth time will cycle back to the first gear.

First gear Soft wind



Second gear Natural wind



Third gear Strong wind



Image: A series of three images depicting the ZAY-F013 fan's adjustable speed settings. Each image shows the fan emitting a different intensity of airflow, labeled as "First gear Soft wind," "Second gear Natural wind," and "Third gear Strong wind."

7. CHARGING

The ZAY-F013 Portable Waist Fan is equipped with a built-in 4500mAh rechargeable battery.

7.1 Charging Procedure

1. Locate the charging port on the side of the fan.
2. Connect the provided USB charging cable to the fan's charging port.

- 3. Connect the other end of the USB cable to a compatible USB power source (e.g., computer, wall adapter, power bank).
- 4. The indicator light will illuminate during charging. It will change color or turn off once fully charged. Refer to the specific indicator behavior on your device.

7.2 Battery Life

A full charge provides up to 10 hours of continuous operation, depending on the selected fan speed. Lower speeds consume less power and extend battery life.

8. MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your fan.

8.1 Cleaning

- Ensure the fan is turned off and disconnected from any power source before cleaning.
- Use a soft, dry cloth to wipe the exterior of the fan.
- For dust accumulation in the air inlet/outlet, use a soft brush or compressed air to gently clear it.
- Do not use abrasive cleaners, solvents, or immerse the fan in water.

8.2 Storage

When not in use for extended periods, store the fan in a cool, dry place, away from direct sunlight and extreme temperatures. It is recommended to charge the battery at least once every three months to maintain battery health.

9. TROUBLESHOOTING

If you encounter issues with your ZAY-F013 Portable Waist Fan, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Fan does not turn on.	Battery is depleted.	Charge the fan using the provided USB cable.
	Power button not pressed correctly.	Press and hold the power button for 2 seconds to turn on.
Weak airflow.	Fan is on the lowest speed setting.	Press the power button repeatedly to cycle through higher speed settings.
	Air inlet/outlet is obstructed.	Ensure no clothing or debris is blocking the fan's vents. Clean if necessary.
Fan stops unexpectedly.	Battery is low or depleted.	Recharge the fan.
Charging indicator not working.	Cable or power source issue.	Try a different USB cable or power adapter. Ensure connections are secure.

If the problem persists after trying these solutions, please contact customer support.

10. SPECIFICATIONS

Detailed technical specifications for the Generic ZAY-F013 Portable Waist Fan:

Feature	Detail
Model Name	ZAY-F013
Brand	Generic
Manufacturer	xiaowuyouping
Electric Fan Design	Wearable Fan
Power Source	Battery Powered
Battery Capacity	4500mAh
Operating Time	Up to 10 hours (depending on speed setting)
Number of Speeds	3
Product Dimensions (L x W x H)	3.5"D x 2.7"W x 3.5"H (approximately 9cm x 7cm x 9cm)
Item Weight	7.2 ounces (approximately 205g)
Wattage	5 watts
Voltage	5 Volts
Special Feature	Lightweight

Size

Weight: 205g/0.45lb



Image: A diagram illustrating the physical dimensions of the ZAY-F013 fan, showing its length, width, and height in both inches and centimeters, along with its weight in grams and pounds.

11. WARRANTY AND SUPPORT

This product comes with a standard manufacturer's warranty. For specific warranty details, please refer to the documentation included with your purchase or contact the seller directly.

If you have any questions, require technical assistance, or need to report an issue, please contact the seller or manufacturer through the platform where the product was purchased. Please have your model number (ZAY-F013) and purchase date ready when contacting support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question