

Logitech 920-012525

Logitech Slim Bluetooth Combo User Manual

Model: 920-012525

INTRODUCTION

This manual provides comprehensive instructions for the setup, operation, maintenance, and troubleshooting of your Logitech Slim Bluetooth Combo. This wireless keyboard and mouse combo is designed for quiet and portable use, offering customizable features and easy switching between multiple devices.

The combo includes a slim keyboard and a Pebble Mouse 2 M350s, both featuring Bluetooth connectivity for seamless integration with Windows, macOS, iPadOS, ChromeOS, and Android devices.

PACKAGE CONTENTS

- Logitech Slim Bluetooth Keyboard
- Logitech Pebble Mouse 2 M350s
- Batteries (pre-installed or included)
- User Documentation



Image: The Logitech Slim Bluetooth Combo, featuring a black keyboard and a matching black mouse.

SETUP

1. Battery Installation

The keyboard and mouse come with pre-installed batteries. If you need to replace them:

1. **Keyboard:** Locate the battery compartment on the underside of the keyboard. Open the cover, insert the required batteries (typically AAA), ensuring correct polarity, and close the cover. The keyboard battery life is approximately 3 years.
2. **Mouse:** Locate the battery compartment on the underside of the mouse. Open the cover, insert the required battery

(typically AA), ensuring correct polarity, and close the cover. The mouse battery life is approximately 2 years.

2. Powering On

1. **Keyboard:** Slide the power switch, usually located on the top right edge, to the 'ON' position.
2. **Mouse:** Slide the power switch, usually located on the underside, to the 'ON' position.

3. Bluetooth Pairing

The Logitech Slim Bluetooth Combo can connect to up to three devices simultaneously using Bluetooth Easy-Switch technology.

1. Activate Pairing Mode:

- **Keyboard:** Press and hold one of the Easy-Switch keys (F1, F2, or F3) for three seconds until the LED indicator above the key starts blinking rapidly. This indicates it's ready for pairing.
- **Mouse:** Press and hold the Easy-Switch button on the underside of the mouse for three seconds until the LED indicator starts blinking rapidly.

2. **Enable Bluetooth on Your Device:** On your computer, tablet, or smartphone, go to Bluetooth settings and ensure Bluetooth is enabled.
3. **Select Device:** In your device's Bluetooth settings, look for "Logitech Slim Keyboard" and "Logitech Pebble Mouse 2 M350s" in the list of available devices. Select each one to pair.
4. **Confirm Pairing:** Follow any on-screen prompts to complete the pairing process. The LED indicator on the keyboard/mouse will turn solid for a few seconds and then turn off, indicating successful pairing.

Repeat these steps for up to two additional devices using the other Easy-Switch keys (F2, F3) on the keyboard and the Easy-Switch button on the mouse.



Image: The Logitech Slim Bluetooth Combo available in multiple colors, showcasing its sleek design.

OPERATING INSTRUCTIONS

Switching Between Devices

To switch between paired devices:

- **Keyboard:** Press the Easy-Switch key (F1, F2, or F3) corresponding to the device you wish to use. The LED above the key will briefly light up to confirm the switch.

- **Mouse:** Press the Easy-Switch button on the underside of the mouse to cycle through paired devices. The LED will indicate the active channel.

Customizing Functions with Logi Options+ App

Enhance your experience by customizing the keyboard's Fn keys and the mouse's middle button using the Logi Options+ App. This application allows you to assign shortcuts for various functions and applications.

- **Download:** Visit the official Logitech website to download and install the Logi Options+ App.
- **Customization:** Open the app, select your Logitech Slim Bluetooth Combo, and follow the on-screen instructions to personalize key assignments and mouse button functions. This includes shortcuts for screen capture, search, voice dictation, emoji menu, and application-specific actions.



Image: Icon representing the Logi Options+ App, used for customizing keyboard and mouse functions.

Quiet Typing and Clicking

The keyboard features low-profile keys designed for quiet, laptop-like typing. The Pebble Mouse 2 M350s incorporates Silent Touch Technology, reducing click noise by 90% compared to standard mice, ensuring a quiet work environment.

MAINTENANCE

Cleaning

To maintain the performance and appearance of your combo:

- Use a soft, lint-free cloth slightly dampened with water or a mild, non-abrasive cleaner.
- Avoid spraying liquids directly onto the keyboard or mouse.
- Do not use harsh chemicals, solvents, or abrasive materials.
- For cleaning between keys, use compressed air.

Battery Replacement

Replace batteries when performance degrades or the low battery indicator (if present) illuminates. Refer to the "Battery Installation" section under Setup for detailed instructions.

Storage

When not in use for extended periods, turn off both the keyboard and mouse to conserve battery life. Store them in a cool, dry place away from direct sunlight and extreme temperatures.



Image: The Logitech Slim Bluetooth Combo being placed into a backpack, highlighting its portable and lightweight design.

TROUBLESHOOTING

Connection Issues

- **Device Not Connecting:**
 - Ensure the keyboard and mouse are powered on.
 - Check battery levels and replace if necessary.
 - Ensure Bluetooth is enabled on your host device.
 - Re-initiate pairing mode on the keyboard/mouse and re-pair with your device.
 - Try forgetting the device in your host device's Bluetooth settings and then re-pairing.
 - Ensure the keyboard/mouse is within the effective Bluetooth range (typically up to 10 meters).
- **Interference:**
 - Move the keyboard/mouse closer to your host device.
 - Avoid placing the devices near other wireless devices (e.g., Wi-Fi routers, cordless phones) that might cause interference.

Keyboard/Mouse Not Responding

- Check if the correct Easy-Switch channel is selected on both the keyboard and mouse for the active device.
- Restart your host device.
- If using Logi Options+ App, ensure it is running correctly and not causing conflicts.

Keys Not Working or Mouse Cursor Jumps

- Clean the keyboard keys or mouse sensor as described in the Maintenance section.
- Ensure the mouse is used on a suitable surface.

SPECIFICATIONS

Brand	Logitech
-------	----------

Model Number	920-012525
Connectivity Technology	Bluetooth
Compatible Operating Systems	Windows 10, 11 or later, macOS 11 or later, iPadOS 14 or later, Chrome OS, Android, Linux
Keyboard Battery Life	Up to 3 years (with included batteries)
Mouse Battery Life	Up to 2 years (with included batteries)
Special Features	Portable, Lightweight, Customizable Fn keys, Silent Touch Technology (mouse), Easy-Switch (up to 3 devices)
Color	Black
Item Weight	1.39 pounds (approx.)
Package Dimensions	12.24 x 9.45 x 1.3 inches (approx.)

WARRANTY AND SUPPORT

Logitech products typically come with a limited hardware warranty. For specific warranty details, please refer to the warranty information included with your product packaging or visit the official Logitech support website.

For technical support, FAQs, and driver downloads, please visit the Logitech support page:

[Logitech Support Website](#)

You can also find additional resources and community forums on the Logitech website.

