

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- > [Benibela](#) /
- > [Benibela 10.1-inch WiFi Digital Picture Frame User Manual](#)

Benibela 31

Benibela 10.1-inch WiFi Digital Picture Frame

USER MANUAL

1. Introduction

Thank you for choosing the Benibela 10.1-inch WiFi Digital Picture Frame. This device is designed to help you easily share and display your cherished photos and videos with family and friends, no matter where they are. With its intuitive touchscreen, ample storage, and seamless app integration, keeping memories alive has never been simpler. Please read this manual carefully to ensure proper setup and operation of your new digital picture frame.



The Benibela Digital Picture Frame in use, showcasing its ability to display photos and connect with a smartphone app for easy sharing.

2. Product Features

- **Instant Sharing via Vphoto App:** Seamlessly load photos and videos from your phone to the frame using the free VPhoto App. Add captions and control slideshows remotely.
- **Unlimited Cloud Storage & Multi-function:** When online, the frame provides unlimited cloud storage for uploading and downloading media without data usage. Features 32GB built-in memory with micro SD support, storing up to 80,000 photos.
- **Secure & Family-Friendly Sharing:** Only authorized users can access the frame through the encrypted VPhoto App, ensuring privacy. Invite family worldwide to share moments.
- **Immersive 10.1-inch IPS HD Touch Display:** Experience vivid clarity with a 1280*800 pixels touchscreen. Can be used as a digital art frame or for syncing calendars.
- **Videos with Sound:** Relive laughter and milestones with video playback. Upload clips via app or SD card.
- **Auto Rotation:** The frame supports automatic rotation for both portrait and landscape display, with a detachable stand.
- **Customizable Options:** Adjust play order, brightness, title display, and set sleep mode.

10.1" Wi-Fi Digital Photo Frame



Key features of the 10.1-inch Wi-Fi Digital Photo Frame, including connectivity, media types, and display modes.

3. Package Contents

- Benibela 10.1-inch WiFi Digital Picture Frame
- Detachable Stand
- Power Adapter
- User Manual (this document)

4. Setup Guide

4.1 Initial Setup

1. **Unpack the Frame:** Carefully remove the digital picture frame and all accessories from the packaging.
2. **Attach the Stand:** Insert the detachable stand into the slot on the back of the frame. Ensure it is securely in place for stable positioning in either landscape or portrait orientation.
3. **Connect Power:** Plug the power adapter into the DC port on the back of the frame, then plug the adapter into a wall outlet. The frame will automatically power on.



Various views of the digital picture frame, illustrating its versatile display options and connection points.



4.2 Connecting to Wi-Fi and Vphoto App

1. **Download Vphoto App:** On your smartphone or tablet, download the "Vphoto" app from the App Store (for iOS) or Google Play Store (for Android).
2. **Create Account:** Open the Vphoto app and create a new user account or log in if you already have one.
3. **Connect Frame to Wi-Fi:** On the digital picture frame, follow the on-screen prompts to connect to your home Wi-Fi network. You will need to select your network and enter the password.

4. **Bind Device:** In the Vphoto app, select the option to "Add Device" or "Bind Device." The frame will display a unique Frame ID or QR code. Enter this ID into the app or scan the QR code to link your frame to your Vphoto account.
5. **Start Sharing:** Once successfully bound, you can begin uploading photos and videos directly from your phone to the frame via the Vphoto app. You can also invite beloved ones to share photos and videos with your frame anytime, anywhere.

Operation way to for Instant WiFi Sharing

1. Download Vphoto App and Creat Account.
2. Add Device by Code and Connect your Frame with App Via Unique Frame ID.
3. Upload Photos & Videos via APP, Email, Micro SD car or USB Drive.
4. Invite you Beloved Ones to Share Photos and Videos Anywhere Anytime.



Step-by-step guide for instant WiFi sharing using the Vphoto app.

5. Operating Instructions

5.1 Navigating the Touchscreen

The Benibela Digital Picture Frame features an intuitive touchscreen display. You can interact with the frame by tapping, swiping, and pinching gestures, similar to a smartphone or tablet.

- **Swipe to Change Photos:** Swipe left or right on the screen to manually navigate through your photo collection.
- **Automatic Slideshow:** The frame will automatically play a slideshow of your uploaded photos and videos.
- **Access Settings:** Tap the screen once to reveal on-screen controls and access the settings menu. From here, you can adjust various options.



Touchscreen controls for managing photos, including rotation, scaling, zooming, and accessing settings.

5.2 Adjusting Settings

Within the settings menu, you can customize your frame's behavior:

- **Slideshow Interval:** Set the duration each photo or video is displayed.
- **Play Order:** Choose between sequential, random, or other display orders.
- **Brightness:** Adjust the screen brightness to suit your environment.
- **Sleep Mode:** Schedule the frame to turn off or enter a low-power state during specific hours (e.g., overnight).
- **Volume:** Control the audio volume for videos.
- **Wi-Fi Settings:** Reconnect to a different network or manage existing connections.

5.3 Sharing Photos and Videos

The primary method for sharing content is through the Vphoto app:

- **From App:** Open the Vphoto app, select the frame you wish to send to, choose photos or videos from your device's gallery, and tap "Send." You can also add captions.
- **Invite Others:** Share your frame's unique ID with family and friends. They can download the Vphoto app, add your frame using the ID, and then send their own photos and videos directly to your frame.
- **Email:** The frame supports receiving photos via email. Your frame will have a unique email address provided during setup. Send photos as attachments to this address.
- **Micro SD Card / USB Drive:** For local content, insert a micro SD card or USB drive into the designated port on the frame. The frame will detect the media and allow you to import content.



Input options on the digital picture frame, including TF Card, USB, and Type-C ports for local media transfer.

6. Maintenance

- **Cleaning the Screen:** Use a soft, lint-free cloth (microfiber is ideal) to gently wipe the screen. For stubborn smudges, slightly dampen the cloth with water or a screen-cleaning solution designed for electronics. Do not spray liquid directly onto the screen.
- **General Care:** Keep the frame away from direct sunlight, excessive heat, and moisture. Avoid dropping the frame or subjecting it to strong impacts.
- **Software Updates:** Periodically check for software updates through the frame's settings menu to ensure optimal performance and access to new features.

7. Troubleshooting

| Problem | Possible Cause | Solution |
|------------------------------|--|--|
| Frame does not turn on. | No power, faulty adapter. | Ensure power adapter is securely plugged into the frame and a working wall outlet. Try a different outlet. |
| Cannot connect to Wi-Fi. | Incorrect password, weak signal, network issue. | Double-check Wi-Fi password. Move frame closer to router. Restart router and frame. |
| Photos/videos not appearing. | Not uploaded correctly, frame not connected to internet, incorrect format. | Verify content was sent successfully via the Vphoto app. Ensure frame is connected to Wi-Fi. Check if file formats are supported (JPEG, PNG for photos; MP4 for videos). |
| Touchscreen unresponsive. | Temporary software glitch. | Restart the frame by unplugging and re-plugging the power adapter. |

8. Specifications

| Feature | Detail |
|--------------------------|-----------------------------|
| Screen Size | 10.1 Inches |
| Resolution | 1280 x 800 pixels (WXGA) |
| Internal Storage | 32GB |
| Compatible Devices | Smartphone (via Vphoto App) |
| Connectivity | Wi-Fi |
| External Storage Support | Micro SD Card, USB Drive |
| Product Dimensions | 8.64 x 11.83 x 0.99 inches |
| Item Weight | 1.98 pounds |
| Model Number | 31 |

Over 80000 Stored Photos

32GB Built-in Storage/Extended TF Card



10.1 Inch

XGA

1280*800



16:10



Touch Screen



Key specifications of the digital picture frame, highlighting its display and storage capabilities.

9. Warranty and Support

For product support, troubleshooting assistance, or warranty inquiries, please refer to the contact information provided with your purchase or visit the official Benibela website. Keep your purchase receipt as proof of purchase for any warranty claims.