

SPC Gravity 5 Pro

SPC Gravity 5 Pro 11-inch Tablet User Manual

Model: Gravity 5 Pro (97886128N)

1. INTRODUCTION

The SPC Gravity 5 Pro is an 11-inch tablet designed for a versatile user experience. It features an FHD+ InCell display, powered by an Octa-Core processor with 6GB RAM and 128GB of internal storage, expandable via Micro SD. The tablet runs on Android 14 and includes a 6000 mAh battery with 18W fast charging. Its metallic design offers both durability and a premium feel.

2. WHAT'S IN THE BOX

Upon opening your SPC Gravity 5 Pro tablet package, you should find the following items:

- SPC Gravity 5 Pro Tablet
- USB-C to USB-C Cable
- Quick Start Guide




Image: Unboxing the SPC Gravity 5 Pro tablet, revealing the device and its accessories.

3. PRODUCT OVERVIEW

3.1. Physical Features

The SPC Gravity 5 Pro tablet measures 16.7 cm (length) x 25.6 cm (width) x 0.8 cm (thickness) and weighs approximately 600g. It features a sleek metallic design for enhanced durability and aesthetics.



**Pantalla muy PRO
con resolución FULL HD+**

Image: Front view of the SPC Gravity 5 Pro tablet.



Image: Back view of the SPC Gravity 5 Pro tablet.

3.2. Ports and Buttons

- **USB-C Port:** Located on the side, used for charging and data transfer.
- **Volume Buttons:** Typically located on the top-left side, used to adjust audio levels.
- **Power Button:** Located near the volume buttons, used to turn the device on/off or lock/unlock the screen.
- **Audio Jack:** A 3.5mm audio jack is available for connecting headphones.

3.3. Cameras

The tablet is equipped with both front and rear cameras:

- **Rear Camera:** 5 MP resolution, capable of FHD 1080p video recording.
- **Front Camera:** Suitable for video calls and selfies.



Image: Close-up of the rear camera.

4. SETUP

4.1. Initial Power On

1. Press and hold the Power button located on the top-left side of the tablet until the screen lights up.
2. Follow the on-screen prompts to select your preferred language and region.
3. Connect to a Wi-Fi network to complete the setup process and access online features.

4.2. Charging the Tablet

Before first use, it is recommended to fully charge your tablet. Use the provided USB-C to USB-C cable and a compatible 18W fast charger (not included in the box).

1. Connect one end of the USB-C cable to the tablet's USB-C port.
2. Connect the other end of the USB-C cable to a compatible power adapter.
3. Plug the power adapter into a wall outlet. The charging indicator will appear on the screen.



Image: Tablet displaying fast charging status.

5. OPERATING INSTRUCTIONS

5.1. Android 14 Operating System

Your SPC Gravity 5 Pro tablet runs on Android 14, offering an optimized, secure, and customizable user experience. Navigate through the interface using touch gestures.

5.2. Display and Visual Experience

The 11-inch FHD+ InCell display provides crisp images and vibrant colors with a maximum resolution of 1920x1200 pixels and a 60Hz refresh rate. Enjoy multimedia content with clarity and detail.



Image: Tablet screen showcasing a vibrant display.

5.3. Performance and Storage

Equipped with an Octa-Core processor (Unisoc T606) and 6GB RAM, the tablet delivers smooth performance for demanding applications and multitasking. It comes with 128GB of internal storage, which can be expanded up to an additional 512GB using a microSD card.

5.4. Battery Life

The 6000 mAh battery provides up to 9-12 hours of autonomy, depending on usage. The 18W fast charging feature ensures quick recharging times.

5.5. Connectivity

The tablet supports Wi-Fi (802.11n standard) and Bluetooth for wireless connectivity. It also includes GPS functionality for location services.

6. MAINTENANCE

To ensure the longevity and optimal performance of your SPC Gravity 5 Pro tablet, follow these maintenance guidelines:

- **Cleaning:** Use a soft, lint-free cloth to clean the screen and body. Avoid abrasive materials or harsh chemicals.
- **Environmental Conditions:** Avoid exposing the tablet to extreme temperatures, direct sunlight, or high humidity.
- **Software Updates:** Keep your tablet's software updated to the latest version to benefit from performance improvements and security patches. While specific update guarantees are unknown, regular checks are recommended.

- **Storage Management:** Periodically clear unnecessary files and apps to maintain optimal performance.

7. TROUBLESHOOTING

Here are some common issues and their potential solutions:

- **Tablet not turning on:** Ensure the battery is charged. Connect the tablet to its charger and wait a few minutes before attempting to power it on again.
- **Wi-Fi connectivity issues:** Try restarting your Wi-Fi router and the tablet. If the issue persists, forget the network on your tablet and reconnect.
- **Audio problems:** Check the volume settings. If using headphones, ensure they are properly connected to the 3.5mm audio jack or USB-C port. Some users have reported inconsistent audio output when switching apps; restarting the app or tablet may resolve this.
- **Slow performance:** Close unused applications, clear cache, or free up storage space. If performance remains slow, consider a factory reset (see below).
- **Factory Reset:** If you experience persistent software issues, a factory reset can often resolve them.
Warning: A factory reset will erase all data on your tablet. Back up important data before proceeding. To perform a factory reset, go to Settings > System > Reset options > Erase all data (factory reset).

8. SPECIFICATIONS

Feature	Detail
Brand	SPC
Model Name	Gravity 5 Pro
Model Number	97886128N
Dimensions	16.7 x 25.6 x 0.8 cm
Weight	600 g
Screen Size	11 Inches
Display Type	IPS INCELL
Max Screen Resolution	1920x1200 Pixels (FHD+)
Refresh Rate	60 Hz
Max Screen Brightness	400 NITS
Operating System	Android 14
Processor Manufacturer	Unisoc (ARM)
Processor Model	T606 Octa Core
CPU Speed	1.6 GHz
RAM Size	6 GB
Internal Storage	128 GB

Feature	Detail
Expandable Storage	Up to 512 GB via microSD
Rear Camera Resolution	5 MP
Video Recording Resolution	FHD 1080p
Battery Capacity	6000 mAh (Lithium Ion)
Battery Life	Up to 12 Hours
Charging	18W Fast Charging
Connectivity	Bluetooth, Wi-Fi (802.11n), USB-C
Sensors	Proximity, Ambient Light, Gyroscope, GPS receiver
Audio Features	Stereo Speakers, 3.5mm Audio Jack

9. WARRANTY AND SUPPORT

The product warranty is provided according to current applicable law. For further support or inquiries, please refer to the official SPC website or contact their customer service.

You can visit the SPC brand store for more information: [SPC Brand Store](#)