

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [TORRAS](#) /

› [TORRAS Ultra-Magnetic Ostand Case for iPhone 16 Pro 6.3 inch - User Manual](#)

TORRAS iPhone 16 Pro 6.3 inch

TORRAS Ultra-Magnetic Ostand Case for iPhone 16 Pro 6.3 inch

User Instruction Manual

1. PRODUCT OVERVIEW

The TORRAS Ultra-Magnetic Ostand Case is designed to provide robust protection and enhanced functionality for your iPhone 16 Pro (6.3 inch with 3 cameras). It features a powerful magnetic attraction system, a flexible built-in kickstand, and military-grade drop protection, all within a slim, smudge-proof design.



Image 1: TORRAS Ultra-Magnetic Ostand Case for iPhone 16 Pro. This image shows the black case with the magnetic ring and kickstand.

2. SETUP

2.1. Installing the Case

1. Ensure your iPhone 16 Pro is clean and free of dust or debris.
2. Align the top edge of your iPhone with the top edge of the case, ensuring the camera cutouts match.
3. Gently press your iPhone into the case, starting from the top and working your way down, until all edges are securely fitted. The soft bumper edges facilitate easy installation.

2.2. Verifying Phone Model

To confirm compatibility, verify your iPhone model:

1. Open "Settings" on your iPhone.
2. Click "General".

3. Click "About".

4. Check the "Model Name" to ensure it is "iPhone 16 Pro".




Image 2: Visual guide for verifying iPhone model in settings.

3. OPERATING INSTRUCTIONS


3.1. Using the Flexible Kickstand

The built-in aerospace-grade aluminum kickstand allows for hands-free viewing. It has been tested for over 30,000 opening/closing cycles.

- **To deploy:** Gently pull the ring from the back of the case until it extends.
- **Adjusting angle:** The kickstand adjusts from 0° to 120°, supporting both vertical and horizontal viewing orientations.
- **To retract:** Fold the ring back into its flush position against the case.

Your browser does not support the video tag.

Video 1: Demonstration of the flexible kickstand's horizontal and vertical viewing capabilities, and magnetic attachment.



Öffnen Sie den "O"-Ring >>

Werden Sie Ihre unsichtbare dritte Hand

Image 3: The iPhone 16 Pro case with its kickstand extended, supporting the phone in a vertical position.

3.2. Magnetic Attraction (MagSafe Compatibility)

The case features patented Halbach Array and N56 neodymium magnets, providing strong magnetic force for secure attachment to MagSafe compatible accessories.

- Simply align your MagSafe charger, mount, or wallet with the magnetic ring on the back of the case for a secure connection.
- The case supports effective wireless charging without removal.

Your browser does not support the video tag.

Video 2: A short video demonstrating the strong magnetic attachment of the case to a metal surface.

Schließen Sie den "O"-Ring >>

Die stärkste Magnetkraft



Unterstützt jede Form der kabellosen Aufladung



Image 4: Illustration showing the magnetic strength of the TORRAS Ostand case compared to ordinary and official MagSafe products.

4. MAINTENANCE

4.1. Cleaning the Case

The case features Nano-coating Oleophobic technology to repel fingerprints, sweat, and stains. For cleaning:

- Wipe the case with a soft, damp cloth.
- Avoid using harsh chemicals or abrasive materials, as these may damage the coating.

4.2. General Care

- Avoid exposing the case to extreme temperatures or direct sunlight for prolonged periods.
- Periodically remove the case and clean your iPhone to prevent dust buildup.

5. TROUBLESHOOTING

5.1. Magnetic Accessories Not Attaching Securely

- Ensure the magnetic accessory is MagSafe compatible.
- Verify that the accessory is properly aligned with the magnetic ring on the case.
- Check for any debris or foreign objects between the case and the accessory that might interfere with the magnetic connection.

5.2. Wireless Charging Issues

- Confirm your wireless charger is MagSafe compatible and functioning correctly.
- Ensure the phone is centered on the wireless charger for optimal contact.
- Remove any other metallic objects or cards from between the phone and the charger.

5.3. Kickstand Stiffness or Looseness

- The kickstand is designed for durability and stability. If it feels unusually stiff or loose, ensure no foreign objects are obstructing its mechanism.
- Avoid applying excessive force when opening or closing the kickstand.

6. SPECIFICATIONS

Product Dimensions	6.3 x 3.15 x 0.39 inches
Item Weight	1.59 ounces
Material	Thermoplastic Polyurethane (TPU), TPE, Magnets, Metal Stand
Special Features	Adjustable Stand & Ring Holder, Compatible with MagSafe, Heavy Duty Protection, Slim Fit, Perfect Grip
Compatibility	iPhone 16 Pro (6.3 inch, 3 Cameras)

7. WARRANTY AND SUPPORT

TORRAS offers a lifetime customer support guarantee for this product. If you encounter any issues or require assistance, please contact TORRAS customer service.

- **Lifetime Customer Support:** Available 24/7 for any product-related inquiries.
- **365-Day Exchange:** TORRAS offers a 365-day exchange policy for product defects or damage.

For support, please visit the official TORRAS website or contact their customer service team directly.