Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- AKAI /
- > AKAI UltraBoom-60 Portable Bluetooth Speaker User Manual

AKAI UltraBoom-60 (HA-TS60)

AKAI UltraBoom-60 Portable Bluetooth Speaker User Manual

Model: UltraBoom-60 (HA-TS60)

1. Introduction

Thank you for purchasing the AKAI UltraBoom-60 Portable Bluetooth Speaker. This manual provides essential information for setting up, operating, and maintaining your speaker. Please read it carefully before use to ensure optimal performance and longevity of your device.



Image 1.1: The AKAI UltraBoom-60 speaker unit, wireless microphone, and remote control.

2. WHAT'S IN THE BOX

Carefully unpack your AKAI UltraBoom-60 and ensure all items are present:

- 1N Main Unit (AKAI UltraBoom-60 Speaker)
- 1N Remote Control
- 1N Wireless Microphone
- 1N User Manual/Warranty Card

3. PRODUCT FEATURES

The AKAI UltraBoom-60 is designed to deliver a powerful and versatile audio experience:

- 60W RMS Output: Delivers clear, powerful sound.
- Dual Speakers + Woofer: Features dual 3-inch mid-speakers and a 5.25-inch woofer for balanced audio and

deep bass.

- Multiple Connectivity: Supports Bluetooth 5.0, USB, AUX, and FM radio.
- Karaoke Ready: Includes a dedicated microphone input and a wireless microphone for vocal performances.
- EQ Modes: Customize your sound with various equalizer presets (Pop, Rock, Jazz, Classical).
- Dynamic LED Lights: Built-in multi-color LED lights enhance the listening experience.
- Remote Control: Full control over functions from a distance.
- Portable Design: Compact and easy to transport for indoor and outdoor use.
- Durable Construction: Features a wooden cabinet for enhanced audio quality and durability.



Image 3.1: Overview of the AKAI UltraBoom-60's key features.

4. SETUP INSTRUCTIONS

4.1 Power Connection

- 1. Place the speaker on a stable, flat surface.
- 2. Connect the power cord to the speaker's power input.

3. Plug the other end of the power cord into a standard 220V AC power outlet.

4.2 Wireless Microphone Setup

- 1. Insert batteries into the wireless microphone (batteries not included).
- 2. Turn on the microphone using its power switch.
- 3. The microphone should automatically connect to the speaker. Adjust microphone volume using the dedicated control on the speaker or remote.

5. OPERATING INSTRUCTIONS

5.1 Power On/Off

Press the Power button on the speaker's control panel or the remote control to turn the unit on or off.

5.2 Source Selection

Press the 'MODE' button on the speaker or remote to cycle through available input sources: Bluetooth, USB, AUX, and FM Radio.



Image 5.1: The speaker's control panel for source selection and volume adjustments.

5.3 Bluetooth Pairing

- 1. Select Bluetooth mode on the speaker. The display will indicate 'BT' or a similar pairing status.
- 2. Enable Bluetooth on your smartphone, tablet, or other device.
- 3. Search for 'AKAI UltraBoom-60' in your device's Bluetooth list and select it to pair.
- 4. Once paired, the speaker will confirm the connection, and you can play audio wirelessly.

5.4 USB Playback

- 1. Insert a USB drive containing MP3 audio files into the USB port.
- 2. Select USB mode on the speaker.
- 3. Playback will begin automatically. Use the remote or control panel to navigate tracks and adjust volume.

5.5 AUX Input

1. Connect an audio device (e.g., TV, PC, smartphone) to the speaker's AUX input using a 3.5mm audio cable (not included).

- 2. Select AUX mode on the speaker.
- 3. Audio from your connected device will play through the speaker.

5.6 FM Radio

- 1. Select FM mode on the speaker.
- 2. Press the 'Play/Pause' button to initiate an automatic scan for FM stations.
- 3. Use the 'Previous/Next' buttons to switch between saved stations.

5.7 Audio Controls

- Volume: Adjust the main volume using the rotary knob on the speaker or the volume buttons on the remote.
- Bass/Treble: Use the dedicated Bass and Treble controls on the speaker or remote to fine-tune the audio output.
- **EQ Modes:** Press the 'EQ' button on the remote to cycle through preset equalizer modes: Pop, Rock, Jazz, Classical.



Image 5.2: The EQ mode display showing available sound presets.

5.8 Karaoke Function

With the included wireless microphone, you can enjoy karaoke:

- Ensure the wireless microphone is powered on and connected to the speaker.
- Adjust the microphone volume using the 'MIC VOL' control on the speaker or remote.
- The speaker features built-in echo control for enhanced vocal effects.



Image 5.3: Users engaging in karaoke with the AKAI UltraBoom-60 speaker and wireless microphone.

5.9 LED Lights

The dynamic LED lights automatically synchronize with the music. There are no specific user controls for the LED patterns; they are designed to enhance the audio experience visually.

6. MAINTENANCE

Cleaning: Use a soft, dry cloth to clean the speaker's exterior. Do not use liquid cleaners or abrasive
materials.

- **Storage:** When not in use for extended periods, store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- Ventilation: Ensure the speaker has adequate ventilation to prevent overheating. Do not block any vents.
- Water Exposure: This speaker is not waterproof. Avoid exposure to water or high humidity.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
No power	Power cord not connected; Power outlet not working	Ensure power cord is securely plugged in; Test the outlet with another device.
No sound	Volume too low; Incorrect source selected; Device not connected properly	Increase volume; Select correct input source (Bluetooth, USB, AUX); Reconnect audio cable or re-pair Bluetooth device.
Bluetooth pairing failure	Speaker not in pairing mode; Device too far; Interference	Ensure speaker is in Bluetooth mode; Move device closer to speaker (within 10 meters); Turn off other Bluetooth devices.
Microphone not working	Microphone off; Low batteries; Mic volume too low	Turn on microphone; Replace batteries; Increase 'MIC VOL' on speaker/remote.
FM radio poor reception	Weak signal; Interference	Reposition the speaker; Try scanning for stations again.

8. SPECIFICATIONS

Feature	Detail
Model Name	HA-TS60
Output Power	60W RMS
Speaker Configuration	Dual 3-inch Mid Speakers, 5.25-inch Woofer
Connectivity	Bluetooth 5.0, USB, AUX, FM Radio
Compatible Devices	Laptop, Smartphone, Tablet, Television
Control Method	Remote Control, On-unit controls
Special Features	Karaoke function with wireless mic, EQ Modes, Dynamic LED Lights
Input Voltage	220 Volts
Product Dimensions	27D x 20.2W x 53.3H Centimeters
Item Weight	6.78 Kilograms
Material	Wood (Cabinet)
Maximum Range (Bluetooth)	10 meters

Feature	Detail
Frequency Response	20 KHz

9. WARRANTY AND SUPPORT

The AKAI UltraBoom-60 Portable Bluetooth Speaker comes with a **1-Year Limited Warranty** from the date of purchase. This warranty covers manufacturing defects under normal use conditions.

For warranty claims, technical support, or customer service, please contact:

• Email: esales@akaiindia.in / Akaicare@akaiindia.in

• Customer Care Number: 8544840022 / 33

• Website: https://akaiindia.in

Please retain your purchase receipt and warranty card for future reference.

© 2025 AKAI. All rights reserved.

Related Documents - UltraBoom-60 (HA-TS60)



PINTECH HA-205 High Voltage Amplifier Instruction Manual

This instruction manual provides detailed information on the PINTECH HA-205 High Voltage Amplifier. It covers product overview, specifications, front and rear panel descriptions, operation procedures, maintenance, cleaning, warranty, repair, and a comparison with other PINTECH amplifier models. Essential for users needing to understand and operate the HA-205 safely and effectively.



PINTECH HA-205 High Voltage Amplifier Instruction Manual

Detailed instruction manual for the PINTECH HA-205 High Voltage Amplifier, covering specifications, front and rear panel descriptions, operation, output connection methods, maintenance, and warranty information.



Nissan Juke HVAC System Service and Repair Manual

Comprehensive guide for servicing the Nissan Juke's Ventilation, Heater, and Air Conditioning (HVAC) system. Covers detailed precautions, preparation steps, system descriptions, diagnostic procedures, refrigerant and lubricant handling, performance testing, symptom diagnosis, and component removal/installation.



AKAI KS878-BT Bluetooth Pedestal Karaoke System Instruction Manual

User manual for the AKAI KS878-BT Bluetooth Pedestal Karaoke System with 6 Speakers and Light Effects. Provides detailed instructions on setup, operation, safety precautions, maintenance, troubleshooting, and specifications.



AKAI A58084 Bluetooth Karaoke Machine Instruction Manual

Comprehensive instruction manual for the AKAI A58084 Bluetooth Karaoke Machine, detailing features, setup, operation, safety guidelines, and troubleshooting for this home entertainment device.



Beurer HA 60 Digital Hearing Amplifiers User Manual

User instructions and manual for the Beurer HA 60 digital hearing amplifiers, covering included items, device description, usage, warnings, maintenance, troubleshooting, technical specifications, and warranty information.