

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Uproot Clean](#) /
- › [Uproot Clean Washing Machine Cleaner Tablets Pro - Instruction Manual](#)

## Uproot Clean wm-tabs-1

# Uproot Clean Washing Machine Cleaner Tablets Pro - Instruction Manual

Model: wm-tabs-1 | Brand: Uproot Clean

## 1. INTRODUCTION

The Uproot Clean Washing Machine Cleaner Tablets Pro are designed to provide a deep clean for your washing machine. These tablets effectively eliminate odors, dissolve grime, and help reduce pet hair accumulation, ensuring your machine operates efficiently and your laundry remains fresh. This manual provides essential information for the safe and effective use of your Uproot Clean tablets.

## 2. SAFETY INFORMATION

**WARNING: Keep out of reach of children and pets. Avoid contact with eyes and skin. In case of contact, rinse thoroughly with water. If swallowed, seek medical attention immediately.**

## 3. PRODUCT OVERVIEW

Uproot Clean Washing Machine Cleaner Tablets Pro are formulated to clean various components of your washing machine, including the drum, valves, hose pipes, seals, and filters. They are compatible with all washing machine types: High-Efficiency (HE), Top-Loading, and Front-Loading models, and are safe for septic systems.

### Key Benefits:

- Eliminates pet odors and other foul smells.
- Dissolves grime, residue, and built-up deposits.
- Reduces excessive pet hair accumulation.
- Helps prolong the life and maintain the performance of your washing machine.

### Product Components:

Each package contains 24 individually wrapped tablets, providing a 12-month supply when used as recommended.

**UPROOT  
CLEAN**

**24** | **1 YEAR**  
TABLETS | SUPPLY



# WASHING MACHINE CLEANER PRO

CLEANS ♦ DEODORIZES ♦ REVITALIZES ♦ SHIELDS



Compatible with all  
washing machine cleaners



Safe for Septic Tanks



Formulated  
Specifically For

**PET  
OWNERS**

Fights pet odor and helps to  
remove pet hair.



Image: Uproot Clean Washing Machine Cleaner Pro 24-pack box with two tablets.

# A Whole Year's Supply in One Box!



Image: Open box of Uproot Clean tablets showing 24 individually wrapped tablets, indicating a year's supply.

## How it Cleans:

# Cleans Beyond the Surface

Drum  
& Basket



Valves  
& Hose Pipes



Seals  
& Filters



+ More

Image: Diagram illustrating how the cleaner targets the drum, basket, valves, hose pipes, seals, and filters.

## Ingredients:

The tablets contain a blend of active ingredients designed for comprehensive cleaning:

- **Sodium Percarbonate:** Provides effervescence and helps remove stains.
- **Tea Polyphenols:** Aids in odor removal.
- **Alcali Protease:** Dissolves hair and eliminates stains.
- **Lipase:** Decomposes fats and stains.
- **Alpha-Amylase:** Dissolves hair starch and stains.
- **Sodium Polyacrylate:** Disperses dirt and prevents stains from resettling.
- **Sodium Silicate:** Softens water and protects the washing machine.
- **Sodium Carbonate & Citric Acid:** Contribute to effervescence and stain removal.

# Renew and Refresh with Powerful Ingredients



## **Alkali Protease**

Dissolve hair and eliminate stains



## **Tea Polyphenols**

Remove odors



## **Lipase**

Decomposes fat & stains



## **Alpha-Amylase**

Dissolves hair starch & stains



## **Sodium Polyacrylate**

Disperses dirt & prevents stains from resettling



## **Sodium Silicate**

Softens water and protect washing machine



## **Sodium Percarbonate, Sodium Carbonate, and Citric Acid**

Add effervescence, remove stains

Image: Visual representation of key ingredients and their cleaning actions.

## 4. SETUP

Before using the Uproot Clean Washing Machine Cleaner Tablets, ensure your washing machine is completely empty. If there is visible residue or excessive dirt, it is recommended to pre-clean the machine by running an empty rinse cycle or wiping down accessible surfaces.

## 5. OPERATING INSTRUCTIONS

Follow these steps for effective cleaning:

### 1. **Step 1: Prepare the Machine**

Ensure the washing machine is completely empty. If necessary, run an empty cycle to prepare it.

### 2. **Step 2: Insert Tablet**

Place one Uproot Clean tablet directly into the washing machine drum. **DO NOT** place the tablet in the detergent dispenser compartment.

**3. Step 3: Run Cycle**

Select and run a "Normal" cycle with hot water, or use your machine's dedicated "Clean Washer" cycle if available.

**4. Step 4: Wipe Residue**


After the cycle is complete, open the washing machine door and wipe away any leftover residue with a clean towel.

## HOW TO USE So Easy Your Dog Can Do It

1. Put one tablet directly in an empty washer tub (not the dispenser)



2. Run a normal hot wash cycle



3. Wipe off any leftover residue and enjoy your spotless, fur-free washing machine!



Image: Step-by-step visual guide on how to use the cleaning tablets.

UPROOT  
CLEAN



24 TABLETS | 1 YEAR SUPPLY

## Directions

### WASHING MACHINE CLEAN

CLEANS + DEODORS



Compatible with all  
washing machine cleaners  
Safe for Septic Tanks



Formulated  
Specifically For  
PET

#### Step 1

Check if the washing is empty and clean. If needed run one cycle to make sure it's ready.

#### Step 2

Insert one tablet directly into the drum. DO NOT put it into the detergent compartment.

#### Step 3

Run on "Normal" with hot water or "Clean Washer" cycle.

#### Step 4

Wipe away any left over residue with a towel.






Image: Detailed directions for use, including a QR code for additional information. For more information, visit [qrco.de/bf1Zyr](http://qrco.de/bf1Zyr).

## 6. MAINTENANCE

For optimal washing machine performance and continuous cleanliness, it is recommended to use one Uproot Clean Washing Machine Cleaner Tablet Pro once a month. Regular use helps prevent the buildup of grime, odors, and pet hair, extending the life of your appliance.

# Your Washing Machine - Like New



Machine Drum Spotless  
Inside and Out



Tub Seals - Impeccable



Hose Pipes - Free of Residue



Under-Drum Area - Friction-Free,  
as it Should Be

Image: Visual comparison of a washing machine drum before and after using the cleaner, highlighting cleanliness of drum, seals, and hose pipes.

## 7. TROUBLESHOOTING

No specific troubleshooting steps are provided for this product. If you encounter persistent issues with your washing machine's cleanliness or performance after using the tablets, please refer to your washing machine's instruction manual or contact Uproot Clean customer support for assistance.

## 8. SPECIFICATIONS

Feature	Detail
Brand	Uproot Clean
Model Number	wm-tabs-1
Item Form	Tablet

Scent	Unscented
Specific Uses	Washing Machine Cleaning
Material Feature	Safe for septic tanks
Package Dimensions	7.5 x 6.5 x 0.7 inches
Item Weight	11.22 ounces
Manufacturer	Uproot Lint LLC
Date First Available	July 31, 2024
ASIN	B0D6NLT286

## 9. WARRANTY AND SUPPORT

Specific warranty information for Uproot Clean Washing Machine Cleaner Tablets Pro is not provided in the product details. For any product-related inquiries, support, or concerns, please contact Uproot Clean directly through their official channels or the retailer where the product was purchased.

