

Andis MLC

Andis Black Label MLC Professional Master Cordless Lithium-Ion Hair Clipper Instruction Manual

Model: MLC | UPC: 040102006364

IMPORTANT SAFETY INFORMATION

For your safety and to ensure proper operation, please read all instructions carefully before using the Andis Black Label MLC Professional Master Cordless Lithium-Ion Hair Clipper.

- Always unplug the clipper before cleaning or replacing parts.
- Do not use the clipper on wet hair. Ensure hair is dry before cutting.
- Keep the appliance out of reach of children. Adult supervision is required if used near children.
- Always follow the manufacturer's instructions for cleaning and maintenance to prevent damage and ensure longevity.
- Do not immerse the clipper in water or other liquids.
- If the power cord is damaged, it must be replaced by the manufacturer, its service agent, or similarly qualified persons to avoid a hazard.

PRODUCT OVERVIEW

The Andis Black Label MLC Professional Master Cordless Lithium-Ion Hair Clipper is designed for professional use, offering powerful and precise cutting performance. This special edition features a sleek black design and an adjustable Phaze Blade.






Figure 1: Andis Black Label MLC Clipper on its charging stand.

Key Features:

- **Black Label Colorway:** Exclusive all-black finish.
- **Revolutionary Phaze Blade:** Adjustable carbon-steel blade (0000-0A) for versatile blending and precision.
- **Powerful Rotary Motor:** Delivers 6,500 SPM (strokes per minute) for efficient cutting through all hair types with an improved sound profile.
- **Lithium-Ion Battery:** Provides up to 1.5 hours of cordless operation, with cord/cordless flexibility.
- **Ultra-durable Housing:** Constructed from unbreakable aluminum for long-lasting performance.
- **Premium Charging Stand:** Easy and convenient charging.
- **Bonus Size 0 Dual-Magnetic Attachment Comb:** Included for additional cutting options.



Figure 2: Detailed view of the clipper highlighting its main features.

PACKAGE CONTENTS

Verify that all items are present in the package:

- Andis Black Label MLC Professional Master Cordless Lithium-Ion Hair Clipper
- Adjustable Phaze Blade (pre-attached)
- Premium Charging Stand
- Power Adapter
- Size 0 Dual-Magnetic Attachment Comb (1/16" / 1.5mm)
- Blade Oil
- Cleaning Brush



Figure 3: All items included in the product package.

SETUP AND INITIAL USE

Charging the Clipper:

1. Connect the power adapter to the charging stand.
2. Plug the power adapter into a suitable electrical outlet.
3. Place the clipper onto the charging stand. Ensure the clipper is seated correctly and the charging indicator light illuminates.
4. Allow the clipper to charge fully before its first use. A full charge typically takes approximately 90 minutes and provides up to 1.5 hours of run time.

Blade Adjustment:

The Phaze Blade is adjustable, allowing for cutting lengths from 0000 (closest cut) to 0A (longer cut). Use the taper lever on the side of the clipper to adjust the blade. Moving the lever up shortens the cut, and moving it down lengthens it.



Figure 4: Close-up of the adjustable Phaze Blade.

Attaching Guide Combs:

To achieve longer cutting lengths, attach the provided Size 0 dual-magnetic attachment comb. Align the comb with the clipper blade and firmly press it into place until it clicks securely. Ensure the comb is fully seated before use.

OPERATING INSTRUCTIONS

General Hair Cutting:

1. Ensure hair is clean and dry before cutting.
2. Apply a small amount of blade oil to the clipper blades before each use. Turn the clipper on for a few seconds to distribute the oil.
3. Select the desired cutting length using the taper lever or by attaching a guide comb.
4. Hold the clipper firmly and move it against the direction of hair growth. Use smooth, overlapping strokes.

5. For blending, gradually adjust the taper lever or switch to different guide combs.
6. Regularly clear accumulated hair from the blades during use to maintain optimal performance.

Corded Operation:

The clipper can be operated directly from the power adapter if the battery is low or if preferred. Simply plug the power adapter into the clipper and an electrical outlet. The clipper will run while charging.

MAINTENANCE AND CARE

Cleaning the Blades:

1. After each use, turn off and unplug the clipper.
2. Use the provided cleaning brush to remove loose hair from the blades and the clipper housing.
3. For a more thorough cleaning, the blade set can be carefully removed. Refer to the Andis website or authorized service center for detailed blade removal instructions if needed.

Oiling the Blades:

To ensure optimal cutting performance and extend blade life, oil the blades before and after each use. Apply 2-3 drops of Andis clipper oil across the top of the blade teeth and 1 drop on each side of the blade heel. Turn the clipper on for a few seconds to allow the oil to penetrate.

Storage:

Store the clipper in a cool, dry place, away from moisture and direct sunlight. Always ensure the clipper is clean and oiled before storing.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Clipper does not turn on.	Battery is discharged; Power adapter not connected; Faulty outlet.	Charge the clipper fully. Ensure power adapter is securely connected to both clipper/stand and a working electrical outlet. Test the outlet with another device.
Clipper pulls or snags hair.	Blades are dull; Blades are not oiled; Hair buildup between blades; Incorrect cutting technique.	Oil the blades. Clean hair from between blades. Consider replacing blades if dull. Ensure you are cutting against the direction of hair growth.
Clipper runs slowly or with reduced power.	Low battery charge; Hair buildup in motor area; Blades are not oiled.	Charge the clipper. Clean blades and ensure they are oiled. If problem persists, contact customer support.
Excessive noise or vibration.	Blades are misaligned; Internal component issue.	Check blade alignment. If the issue continues, discontinue use and contact Andis customer support.

PRODUCT SPECIFICATIONS

Feature	Detail
Model Number	562305

Feature	Detail
Blade Type	Adjustable Carbon-Steel Phaze Blade
Cutting Lengths	0000 to 0A (adjustable via taper lever)
Motor Type	Rotary Motor
Motor Speed	6,500 SPM (Strokes Per Minute)
Battery Type	Lithium-Ion
Run Time	Up to 1.5 hours (90 minutes)
Power Source	Cord/Cordless Operation
Housing Material	Ultra-durable Aluminum
Weight	1.17 Kilograms (approximately 2.58 Pounds)
UPC	040102006364

WARRANTY AND SUPPORT



Andis products are manufactured to the highest quality standards. For information regarding warranty coverage, product registration, or technical support, please visit the official Andis website or contact their customer service department.





Andis Official Website: www.andis.com

Please retain your proof of purchase for warranty claims.

© 2025 Andis Company. All rights reserved.

Related Documents - MLC

	<p>Andis Master MLC Cordless Clipper: Use and Care Instructions</p> <p>Comprehensive guide for the Andis Master MLC Cordless Clipper, covering important safeguards, operating instructions, charging, maintenance, and troubleshooting.</p>
	<p>Andis Master & Master Cordless Adjustable Blade Series Clipper Guide</p> <p>Explore the Andis Master and Master Cordless Adjustable Blade Series, featuring Fade, Phaze, Taper, and Phat cutters. This guide details cut lengths, tooth counts, and specifications for professional barbers and stylists.</p>

 <p>ANDIS M-FORCE WIDE BLADE ASSEMBLY INSTRUCTIONS</p> <p>1. Insert the blade into the clipper head. 2. Push the blade down until it is fully seated. 3. Turn the clipper head to the right to lock the blade in place. 4. Push the clipper head to the left to release the blade. 5. Insert the blade into the clipper head. 6. Push the blade down until it is fully seated. 7. Turn the clipper head to the right to lock the blade in place. 8. Push the clipper head to the left to release the blade.</p> <p>USE 2023 REVISION INSTRUCTIONS</p>	<p>Andis M-Force Wide Blade Assembly Instructions - Step-by-Step Guide</p> <p>Detailed, step-by-step instructions for assembling the Andis M-Force Wide Blade. Learn how to properly clean, reassemble, and oil your clipper blade for optimal performance.</p>
 <p>ANDIS USE & CARE INSTRUCTIONS TS-1</p> <p>For professional use only. Not for home use.</p>	<p>Andis TS-1 Use & Care Instructions Manual</p> <p>Comprehensive guide for the Andis TS-1 shaver, covering safety precautions, operating instructions, maintenance, battery care, and proper disposal for optimal performance and longevity.</p>
 <p>andis USE AND CARE</p> <p>MODEL RBC</p> <p>Read these instructions carefully before using the clipper. It is important to read these instructions carefully before using the clipper. It is important to read these instructions carefully before using the clipper. It is important to read these instructions carefully before using the clipper.</p>	<p>Andis RBC Hair Clipper: Use and Care Guide</p> <p>Comprehensive use and care guide for the Andis RBC hair clipper, covering important safeguards, operating instructions, maintenance, and troubleshooting for optimal performance.</p>
 <p>andis</p>	<p>Andis HVD-1 Professional Hair Dryer User Manual and Care Guide</p> <p>Comprehensive guide for the Andis HVD-1 professional hair dryer, covering important safety precautions, operating instructions, maintenance, cleaning, and warranty information.</p>