De'Longhi RM

De'Longhi Magnifica Evo Series User Manual

Fully Automatic Espresso & Coffee Machine

Introduction

This manual provides comprehensive instructions for the safe and efficient operation, maintenance, and troubleshooting of your De'Longhi Magnifica Evo Fully Automatic Espresso and Coffee Machine. Please read this manual thoroughly before using the appliance for the first time and keep it for future reference.

The De'Longhi Magnifica Evo series offers a range of fully automatic espresso and cappuccino machines designed to deliver café-quality beverages. Key features include a built-in conical burr grinder with 13 adjustable settings, an intuitive touch display, and for certain models, the patented LatteCrema milk frothing system.



Image: Two De'Longhi Magnifica Evo machines. The left machine features the LatteCrema milk frothing system, preparing a layered coffee drink. The right machine is a standard espresso model, brewing two shots of espresso. Both machines are silver and black.

Setup

Unpacking and Initial Placement

- Carefully remove all packaging materials from the appliance.
- Place the machine on a stable, flat surface, away from water sources and heat. Ensure adequate ventilation around the unit.

Water Tank Filling

The water tank is located on the side of the machine. Pull it out to fill with fresh, cold water. Ensure the tank is properly seated before operation.

Your browser does not support the video tag.

Video: Demonstrates the removal and refilling of the water tank on the De'Longhi Magnifica Evo coffee machine. The tank slides out from the side for easy access.

Coffee Bean Hopper

Open the lid on top of the machine and pour fresh coffee beans into the hopper. Do not overfill. The integrated conical burr grinder will process the beans for each brew.



Image: A close-up view of the top of the De'Longhi Magnifica Evo machine, highlighting the coffee bean hopper filled with whole beans. Text overlays indicate "Freshly Ground Coffee," "13 Grind Settings," and "Bypass for Ground Coffee."

Milk Frothing System (LatteCrema Models)

For models with the LatteCrema system, attach the milk carafe to the machine. Fill the carafe with milk (dairy or alternative) up to the desired level. The system automatically froths the milk directly into your cup.

Your browser does not support the video tag.

Video: Demonstrates how to use the LatteCrema milk frothing system on the De'Longhi Magnifica Evo. It shows filling the milk carafe, the frothing process for various milk types, and adjusting the frothing spout.

Operating Instructions

Powering On and Pre-heating

Press the power button to turn on the machine. It will undergo a brief pre-heating cycle, indicated by flashing lights. Wait until the lights are solid before selecting a beverage.

Selecting a Beverage

The intuitive touch display offers various one-touch beverage options. Simply press the icon corresponding to your desired drink:

- **My Latte:** Customizable latte option.
- **Latte Macchiato:** Layered milk and espresso.
- **Cappuccino:** Espresso with frothed milk.
- **Espresso:** A concentrated coffee shot.
- **Coffee:** Standard brewed coffee.
- **Over Ice:** Specifically brewed for iced coffee.
- **Hot Water:** For tea or other hot beverages.



Image: The control panel of the De'Longhi Magnifica Evo, displaying touch icons for "My Latte," "Latte Macchiato," "Cappuccino," "Espresso," "Coffee," "Over Ice," and "Hot Water." The machine is silver with a black top.

Adjusting Coffee Strength and Grind Settings

You can adjust the strength of your coffee using the bean icons on the control panel. More beans indicate a stronger brew. The conical burr grinder has 13 adjustable settings, allowing you to fine-tune the grind for optimal flavor extraction. Refer to the grinder adjustment knob located inside the bean hopper.

Brewing Process

Once a beverage is selected, the machine will automatically grind the beans (if using whole beans), brew the coffee, and dispense it into your cup. For milk-based drinks, the LatteCrema system will froth and dispense milk before or after the coffee, depending on the selected beverage.

Maintenance

Daily Cleaning

- **Drip Tray and Grounds Container:** Empty and rinse the drip tray and coffee grounds container daily. These parts are dishwasher-safe.
- **Milk Carafe (LatteCrema Models):** After each use, perform the automatic cleaning cycle for the milk carafe. Detach and rinse the carafe components regularly.

Your browser does not support the video tag.

Video: Demonstrates the removal and emptying of the coffee grounds container and drip tray from the De'Longhi Magnifica Evo. The process is shown to be simple and hygienic.

Descaling

The machine will indicate when descaling is required via an illuminated icon on the control panel. Use only De'Longhi descaling solution and follow the instructions provided with the solution and in the machine's display prompts. Regular descaling is crucial for maintaining machine performance and longevity.

Brew Unit Cleaning

The brew unit should be removed and rinsed under running water at least once a month. Ensure it is completely dry before reinserting.

Troubleshooting

Common Issues and Solutions

Problem	Possible Cause	Solution
No coffee dispensed.	Water tank empty; coffee beans empty; brew unit clogged.	Refill water tank; refill bean hopper; clean brew unit.
Coffee is too weak/strong.	Incorrect strength setting; grind setting too coarse/fine.	Adjust coffee strength setting; adjust grind setting.
Milk not frothing properly.	Milk carafe dirty; milk type unsuitable; frothing nozzle clogged.	Clean milk carafe and nozzle; use fresh, cold milk (dairy or suitable alternative); ensure nozzle is clear.
Descaling light illuminated.	Machine requires descaling.	Perform descaling cycle as per manual instructions.

For issues not listed here, please consult the full user manual or contact De'Longhi customer support.

Specifications

Brand: De'Longhi

Model: Magnifica Evo (RM)

Coffee Maker Type: Fully Automatic Espresso Machine

Coffee Input Type: Whole Beans (with bypass for pre-ground coffee)

Grinder: Conical Burr Grinder with 13 settings

Special Feature: Milk Frother (LatteCrema System on applicable models)

Beverage Options: Espresso, Coffee, Long, Americano, Steam (manual frother models); My Latte, Latte Macchiato, Cappuccino, Espresso, Coffee, Over Ice, Hot Water (LatteCrema models)

ASIN: B0D6QCWJ3G

Warranty and Support

For warranty information, please refer to the warranty card included with your product or visit the official De'Longhi website. Keep your proof of purchase for warranty claims.

For technical support, spare parts, or service, please contact De'Longhi customer service. Contact details can be found on the De'Longhi website or in your product packaging.

Visit the official De'Longhi Store for more products and support:De'Longhi Store

© 2024 De'Longhi. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

How can I fix the steam error and continuous flickering descaling light on my De'Longhi Magnifica Evo?

When the steam and descaling lights flicker continuously on a De'Longhi Magnifica Evo, it typically indicates that the machine requires a descaling cycle or that the water circuit needs to be primed/cleared.Perform a Descaling...

Read full answer