**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



### WolfLawS X1

# WolfLawS X1 Wireless Gaming Headset User Manual

Model: X1

## 1. Introduction

Thank you for choosing the WolfLawS X1 Wireless Gaming Headset. This manual provides detailed instructions for setting up, operating, and maintaining your headset to ensure optimal performance and an immersive gaming experience. Please read this manual thoroughly before use.




Figure 1.1: WolfLawS X1 Wireless Gaming Headset with its 2.4GHz receiver.

## 2. Product Overview

### 2.1 Key Features

- **Wide Compatibility:** Dual-mode connectivity (Bluetooth and 2.4G) for Xbox Series X|S, Xbox One, PS5, PC, Mac, and Nintendo Switch.
- **Superior Sound Quality:** Equipped with 50mm speakers and 3D surround sound technology for realistic audio.
- **Extended Battery Life:** Up to 40 hours of continuous playtime on a single charge (2 hours for full charge).
- **Low Latency:** Less than 20ms audio latency for instant feedback.
- **Noise-Canceling Microphone:** Detachable microphone ensures clear communication.
- **Comfortable Design:** Adjustable headband and memory foam ear cushions for prolonged use.
- **Convenient Controls:** Easy-to-reach buttons for volume, mute, and other settings.

### 2.2 Package Contents

The WolfLawS X1 Wireless Gaming Headset package includes:

- WolfLawS X1 Wireless Gaming Headset
- 2.4GHz Wireless Transmitter (Receiver)
- USB-C Charging Cable
- User Manual

## 3. Setup and Connection

### 3.1 Charging the Headset

Before first use, fully charge the headset. Connect the supplied USB-C charging cable to the headset's Type-C port and the other end to a USB power source. A full charge takes approximately 2 hours and provides up to 40 hours of playtime.




Figure 3.1: Illustration of the headset's 40-hour battery life and 2.4GHz wireless connectivity.

## 3.2 Connecting to Devices (2.4GHz Wireless Mode)

The 2.4GHz wireless mode is compatible with Xbox Series X|S, PS5, and PC/laptops. For Xbox One controllers, an extra Microsoft Adapter (not included) may be required for older versions.

1. Insert the X1 Receiver (transmitter) firmly and fully into the USB port of your console (Xbox Series X|S, PS5, PC) or Xbox One controller. Ensure there is no gap between the receiver and the port to avoid audio issues.
2. Press and hold the Power Button on the headset for 2 seconds to turn it on. The headset will automatically attempt to connect to the receiver.
3. Once connected, the indicator light on the headset will stabilize.




Figure 3.2: Instructions for plugging the X1 Receiver into an Xbox controller and activating the microphone.





Figure 3.3: Visual guide for ensuring the dongle is plugged in tightly and fully to prevent audio issues.

## 3.3 Connecting to Devices (Bluetooth Mode)

Bluetooth mode is compatible with Mac, Nintendo Switch, and mobile devices.

1. Press and hold the Light/Wireless or BT Mode button on the headset for 2 seconds to switch to Bluetooth mode. The indicator light will flash, indicating pairing mode.
2. On your device (Mac, Nintendo Switch, mobile), go to Bluetooth settings and select "WolfLawS X1" from the list of available devices.
3. Once paired, the indicator light on the headset will stabilize.





Figure 3.4: Compatibility overview of the X1 wireless receiver with different gaming platforms and devices.

## 4. Operating Instructions

### 4.1 Headset Controls




Figure 4.1: Overview of the easy-to-use function buttons on the headset.

- **Light/Wireless or BT Mode Button:** Click once for Light On/Off. Hold for 2 seconds to switch between Wireless (2.4GHz) and Bluetooth modes.
- **Volume Wheel:** Rotate to adjust the audio volume.
- **Type-C Port:** Used for charging the headset.
- **Mic Mute Switch:** Toggle to mute or unmute the microphone.
- **Detachable Mic:** Plug in or remove the microphone as needed.
- **Power Button:** Hold for 2 seconds to activate or turn off the headset.

## 4.2 Audio and Microphone Usage

The headset features 50mm speakers for immersive 3D surround sound and a noise-canceling microphone for clear voice pickup.




Figure 4.2: Detailed view of the 50mm audio drivers and 3D surround sound capabilities.




Figure 4.3: Visual representation of the microphone's ability to pick up clear sound.

To activate the microphone function on Xbox, follow these steps:

1. Connect to the controller and enter the interface.
2. Click **Settings** > **General** > **Volume and Audio Output**.
3. See **Advanced** and choose **Audio testing & details**.
4. Click **Volume**.
5. Enter into the audio & music interface, then turn the **Headset mic** on.

Alternatively, for some Xbox setups:

1. Connect to the controller and enter the interface.
2. Choose **Xbox Accessories**.
3. Click **More Options**.
4. Click **Volume**.
5. Enter into the audio & music interface, then turn the **Headset mic** on.

## 5. Maintenance

To ensure the longevity and optimal performance of your WolfLawS X1 headset, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to clean the headset. Do not use abrasive cleaners or solvents. For ear cushions, gently wipe with a damp cloth and allow to air dry completely.
- **Storage:** Store the headset in a cool, dry place away from direct sunlight and extreme temperatures.
- **Handling:** Avoid dropping the headset or exposing it to excessive force. Do not pull on the cables forcefully.
- **Moisture:** The headset is not water-resistant. Avoid exposure to water or high humidity.

## 6. Troubleshooting

If you encounter issues with your WolfLawS X1 headset, refer to the following common problems and solutions:

| Problem | Possible Cause | Solution |
|---|---|---|
| No audio or buzzing/echoing sound | Receiver not fully inserted; Low Xbox controller battery. | Ensure the receiver is inserted firmly and fully into the port. Ensure your Xbox controller has sufficient battery power. |
| Microphone not working | Mic mute switch engaged; Incorrect console settings; Microphone not properly attached. | Check the mic mute switch on the headset. Verify microphone settings on your console (refer to Section 4.2). Ensure the detachable microphone is securely plugged in. |
| Headset not connecting | Out of range; Low headset battery; Incorrect mode selected. | Ensure the headset is within 49ft (15m) of the receiver/device. Charge the headset fully. Confirm the correct mode (2.4GHz or Bluetooth) is selected for your device. |
| Audio too low or distorted | Volume settings too low; Console audio mixer settings. | Adjust the volume wheel on the headset. Check and adjust the volume settings on your console (e.g., Xbox audio mixer). |

## 7. Specifications

| Feature | Detail |
|---|---|
| Model Name | X1 |
| Connectivity Technology | Wireless (Bluetooth, 2.4GHz RF) |
| Compatible Devices | Xbox Series X\|S, Xbox One, PS5, PC, Mac, Nintendo Switch |
| Audio Driver Size | 50 Millimeters |
| Frequency Range | 20 Hz - 20,000 Hz |
| Impedance | 160 Ohm |

| Feature | Detail |
|---|---|
| Battery Life | 40 Hours |
| Charging Time | 2 Hours |
| Audio Latency | 20 Milliseconds |
| Microphone | Detachable, Noise-Canceling |
| Ear Placement | Over Ear |
| Material | Plastic |
| Item Weight | 1.13 ounces |
| Color | Green |

## 8. Warranty and Support

For warranty information and customer support, please refer to the documentation included with your product packaging or visit the official WolfLawS website. Keep your purchase receipt as proof of purchase for any warranty claims.

© 2024 WolfLawS. All rights reserved.

### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

**Open the live page**

**https://manuals.plus/asin/B0D6QSMGZQ**

More documents and user manuals: **https://manuals.plus/**